

Linksys AHC1CP1

Linksys Flip Video HDMI Cables (Model AHC1CP1) User Manual

Model: AHC1CP1

1. PRODUCT OVERVIEW

The Linksys Flip Video HDMI Cables are designed to connect your Flip UltraHD or MinoHD camcorder directly to an HDTV. This allows you to view your recorded high-definition videos on a larger screen with clear and crisp digital quality. The package includes two cables: a shorter 2-foot cable for portability and a longer 6.5-foot cable for home use.

Key Features:

- **Compatibility:** Works with Flip MinoHD video cameras (M31120B, M3160S, M2120M) and select Flip UltraHD video cameras (U260 models, U2120 models).
- **Easy Viewing:** Provides a convenient way to enjoy your HD videos on any HDMI-compatible television.
- **High-Quality Signal:** Delivers a high-quality digital signal for crisp and clear video playback on your HDTV.
- **Dual Cable Pack:** Includes one 2-foot HDMI cable and one 6.5-foot HDMI cable for versatile use.
- **Connector Types:** Each cable features a mini-HDMI connector for the Flip video camera and a standard HDMI connector for the HDTV.

2. SETUP INSTRUCTIONS

Follow these steps to connect your Flip Video camcorder to your HDTV using the HDMI cables:

1. **Identify the Cables:** The package contains two HDMI cables. Choose the appropriate length (2-foot for travel or 6.5-foot for home use) based on your setup.
2. **Locate Connectors:** Each cable has two different ends: a smaller *mini-HDMI* connector and a larger *standard HDMI* connector.
3. **Connect to Camcorder:** Carefully insert the **mini-HDMI** connector end into the HDMI port on your Flip Video HD camcorder. This port is typically located on the side or bottom of the camcorder.
4. **Connect to HDTV:** Insert the **standard HDMI** connector end into an available HDMI input port on your HDTV. Note the HDMI input number (e.g., HDMI 1, HDMI 2) for later selection.

5. **Power On Devices:** Ensure both your Flip Video camcorder and your HDTV are powered on.
6. **Select Input:** On your HDTV, use the remote control to select the corresponding HDMI input source (e.g., HDMI 1, HDMI 2) where you connected the cable.



Image 1: Connecting the mini-HDMI end to a Flip Video camcorder.



Image 2: A closer view of the mini-HDMI cable securely connected to the camcorder's port.

3. OPERATING INSTRUCTIONS

Once the cables are connected and the correct HDMI input is selected on your HDTV, your Flip Video camcorder's display should mirror on your television screen. You can then navigate your camcorder's menu and play back videos directly on your HDTV.

- Use your Flip Video camcorder's controls to browse through your recorded videos.
- Select a video to play it back on your HDTV.
- The audio from your camcorder will also be transmitted through the HDMI cable to your HDTV's speakers.

Product Overview Video:

Your browser does not support the video tag.

Video 1: An introductory video demonstrating the simplicity of Flip Video cameras and their sharing capabilities. While not directly showing cable connection, it illustrates the product ecosystem.

4. MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Linksys Flip Video HDMI Cables, follow these maintenance guidelines:

- **Storage:** Store cables in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cables sharply, as this can damage the internal wires.
- **Cleaning:** Use a soft, dry cloth to gently wipe the cable and connectors. Do not use liquid cleaners or solvents, as they may damage the cable's insulation or connector pins.
- **Handling:** Always grasp the connector ends when plugging or unplugging the cables. Avoid pulling on the cable itself, which can strain the connections and lead to damage.
- **Protection:** When not in use, consider using cable ties or wraps to keep the cables neatly organized and prevent tangling or damage.

5. TROUBLESHOOTING

If you encounter issues while using your HDMI cables, refer to the following troubleshooting tips:

- **No Picture/Sound on TV:**
 - Ensure both the camcorder and HDTV are powered on.
 - Verify that the HDMI cable is securely connected to both the camcorder and the HDTV.
 - Check that the correct HDMI input source is selected on your HDTV (e.g., HDMI 1, HDMI 2).
 - Try using the other HDMI cable provided in the pack to rule out a faulty cable.
 - Test the camcorder with another HDMI-compatible display if possible.
- **Poor Picture Quality:**
 - Ensure the cable connections are firm. Loose connections can degrade signal quality.
 - Confirm that your Flip Video camcorder is set to record in HD resolution for optimal output.
 - Check your HDTV's picture settings.
- **Cable Does Not Fit:**
 - Ensure you are using the mini-HDMI end for the camcorder and the standard HDMI end for the TV. These connectors are different sizes.
 - Do not force the connectors, as this can cause damage to the ports or the cable.

6. SPECIFICATIONS

Feature	Detail
Brand	Linksys
Model	AHC1CP1
Connector Type	HDMI (Mini-HDMI to Standard HDMI)
Cable Type	HDMI
Compatible Devices	Flip MinoHD and UltraHD Camcorders, HDMI-compatible Televisions

Feature	Detail
Color	Black; White (Cables may vary in color)
Connectivity Technology	HDMI
Unit Count	1.0 Count (Package contains two cables)
Item Weight	7.2 ounces
Cable Lengths	One 2-foot cable, one 6.5-foot cable
Manufacturer	CISCO
UPC	813477010157



Image 3: A white/silver variant of the Linksys Flip Video HDMI cable.



Image 4: A black variant of the Linksys Flip Video HDMI cable.

7. WARRANTY AND SUPPORT

Warranty Information: This product is covered by a **90-day warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support: For further assistance, technical support, or warranty inquiries, please visit the official Linksys support website or contact their customer service. Refer to the packaging or the Linksys website for the most current contact information.

Online Resources: You may find additional resources, FAQs, and product registration information on the [Linksys Store on Amazon](#) or the main Linksys website.

