

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ASUS](#) /

› [ASUS VH232H 23-Inch Full-HD LCD Monitor User Manual](#)

ASUS VH232H

ASUS VH232H 23-Inch Full-HD LCD Monitor User Manual

Model: VH232H

1. INTRODUCTION

The ASUS VH232H is a 23-inch Full-HD LCD monitor designed for personal entertainment and computing. It features a 1920x1080 resolution, integrated speakers, and multiple connectivity options including HDMI, DVI, and VGA. This manual provides comprehensive instructions for the proper setup, operation, and maintenance of your monitor to ensure optimal performance and longevity.

2. SAFETY INFORMATION

- Always disconnect the power cord from the electrical outlet before cleaning the monitor.
- Do not expose the monitor to rain or moisture to prevent fire or shock hazards.
- Do not open the monitor casing. There are no user-serviceable parts inside. Refer all servicing to qualified service personnel.
- Place the monitor on a stable, flat surface to prevent it from falling.
- Ensure proper ventilation around the monitor. Do not block ventilation openings.
- Use only the power adapter and cables supplied with the monitor or specified by the manufacturer.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- ASUS VH232H LCD Monitor
- Monitor Stand Base and Neck
- Power Cord

- VGA Cable
- Audio Cable
- Quick Start Guide
- Warranty Card

Note: Contents may vary by region. If any items are missing or damaged, contact your retailer.

4. SETUP

4.1 Assembling the Monitor Stand

1. Carefully place the monitor face down on a soft, clean cloth to prevent scratches.
2. Attach the stand neck to the back of the monitor, aligning the tabs and pushing firmly until it clicks into place.
3. Attach the stand base to the bottom of the stand neck. Secure it with the captive screw located on the underside of the base.
4. Gently lift the monitor and place it upright on a stable surface.

4.2 Connecting Your Monitor

The ASUS VH232H offers multiple input options. Choose the appropriate cable for your device.



Figure 4.2.1: Rear view of the ASUS VH232H monitor displaying the HDMI, DVI, VGA, and audio input/output ports.

- **HDMI Connection:** Connect one end of an HDMI cable to the HDMI port on your computer's graphics card and the other end to the HDMI port on the monitor. HDMI transmits both video and audio.
- **DVI Connection:** Connect one end of a DVI cable to the DVI port on your computer's graphics card and the other end to the DVI port on the monitor. DVI transmits video only.
- **VGA Connection:** Connect one end of a VGA cable to the VGA port on your computer's graphics card and the other end to the VGA port on the monitor. VGA transmits video only.
- **Audio Connection:** If using DVI or VGA, connect the included audio cable from your computer's audio output jack to the 'Audio In' port on the monitor to utilize the integrated speakers.
- **Power Connection:** Connect the power cord to the monitor's power input, then plug the other end into a grounded electrical outlet.

4.3 Powering On

1. Ensure all cables are securely connected.
2. Press the power button on the front of the monitor. The power indicator light will illuminate.

3. Turn on your computer. The monitor should automatically detect the input signal.



Figure 4.3.1: Front view of the ASUS VH232H monitor, showcasing its display and sleek design.

5. OPERATING THE MONITOR

5.1 Control Buttons

The control buttons are located on the lower right bezel of the monitor.



Figure 5.1.1: Close-up view of the monitor's control buttons, including Menu, Input Select, and Power.

- **Power Button:** Turns the monitor on or off.
- **Menu Button:** Activates the On-Screen Display (OSD) menu or enters a sub-menu.
- **Input Select Button:** Cycles through available video input sources (HDMI, DVI, VGA).
- **Splendid Button:** Quick access to ASUS Splendid Video Intelligence Technology modes.
- **Brightness/Volume Buttons:** Adjust brightness or navigate OSD menu options.

5.2 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various display settings.

1. Press the **Menu** button to activate the OSD menu.
2. Use the navigation buttons (often marked with arrows or similar to brightness/volume controls) to move through the menu options.
3. Press the **Menu** button again (or a dedicated 'Select' button) to enter a sub-menu or confirm a selection.
4. Use the navigation buttons to adjust values or select options.
5. Press the **Exit** button (often the power button or a dedicated 'Exit' button) to close the OSD menu.

Key OSD Settings:

- **Splendid:** Select from various preset display modes (e.g., Standard, Game, Scenery, Night View, Theater, sRGB) optimized for different content types.
- **Color:** Adjust Brightness, Contrast, Saturation, Color Temperature, and Skin Tone.
- **Image:** Fine-tune Sharpness, Aspect Ratio Control, ASCR (ASUS Smart Contrast Ratio), and Trace Free.

- **Input Select:** Manually switch between HDMI, DVI, and VGA inputs.
- **System Setup:** Adjust OSD settings (language, position, timeout), ECO mode, and reset to factory defaults.

5.3 Integrated Speakers

The monitor includes built-in 2W stereo speakers. For optimal audio quality, especially for music or gaming, external speakers are recommended. Adjust the volume through the OSD menu or your computer's sound settings.

6. MAINTENANCE

6.1 Cleaning the Monitor

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a non-ammonia, non-alcohol based screen cleaner. Do not spray cleaner directly onto the screen.
- **Casing:** Use a soft, dry cloth to wipe the monitor casing. Avoid using abrasive cleaners or solvents.

6.2 Storage

If storing the monitor for an extended period, disconnect all cables, pack it in its original packaging (if available), and store it in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your ASUS VH232H monitor.

Problem	Possible Cause	Solution
No power / Power LED off	Power cord not connected; Power outlet faulty; Monitor power button off.	Ensure power cord is securely connected to monitor and outlet. Test outlet with another device. Press monitor power button.
No image / "No Signal" message	Video cable not connected; Incorrect input source selected; Computer not powered on or in sleep mode.	Check video cable connections (HDMI, DVI, VGA). Use the Input Select button to cycle through inputs. Ensure computer is on and not in sleep mode.
Image too dark or too bright	Brightness/Contrast settings incorrect.	Adjust Brightness and Contrast settings via the OSD menu. Try different Splendid modes.
Flickering image	Loose video cable; Graphics card issue; Refresh rate mismatch.	Reseat video cable. Update graphics card drivers. Adjust display refresh rate in your computer's display settings.
No audio from integrated speakers	Audio cable not connected (for DVI/VGA); Volume too low; Muted; Incorrect audio output selected on computer.	Ensure audio cable is connected (if not using HDMI). Increase volume via OSD or computer. Check computer's sound output settings.

8. SPECIFICATIONS

Feature	Description
---------	-------------

Feature	Description
Screen Size	23 Inches Wide (16:9)
Resolution	Full HD 1920 x 1080
Response Time	5 ms
Contrast Ratio	20,000,000:1 (ASCR)
Brightness	Not specified in input, typical for LCD
Connectivity	HDMI, DVI, VGA, Audio In, SPDIF
Speakers	2 x 2W Stereo RMS
Dimensions (LxWxH)	21.61 x 8.66 x 13.78 inches
Item Weight	12.1 pounds
VESA Wall Mounting	100x100mm

9. WARRANTY AND SUPPORT

Your ASUS VH232H monitor is covered by a 3-year system and panel warranty. ASUS also offers a Rapid Replacement service, which provides a replacement unit as soon as the defective unit is in the mail, minimizing your downtime.

For technical support, warranty claims, or service inquiries, please visit the official ASUS support website or contact your local ASUS customer service center. Have your product model number (VH232H) and serial number ready when contacting support.

Please refer to the warranty card included in your package for detailed terms and conditions.



© 2024 ASUS. All rights reserved.

Related Documents - VH232H



[ASUS ROG Strix XG259CM Gaming Monitor User Manual and Specifications](#)

A comprehensive guide to the ASUS ROG Strix XG259CM gaming monitor, covering setup, features like GamePlus and GameVisual, specifications, safety information, and troubleshooting. Learn how to connect and configure your display for an optimal gaming experience.

ASUS
PA248 Series
LCD Monitor

User Guide



HDMI

[ASUS PA248 Series LCD Monitor User Guide: Setup, Features, and Specifications](#)

A comprehensive user guide for the ASUS PA248 Series LCD Monitor. This document details setup procedures, OSD menu functions, troubleshooting tips, technical specifications, and supported operating modes, providing users with essential information for optimal display performance.

ASUS
VS248 Series
LCD Monitor

User Guide



HDMI

[ASUS VS248 Series LCD Monitor User Guide](#)

Official user guide for the ASUS VS248 Series LCD Monitor, providing detailed instructions on setup, operation, OSD menu configuration, specifications, troubleshooting, and supported display modes. Learn how to connect and optimize your ASUS VS248 monitor for an enhanced viewing experience.

ASUS
VH236/VH232/VH202 Series
LCD Monitor

User Guide



[ASUS VH236/VH232/VH202 Series LCD Monitor User Guide](#)

Comprehensive user guide for the ASUS VH236, VH232, and VH202 series LCD monitors, detailing setup, features, specifications, and troubleshooting for optimal viewing experience.

ASUS
VY279 シリーズ
液晶ディスプレイ

ユーザーガイド



HDMI

[ASUS VY279 Series LCD Display User Guide](#)

This user guide provides comprehensive instructions for setting up, operating, and troubleshooting the ASUS VY279 Series LCD Display. It covers assembly, cable connections, OSD menu navigation, image adjustments, and safety precautions.



[ASUS ROG Strix XG259CMS Gaming Monitor User Guide](#)

Comprehensive user guide for the ASUS ROG Strix XG259CMS 24.5-inch Full HD Gaming LCD Monitor. Covers setup, features, OSD menu, specifications, troubleshooting, and safety information.