

## Bluetooth 4326596135

# shift 3 Bluetooth Hands-Free Auto Speaker Black Series User Manual

Model: 4326596135 | Brand: Bluetooth

## INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your shift 3 Bluetooth Hands-Free Auto Speaker Black Series. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.



Image: The shift 3 Bluetooth Hands-Free Auto Speaker, a compact black device with a metallic trim, featuring a speaker grille, control buttons, and a clip for attachment. This image shows the front view of the speaker.

## SETUP

### 1. Charging the Device

The shift 3 speaker is powered by an internal battery. Before first use, fully charge the device using the provided power adapter. Connect the power adapter to the speaker's charging port and plug it into a standard wall outlet. The charging indicator light will typically show the charging status and turn off or change color when fully charged.

## 2. Initial Placement

As a tabletop mount device, place the speaker on a stable, flat surface. For in-car use, utilize its design for convenient placement, ensuring it does not obstruct your view or interfere with driving controls.

## 3. Bluetooth Pairing

1. Ensure the speaker is charged and turned on.
2. Activate Bluetooth on your smartphone, tablet, or other compatible device.
3. Put the shift 3 speaker into pairing mode. This usually involves pressing and holding the Bluetooth button or power button until an indicator light flashes rapidly or a voice prompt confirms "pairing mode."
4. On your device, search for available Bluetooth devices. Select "shift 3" or a similar name from the list.
5. Once connected, the speaker will typically provide an audible confirmation, and the indicator light will change to a steady blue.

*Note: If prompted for a passcode, enter "0000" (four zeros).*

## OPERATING INSTRUCTIONS

---

### Power On/Off

- To turn on: Press and hold the power button until the indicator light illuminates.
- To turn off: Press and hold the power button until the indicator light turns off.

### Hands-Free Calling

- **Answering a Call:** When a call comes in, press the multi-function button (often marked with a phone icon) once to answer.
- **Ending a Call:** During a call, press the multi-function button once to end the call.
- **Rejecting a Call:** Press and hold the multi-function button for approximately 2 seconds to reject an incoming call.
- **Redialing Last Number:** Double-press the multi-function button to redial the last number called.
- **Voice Control:** If supported by your connected device, you may activate voice assistants (e.g., Siri, Google Assistant) by pressing and holding a dedicated voice control button or the multi-function button.

### Audio Playback

- **Play/Pause:** Press the multi-function button once to play or pause audio.
- **Volume Control:** Use the volume up (+) and volume down (-) buttons on the speaker to adjust the audio level.
- **Next/Previous Track:** Some models may have dedicated buttons or require a long press of the volume buttons to skip tracks. Refer to your device's specific button layout.

## MAINTENANCE

---

### Cleaning

Wipe the exterior of the speaker with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents. Avoid getting moisture into any openings.

### Battery Care

- To preserve battery life, avoid fully discharging the battery frequently.

- Store the device in a cool, dry place when not in use for extended periods.
- Recharge the battery at least once every three months if not used regularly.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device using the provided power adapter.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; Bluetooth on source device is off or too far; previously paired device interfering.	Ensure speaker is in pairing mode. Turn Bluetooth off and on again on your source device. Move devices closer. Disconnect from other Bluetooth devices.
Poor audio quality during calls (squealing/whining).	Interference; microphone issues; device malfunction.	Move away from other electronic devices. Ensure speaker is positioned correctly. If problem persists, contact customer support.
No sound from speaker.	Volume too low; device not connected; audio source paused.	Increase volume on both speaker and connected device. Verify Bluetooth connection. Check if audio is playing on the source device.

## SPECIFICATIONS

Feature	Detail
Model Name	shift 3
Item Model Number	4326596135
Brand	Bluetooth
Speaker Type	Surround Sound
Special Feature	Hands-free
Compatible Devices	Projector, Laptop, MP3 Player, Desktop, Television, Tablet, Smartphone
Controller Type	Button
Surround Sound Channel Configuration	3.0
Color	Black
Included Components	Power adapter, User manual
Is Waterproof	FALSE
Warranty Type	Limited
Control Method	Voice


Feature	Detail
Wireless Communication Technology	Bluetooth
Power Source	Battery Powered
Audio Driver Type	Dynamic Driver
Connectivity Protocol	Bluetooth
UPC	694202203835
Manufacturer	Bluetooth
Package Dimensions	10.3 x 8.8 x 2.5 inches
Item Weight	10.4 ounces
ASIN	B002SDA1BA
Date First Available	November 27, 2009
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount

## WARRANTY AND SUPPORT

The shift 3 Bluetooth Hands-Free Auto Speaker comes with a **Limited Warranty**. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support, troubleshooting beyond this manual, or warranty claims, please contact the manufacturer, Bluetooth, through their official support channels. This product includes a user manual as part of its components.

© 2024 Bluetooth. All rights reserved.

## Related Documents

	<p><a href="#">Bluetooth 5.3 Core Specification Feature Enhancements</a></p> <p>This document details the feature enhancements introduced in the Bluetooth Core Specification Version 5.3, including Periodic Advertising Enhancement, Encryption Key Size Control Enhancement, Connection Subrating, and Channel Classification Enhancement.</p>
---	---

