

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sea Gull Lighting](#) /

› [Sea Gull Lighting 52-Inch Quality Max Plus Ceiling Fan with Light Kit \(Model 77065-829\) Instruction Manual](#)

### Sea Gull Lighting 77065-829

# Sea Gull Lighting 52-Inch Quality Max Plus Ceiling Fan with Light Kit

Model: 77065-829

## 1. PRODUCT OVERVIEW

This manual provides instructions for the installation, operation, and maintenance of your Sea Gull Lighting 52-Inch Quality Max Plus Ceiling Fan with Light Kit. This unit combines a functional ceiling fan with an integrated flush mount style light fixture, designed for indoor use.



*Image 1: The Sea Gull Lighting 52-Inch Quality Max Plus Ceiling Fan with Light Kit, featuring five blades and an integrated light fixture.*

## 2. SAFETY INFORMATION

Read all instructions carefully before beginning installation. Failure to follow these instructions may result in electrical shock, fire, or personal injury.

- **Electrical Safety:** Ensure power is disconnected at the circuit breaker or fuse box before installation or servicing. All wiring must be in accordance with national and local electrical codes.
- **Mounting:** The fan must be mounted to a structurally sound ceiling outlet box capable of supporting the fan's weight (approximately 20 pounds).

- **Blade Clearance:** Maintain a minimum clearance of 7 feet from the floor to the fan blades. Ensure blades are clear of any obstructions.
- **Light Bulbs:** Use only the specified bulb type and wattage (3 A19 Medium 60 watt light bulbs or equivalent LED replacements).
- **Damp Locations:** This product is UL listed for damp locations, making it suitable for covered outdoor areas or bathrooms where moisture may be present, but not direct water exposure.

### 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact customer support.

- Fan Motor Assembly
- Fan Blades (5)
- Blade Brackets
- Light Kit Assembly (including satin etched glass diffuser)
- Mounting Bracket
- Downrod and Canopy
- Hardware Pack (screws, washers, wire nuts)
- Pull Chains (for fan speed and light control)



*Image 2: A decorative plate, likely a component of the light kit or canopy, featuring a braided edge design.*

### 4. INSTALLATION

---

Professional installation is recommended. Ensure all power is OFF at the circuit breaker before proceeding.

1. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling outlet box using the provided screws. Ensure the box is rated for fan support.
2. **Wiring:** Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the separate wiring guide (not included in this manual). Ensure all connections are secure

with wire nuts.

3. **Fan Assembly:** Attach the downrod to the fan motor assembly. Carefully lift the fan and hang it on the mounting bracket.
4. **Blade Attachment:** Secure each fan blade to its respective blade bracket, then attach the blade brackets to the fan motor.
5. **Light Kit Installation:** Connect the light kit wiring to the fan motor wiring. Secure the light kit housing to the bottom of the fan motor. Install the satin etched glass diffuser.
6. **Bulb Installation:** Install three A19 Medium 60-watt incandescent bulbs or equivalent LED lamps into the light kit sockets.

## 5. OPERATION

---

Once installed and power is restored, operate the fan and light using the pull chains.

- **Fan Speed Control:** One pull chain controls the fan speed. Pulling it cycles through high, medium, low, and off settings.
- **Light Control:** The other pull chain controls the light. Pulling it turns the light on or off.

## 6. MAINTENANCE

---

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Bulb Replacement:** Disconnect power before replacing bulbs. Allow bulbs to cool completely. Replace with three A19 Medium 60-watt incandescent bulbs or compatible LED lamps.
- **Tighten Screws:** Periodically check and tighten all screws on the fan blades and motor housing to prevent wobbling and noise.

## 7. TROUBLESHOOTING

---

If you experience issues with your ceiling fan, refer to the following common problems and solutions:

- **Fan Does Not Start:** Check that the circuit breaker is on and the wall switch (if applicable) is in the ON position. Ensure all wire connections are secure.
- **Light Does Not Work:** Verify that the light pull chain is in the ON position. Check bulbs for proper installation and ensure they are not burnt out. Confirm wiring connections to the light kit.
- **Fan Wobbles:** Ensure all blade screws are tight. Check that the mounting bracket is securely fastened to the ceiling. Verify that the blades are not bent or damaged.
- **Noisy Operation:** Confirm all screws are tight. Check for any loose parts or obstructions.

## 8. SPECIFICATIONS

---

<b>Brand</b>	Sea Gull Lighting
<b>Model Number</b>	77065-829
<b>Electric Fan Design</b>	Ceiling Fan

<b>Power Source</b>	Corded Electric
<b>Product Dimensions</b>	27.2"D x 14.8"W x 11.2"H
<b>Assembled Diameter</b>	52 Inches
<b>Wattage</b>	65 watts
<b>Voltage</b>	120 Volts
<b>Air Flow Capacity</b>	5996 Cubic Feet Per Minute
<b>Indoor/Outdoor Usage</b>	Indoor (UL listed for damp locations)
<b>Type of Bulb</b>	Fluorescent (compatible with 3 A19 Medium 60-watt incandescent or LED)
<b>Item Weight</b>	20 Pounds
<b>Special Feature</b>	Adjustable Height (via downrod)

## 9. WARRANTY AND SUPPORT

This Sea Gull Lighting product is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For technical support, warranty claims, or replacement parts, please contact Sea Gull Lighting customer service. Refer to your purchase documentation for specific contact information or visit the official Sea Gull Lighting website.