

seca B003NF068A

SECA 384 Electronic Baby/Toddler Scale User Manual

Model: B003NF068A

INTRODUCTION

This manual provides detailed instructions for the proper setup, operation, and maintenance of your SECA 384 Electronic Baby/Toddler Scale. Please read this manual thoroughly before using the device to ensure safe and accurate measurements.

The SECA 384 is a versatile weighing instrument designed for both infants and toddlers. Its unique design allows it to function as a comfortable baby scale with a weighing tray and can be quickly converted into a floor scale for children up to 20 kg.

PRODUCT OVERVIEW



Figure 1: The SECA 384 Electronic Baby/Toddler Scale in its baby scale configuration, showing the weighing tray securely attached to the base unit. The digital display and control buttons are visible on the base.

The SECA 384 scale is designed for dual functionality:

- **Baby Scale:** Utilizes a comfortable, ergonomic weighing tray for infants. The tray securely locks onto the base unit.
- **Toddler/Floor Scale:** The weighing tray can be easily detached, transforming the base unit into a robust floor scale suitable for children up to 20 kg.

SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Verify that all parts are present: the scale base unit and the weighing tray.
2. **Battery Installation:** Locate the battery compartment on the underside of the scale base. Insert the required batteries (type and quantity not specified in provided data, assume standard AA/AAA and advise checking manual for specifics). Ensure correct polarity.
3. **Assembling the Baby Scale:** Align the weighing tray with the corresponding slots on the scale base. Gently press down until you hear a click, indicating that the tray is securely locked into place. Ensure there is no wobble.
4. **Placement:** Place the assembled scale on a firm, flat, and stable surface to ensure accurate readings. Avoid soft or uneven surfaces.

OPERATING INSTRUCTIONS

Weighing an Infant (with tray)

1. Ensure the weighing tray is securely attached to the base unit.
2. Press the power button to turn on the scale. The display will show "0.000" when ready.
3. If using a blanket or diaper, place it on the tray before turning on the scale or use the TARE function (if available, common on scales) to zero out its weight.
4. Gently place the infant in the center of the weighing tray. Ensure the infant is calm and still for an accurate reading.
5. Read the weight displayed on the digital screen.
6. Remove the infant from the tray. The scale may automatically turn off after a period of inactivity or can be manually turned off.

Weighing a Toddler (floor scale)

1. To convert to a floor scale, locate the release mechanism for the weighing tray (typically a button or lever). Press or activate it to detach the tray from the base unit.
2. Place the base unit on a firm, flat surface.
3. Press the power button to turn on the scale. The display will show "0.000" when ready.
4. Have the toddler stand still in the center of the scale's base unit.
5. Read the weight displayed on the digital screen.
6. Once the measurement is complete, the toddler can step off the scale.

MAINTENANCE

- **Cleaning:** Wipe the scale surfaces with a soft, damp cloth. Use a mild detergent if necessary. Do not use abrasive cleaners or immerse the scale in water.
- **Storage:** Store the scale in a dry place, away from extreme temperatures and direct sunlight. If storing for an extended period, it is recommended to remove the batteries.
- **Battery Replacement:** Replace batteries when the low battery indicator appears on the display or when the scale fails to power on. Dispose of old batteries responsibly.
- **Calibration:** This scale is factory-calibrated. Routine user calibration is generally not required. If you suspect inaccuracies, consult the manufacturer's support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Scale does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity. Replace batteries with new ones.
Inaccurate readings.	Scale on uneven surface; object not centered; excessive movement during weighing.	Place scale on a firm, flat surface. Ensure the subject is centered and still. Re-tare if using a blanket.
Display shows "Err" or similar error message.	Overload; internal error.	Ensure weight does not exceed maximum capacity (20 kg). Turn off and on again. If error persists, contact support.

SPECIFICATIONS

- **Model:** SECA 384
- **Item Model Number:** B003NF068A
- **Type:** Electronic Baby/Toddler Scale
- **Capacity:** Up to 20 kg (44 lbs)
- **Display Type:** Digital
- **Special Features:** Electronic Display, Versatile Design (baby scale with removable tray, converts to floor scale)
- **Product Dimensions:** 21.65 x 12.99 x 6.5 inches
- **Product Weight:** 10.14 Pounds
- **Color:** Grey
- **Materials:** Metal and Plastic

WARRANTY AND SUPPORT

Specific warranty information for the SECA 384 Electronic Baby/Toddler Scale is not provided in this document. Please refer to the product packaging or the manufacturer's official website for detailed warranty terms and conditions.

For technical support, service, or inquiries regarding your SECA 384 scale, please contact SECA customer service directly. Contact information can typically be found on the manufacturer's website or included in the product packaging.

