

[manuals.plus](#) /› [Air King](#) /› [Air King 16-Inch Oscillating Residential Pedestal Fan Instruction Manual](#)

Air King 9126

Air King 16-Inch Oscillating Residential Pedestal Fan Instruction Manual

Model: 9126

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and save these important safety instructions before using this fan. Failure to follow these instructions may result in electric shock, fire, or injury.

- Always unplug the fan from the power outlet before cleaning, servicing, or moving it.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- This fan is intended for indoor, residential use only. Do not use outdoors or for commercial purposes.
- Do not insert fingers or any other objects through the fan guards when the fan is operating.
- Ensure the fan is placed on a stable, level surface to prevent it from tipping over.
- Close supervision is necessary when any appliance is used by or near children or individuals with reduced physical, sensory, or mental capabilities.

2. PRODUCT OVERVIEW

The Air King 16-inch Oscillating Residential Pedestal Fan is designed to provide effective air circulation in various indoor settings. It features three speed settings, an oscillating function for wider coverage, and adjustable height and tilt for directional airflow.



Image: The Air King 16-inch Oscillating Residential Pedestal Fan, featuring a round base, an adjustable stand, and a fan head with a protective grille and three blades. The fan is gray in color.

Key Features:

- **16-inch Blade Diameter:** Provides substantial airflow.
- **3 Speed Settings:** Allows for customized airflow intensity.
- **Oscillating Function:** Distributes air across a wider area.
- **Adjustable Height:** Column height can be adjusted from 36 inches to 52 inches.
- **Adjustable Tilt:** Fan head can be tilted 30 degrees up to 15 degrees down.
- **Durable Construction:** Features a powder-coated steel front guard and high-impact resistant plastic rear guard.

3. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Air King Pedestal Fan:

1. **Base Assembly:** Place the fan base on a flat, stable surface. Insert the lower pole section into the base and secure it according to the included hardware (typically a large screw or knob from underneath the base).
2. **Adjustable Pole:** Insert the upper, adjustable pole section into the lower pole. Secure it with the provided locking mechanism or screw to prevent it from sliding down during initial setup.
3. **Fan Head Attachment:** Carefully attach the fan head assembly to the top of the adjustable pole. Ensure it is securely fastened using the designated screw or locking pin.
4. **Guard and Blade Installation:** If the fan guards and blades are not pre-assembled, follow the specific instructions provided in the packaging to attach the rear guard, then the fan blades, and finally the front guard. Ensure all clips or screws are tightened to secure the guards.

Once assembled, ensure all connections are tight and the fan is stable before plugging it in.

4. OPERATING INSTRUCTIONS

To operate your Air King Pedestal Fan, follow these steps:

- **Power Connection:** Plug the fan's power cord (NEMA 5-15P) into a standard 120V, 60Hz electrical outlet.
- **Speed Selection:** Locate the speed control knob or buttons, usually on the fan motor housing. Select your desired speed: 1 (low), 2 (medium), or 3 (high).
- **Oscillation Function:** To activate oscillation, press down the oscillation knob located on top of the motor housing. To stop oscillation, pull the knob up.
- **Height Adjustment:** To adjust the fan's height, loosen the height adjustment collar on the pole, raise or lower the upper pole section to the desired height (between 36 and 52 inches), and then securely tighten the collar.
- **Tilt Adjustment:** To adjust the fan head's angle, loosen the tilt adjustment knob or screw on the side of the fan head assembly. Tilt the head to the desired angle (30 degrees up to 15 degrees down) and then securely tighten the knob or screw.
- **Power Off:** To turn off the fan, set the speed control to the '0' or 'OFF' position. Unplug the fan from the outlet when not in use for extended periods.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your fan.

Cleaning:

- **Always unplug the fan before cleaning.**
- Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- To clean the fan blades and inside the guards, you may need to remove the front guard. Refer to the assembly instructions for guard removal. Carefully wipe the blades and interior surfaces with a damp cloth. Ensure all parts are completely dry before reassembling and operating the fan.
- Do not immerse the fan in water or allow water to drip into the motor housing.

Storage:

When storing the fan, especially for extended periods, cover it to protect it from dust. Store it in a cool, dry place.

6. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

- **Fan does not turn on:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check if the speed control is set to an 'ON' position (1, 2, or 3).
 - Verify the circuit breaker or fuse for the outlet has not tripped.
- **Fan does not oscillate:**
 - Ensure the oscillation knob on top of the motor housing is pressed down.
 - Check for any obstructions preventing the fan head from rotating.
- **Reduced airflow:**
 - Clean the fan blades and guards to remove dust and debris that may be obstructing airflow.
 - Ensure the fan is set to a higher speed setting.

If the problem persists after attempting these solutions, contact customer support.

7. SPECIFICATIONS

Specification	Detail
Brand	Air King
Model Number	9126
Blade Diameter	16 inches
Number of Speeds	3
Voltage	120V
Frequency	60 Hz
Air Flow (CFM)	1580 (High) / 1420 (Medium) / 1220 (Low)
RPM	1450 (High) / 1320 (Medium) / 1050 (Low)

Specification	Detail
Amperage	0.60 (High) / 0.50 (Medium) / 0.45 (Low)
Wattage	77 (High) / 65 (Medium) / 57 (Low)
Height	Adjustable from 36 inches to 52 inches
Width	18 inches
Length	18 inches
Color	Gray
Guard Material	Powder Coated Steel Front with High Impact Resistant Plastic Rear
Blade Material	Polypropylene
NEMA Plug Configuration	5-15P
Cord Length	6 ft.
Standards	ETL and OSHA Compliant Guards
Item Weight	0.93 Pounds (approx. 14.9 ounces)
Material Type	Alloy Steel, Plastic

8. WARRANTY AND CUSTOMER SUPPORT

This Air King product is manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Air King website. Keep your purchase receipt as proof of purchase.

For technical assistance, troubleshooting beyond this manual, or to inquire about replacement parts, please contact Air King customer support. Contact details can typically be found on the product packaging or the manufacturer's official website.