

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Energizer](#) /

› [Energizer MAX 9V Alkaline Batteries Instruction Manual](#)

Energizer 00039800129901

Energizer MAX 9V Batteries Instruction Manual

Model: 00039800129901

INTRODUCTION

The Energizer MAX 9V Alkaline Batteries are designed to provide long-lasting power for your essential devices. Featuring POWERSEAL Technology, these batteries are engineered to hold power for up to 5 years in storage, ensuring readiness when needed. They are suitable for a wide range of household electronics, including smoke detectors, safety devices, hand-held meters, and toys.

SETUP AND INSTALLATION

Follow these general steps to install your Energizer MAX 9V battery into a compatible device. Always refer to your device's specific instruction manual for detailed installation procedures.

- 1. Identify Battery Compartment:** Locate the battery compartment on your device. This is often secured with a latch, screw, or cover.
- 2. Open Compartment:** Carefully open the battery compartment. If a tool is required (e.g., a screwdriver), use the appropriate one.
- 3. Remove Old Battery (if applicable):** If replacing an old battery, gently remove it. Dispose of used batteries responsibly according to local regulations.
- 4. Insert New Battery:** Observe the polarity markings (+ and -) inside the battery compartment and on the Energizer MAX 9V battery. Align the battery correctly and insert it firmly. The battery terminals should snap securely into place.
- 5. Close Compartment:** Close the battery compartment securely. Ensure any latches are fastened or screws are tightened.
- 6. Test Device:** Power on your device to confirm proper battery installation and functionality.



Image: Inserting an Energizer MAX 9V battery into a device. Ensure correct polarity.



Image: Installing an Energizer MAX 9V battery into a stud finder.

OPERATING INSTRUCTIONS

Energizer MAX 9V batteries are designed for single-use applications. Once installed, they provide consistent power until depleted. There are no specific operating instructions for the battery itself beyond proper installation and usage within a compatible device.

- Ensure the battery is correctly inserted with the positive (+) and negative (-) terminals aligned as indicated by your device.
- For optimal performance, use batteries of the same type and age within a device.
- Replace all batteries in a device at the same time to prevent issues caused by uneven discharge.

MAINTENANCE AND STORAGE

Proper maintenance and storage can extend the life and safety of your Energizer MAX 9V batteries.

- **Storage:** Store unused batteries in their original packaging in a cool, dry place at normal room temperature. Avoid extreme temperatures.
- **Shelf Life:** Energizer MAX 9V batteries hold power for up to 5 years in storage.
- **Prevent Short Circuits:** To prevent accidental short circuits, which can lead to heat, fire, or explosion, keep battery terminals covered with tape when storing loose batteries. Do not store batteries with metal objects like paper clips or coins.
- **Disposal:** Dispose of used batteries responsibly. Many communities offer recycling programs for batteries. Check local regulations for proper disposal methods.



Image: Energizer MAX 9V battery, highlighting its inclusion of recycled materials.

TROUBLESHOOTING

If your device is not functioning correctly after installing new Energizer MAX 9V batteries, consider the following:

- **Check Polarity:** Ensure the battery is inserted with the correct positive (+) and negative (-) orientation.

- **Secure Connection:** Verify that the battery is firmly seated in its compartment and making proper contact with the device's terminals.
- **Device Malfunction:** If the battery is correctly installed and the device still does not work, the issue may lie with the device itself. Refer to your device's troubleshooting guide or contact its manufacturer.
- **Battery Expiration:** Check the expiration date on the battery packaging. While Energizer MAX batteries have a long shelf life, expired batteries may not perform optimally.

SAFETY INFORMATION

To ensure safe use and prevent injury or damage, please observe the following precautions:

- **Keep Out of Reach of Children:** Batteries can be a choking hazard.
- **Do Not Recharge:** These are single-use alkaline batteries and are not designed to be recharged. Attempting to recharge them can lead to leakage, fire, or explosion.
- **Do Not Disassemble or Incinerate:** Disassembling or incinerating batteries can cause them to rupture or leak.
- **Avoid Mixing Batteries:** Do not mix old and new batteries, or different types of batteries (e.g., alkaline with carbon-zinc or rechargeable).
- **Proper Disposal:** Follow local guidelines for battery disposal.
- **Leakage:** In case of battery leakage, avoid contact with skin and eyes. If contact occurs, rinse thoroughly with water and seek medical attention.

SPECIFICATIONS

Feature	Detail
Brand	Energizer
Model Number	00039800129901
Battery Cell Type	Alkaline
Voltage	9 Volts
Reusability	Single Use
Battery Capacity	2000 Milliampere Hour (mAh)
Item Weight	22.68 g (per battery)
Product Dimensions	0.68 x 3.69 x 4.25 inches
Shelf Life	Up to 5 years in storage
Recycled Materials	Includes up to 4% recycled materials

WARRANTY AND SUPPORT

For warranty information or customer support regarding Energizer MAX 9V batteries, please visit the official Energizer website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Energizer Official Website: www.energizer.com

