

## Laica PS1033BL

# Laica PS1033 Electronic Personal Scale User Manual

Model: PS1033BL

## INTRODUCTION

This user manual provides essential information for the proper use, setup, and maintenance of your Laica PS1033 Electronic Personal Scale. Please read this manual thoroughly before using the device to ensure safe and effective operation.

**Important Warning: The product packaging may contain different information than what is shown on our site. Please always read the label, warnings, and instructions provided with the product before use or consumption.**

## PRODUCT OVERVIEW

The Laica PS1033 is a digital personal scale designed for accurate weight measurement. It features an LCD display and a durable plastic platform.



Image: Laica PS1033 Electronic Personal Scale. This image shows the top view of the white rectangular scale with rounded corners. An LCD display is visible at the top center, showing "53.1". The "LAICA" logo is printed at the bottom center of the scale.

## SETUP

---

### 1. Unpacking

Carefully remove the scale from its packaging. Inspect the device for any signs of damage. Keep the packaging for future storage or transport.

### 2. Battery Installation

The Laica PS1033 scale uses AAA alkaline batteries. Locate the battery compartment on the underside of the scale. Open the compartment cover and insert the batteries, ensuring correct polarity (+/-). Close the cover securely.

### 3. Placement

Place the scale on a hard, flat, and stable surface. Uneven or soft surfaces (like carpets) can affect measurement accuracy.

## OPERATING INSTRUCTIONS

---

### 1. Initializing the Scale

Before the first use, or if the scale has been moved, it is recommended to initialize it. Gently tap the center of the scale with your foot to turn it on. The display will show "0.0" or "CAL" and then turn off. This indicates the scale is ready for use.

### 2. Taking a Measurement

1. Step onto the scale barefoot and stand still, distributing your weight evenly.
2. The display will show your weight. Wait for the reading to stabilize.
3. Step off the scale. The reading will remain on the display for a few seconds before the scale automatically turns off.

### 3. Unit Conversion (if applicable)

If your scale supports multiple units (e.g., kg, lb, st), there may be a button on the underside of the scale to switch between units. Refer to the markings near the button for available options.

## MAINTENANCE

---

### 1. Cleaning

Clean the scale surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the scale in water. Ensure the scale is dry before storage or next use.

### 2. Storage

Store the scale in a cool, dry place. Avoid extreme temperatures and direct sunlight.

### 3. Battery Replacement

If the display shows "Lo" or becomes dim, it's time to replace the batteries. Follow the battery installation steps in the Setup section.

## TROUBLESHOOTING

---

- **No Display / Scale Not Turning On:** Check battery installation and ensure batteries are not depleted. Replace if necessary.
- **Inaccurate Readings:** Ensure the scale is on a hard, flat surface. Re-initialize the scale by tapping it to turn on and off before stepping on. Ensure you are standing still and centered.
- **"Err" or "O-Ld" on Display:** This usually indicates an overload. The scale's maximum capacity is 180 kg. Step off the scale immediately.
- **"Lo" on Display:** Batteries are low. Replace them.

## SPECIFICATIONS

Feature	Detail
Model	PS1033BL
Brand	Laica
Display Type	LCD
Color	White
Weight Limit	180 Kilograms
Product Dimensions (LxWxH)	31.4 x 31 x 3.3 cm
Product Weight	1.77 kg
Battery Type	AAA Alkaline
Form Factor	Mini

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Laica website. Keep your purchase receipt as proof of purchase.

For further assistance, you may contact Laica customer service. Contact details are typically available on the manufacturer's website or product packaging.