



Manuals.plus /

› Husqvarna /

› Husqvarna 532006266 Thrust Washer: Installation and Maintenance Manual

## Husqvarna 532006266

# Husqvarna 532006266 Thrust Washer: Installation and Maintenance Manual

Model: 532006266

## 1. INTRODUCTION

---

This manual provides essential information for the correct installation, operation, and maintenance of the Husqvarna 532006266 Thrust Washer. This component is a genuine Original Equipment Manufacturer (OEM) replacement part designed for use in various lawn and garden equipment, including models from Husqvarna, Poulan, Poulan Pro, Roper, Sears/Craftsman, and Weed Eater. Adhering to these instructions will help ensure proper function and longevity of the part.

## 2. PRODUCT OVERVIEW

---

The Husqvarna 532006266 Thrust Washer is a critical component in various mechanical assemblies, designed to reduce friction and provide proper spacing between moving parts. It is a flat, circular metal washer with specific dimensions to fit designated applications.



*Figure 1: Husqvarna 532006266 Thrust Washer. A close-up view of the flat, circular metal component.*

### **Key Features:**

- **Dimensions:** Outside Diameter (OD): 1-1/4 inches, Inside Diameter (ID): 3/4 inches.
- **Material:** Brass exterior finish.
- **Compatibility:** Replaces previous part numbers 76671, 6266H, 532124931, and 532124956.
- **Multi-Brand Use:** Compatible with equipment from Husqvarna, Poulan, Poulan Pro, Roper, Sears/Craftsman, and Weed Eater.
- **Type:** Original Equipment Manufacturer (OEM) replacement part.

### **3. SPECIFICATIONS**

---

Specification	Detail
Model Number	532006266
Brand	Husqvarna
Washer Type	Flat
Outside Diameter (OD)	1.25 Inches (1-1/4 inches)
Inside Diameter (ID)	0.75 Inches (3/4 inches)
Exterior Finish	Brass
Item Weight	0.02 Pounds (approx. 0.32 ounces)
Number of Pieces	9 (as per product listing, though a single washer is typically purchased)
UPC	705788543007
Replaces Part Numbers	76671, 6266H, 532124931, 532124956

## 4. INSTALLATION AND SETUP

---

The Husqvarna 532006266 Thrust Washer is a replacement part. Installation typically involves replacing an existing worn or damaged washer within a mechanical assembly. Due to the variety of equipment this part is compatible with, specific installation steps will vary. Always refer to the service manual for your specific equipment model for detailed instructions.

### General Installation Guidelines:

- Safety First:** Before beginning any repair, ensure the equipment is turned off, disconnected from its power source (e.g., spark plug wire removed for gasoline engines, battery disconnected for electric), and all moving parts have come to a complete stop. Wear appropriate personal protective equipment (PPE) such as gloves and eye protection.
- Identify Location:** Locate the worn or damaged thrust washer that needs replacement. This part is commonly found in axle assemblies, steering mechanisms, or other areas where rotational friction needs to be managed.
- Disassembly:** Carefully disassemble the surrounding components to gain access to the thrust washer. Keep track of all removed parts and their order for reassembly.
- Remove Old Washer:** Remove the old thrust washer. Inspect the surrounding surfaces for any damage or wear that might have contributed to the washer's failure.
- Install New Washer:** Place the new Husqvarna 532006266 Thrust Washer in its correct position. Ensure it sits flush and is oriented correctly according to your equipment's service manual.
- Reassembly:** Reassemble all components in reverse order of disassembly. Ensure all fasteners are tightened to the manufacturer's specified torque settings, if applicable.
- Test Functionality:** After reassembly, carefully test the equipment's functionality to ensure the new washer is performing correctly and there are no new issues.

If you are unsure about any step, it is recommended to consult a qualified service technician or refer to the detailed service manual for your specific equipment.

## 5. MAINTENANCE

---

Thrust washers are generally low-maintenance components. However, regular inspection of the areas

where they are installed can help identify potential issues before they lead to significant problems.

### **Maintenance Tips:**

- **Regular Inspection:** During routine equipment maintenance, visually inspect the thrust washer and surrounding components for signs of wear, corrosion, or damage. Look for excessive play or grinding noises.
- **Lubrication:** If the application requires lubrication, ensure that the area around the thrust washer is adequately lubricated according to the equipment manufacturer's recommendations.
- **Cleaning:** Keep the area around the thrust washer free from dirt, debris, and corrosive materials that could accelerate wear.
- **Prompt Replacement:** If a thrust washer shows signs of significant wear, deformation, or damage, replace it promptly to prevent further damage to other components.

## **6. TROUBLESHOOTING**

---

Issues related to a thrust washer typically manifest as increased friction, excessive play, or unusual noises in the mechanical assembly where it is installed.

### **Common Issues and Solutions:**

- **Excessive Play or Looseness:**
  - **Cause:** Worn thrust washer, incorrect washer size, or loose fasteners.
  - **Solution:** Inspect the thrust washer for wear. Replace if worn. Ensure the correct size washer is used. Check and tighten all associated fasteners.
- **Grinding or Rubbing Noises:**
  - **Cause:** Severely worn or damaged thrust washer, lack of lubrication, or improper installation.
  - **Solution:** Disassemble and inspect the washer. Replace if damaged. Ensure proper lubrication is applied if required by the equipment. Verify correct installation.
- **Difficulty in Movement or Increased Resistance:**
  - **Cause:** Thrust washer binding, incorrect washer size, or foreign debris.
  - **Solution:** Inspect for debris or binding. Ensure the washer is installed correctly and is the appropriate size for the application.

If troubleshooting steps do not resolve the issue, or if you are uncomfortable performing repairs, it is advisable to seek assistance from a certified service technician.

## **7. WARRANTY INFORMATION**

---

The Husqvarna 532006266 Thrust Washer comes with a **1-year warranty** covering defects in material or workmanship. This warranty applies from the date of purchase. Please retain your proof of purchase for any warranty claims.

For specific warranty terms and conditions, or to initiate a warranty claim, please contact Husqvarna customer support or an authorized service center.

## **8. SUPPORT AND CONTACT**

---

For further assistance, technical support, or inquiries regarding the Husqvarna 532006266 Thrust Washer, please refer to the official Husqvarna website or contact an authorized Husqvarna dealer or service center.

**Husqvarna Official Website:** [www.husqvarna.com](http://www.husqvarna.com)

When contacting support, please have your equipment model number and the part number (532006266) readily available.