

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Logitech](#) /
- › [Logitech M100 Corded Optical Mouse User Manual](#)

Logitech 910-001602

Logitech M100 Corded Optical Mouse User Manual

Model: 910-001602

PRODUCT OVERVIEW

The Logitech M100 Corded Optical Mouse is engineered for comfortable and reliable computer navigation. Its ambidextrous design ensures suitability for both right-handed and left-handed users. Featuring high-definition optical tracking and a multi-function scroll wheel, this mouse provides precise cursor control and effortless document or web page scrolling.



Image: Top-down view of the Logitech M100 Corded Optical Mouse, showing the scroll wheel and main buttons.

SETUP INSTRUCTIONS

1. **Unpack the Mouse:** Carefully remove the Logitech M100 mouse from its packaging.
2. **Connect to Computer:** Locate an available USB port on your computer. Insert the USB connector of the mouse firmly into the USB port.
3. **Driver Installation (Automatic):** The operating system (Windows, macOS, Linux) will typically detect the mouse automatically and install the necessary drivers. This process usually takes a few seconds.
4. **Verify Functionality:** Once connected, move the mouse to check if the cursor on your screen responds. Click the left and right buttons, and scroll the wheel to ensure all functions are working correctly.



Image: Side view of the Logitech M100 Corded Optical Mouse, highlighting the attached USB cable.

OPERATING YOUR MOUSE

Basic Functions

- **Left Click:** Press the left button to select items, open files, or activate functions.
- **Right Click:** Press the right button to open context menus, providing additional options for selected items.
- **Scroll Wheel:** Roll the scroll wheel up or down to navigate through documents and web pages.
- **Middle Click (Scroll Wheel Button):** Press the scroll wheel down to activate middle-click functions, which can vary by application (e.g., opening links in new tabs).

Ambidextrous Design

The Logitech M100 features an ambidextrous design, making it comfortable for both right-handed and left-handed users. No special configuration is required for left-handed use, as the primary functions remain consistent.

High-Definition Optical Tracking

The mouse utilizes high-definition optical tracking for smooth and precise cursor control on various surfaces. For optimal performance, use the mouse on a clean, non-reflective surface or a mouse pad.

MAINTENANCE AND CARE

- **Cleaning the Mouse:** To clean the mouse, gently wipe its surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Cleaning the Optical Sensor:** Occasionally, dust or debris may accumulate around the optical sensor on the underside of the mouse. Use a soft, dry cloth or a cotton swab to carefully clean the sensor area. Do not use liquids directly on the sensor.

- **Cable Care:** Avoid sharp bends or excessive pulling on the USB cable to prevent damage.

TROUBLESHOOTING

Mouse Not Responding

- **Check USB Connection:** Ensure the USB connector is securely plugged into a working USB port on your computer. Try plugging it into a different USB port.
- **Restart Computer:** Sometimes, a simple computer restart can resolve connectivity issues.
- **Test on Another Computer:** If possible, test the mouse on another computer to determine if the issue is with the mouse or your computer's USB ports/drivers.

Cursor Movement is Erratic or Jumpy

- **Clean Optical Sensor:** Dust or debris on the optical sensor can cause erratic movement. Refer to the "Maintenance and Care" section for cleaning instructions.
- **Change Surface:** The mouse may not track well on certain highly reflective, transparent, or uneven surfaces. Try using a mouse pad or a different surface.

Scroll Wheel Not Working

- **Restart Application/Computer:** Close and reopen the application you are using, or restart your computer.
- **Check Software Settings:** Ensure that mouse scrolling is enabled in your operating system's mouse settings.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	910-001602
Connectivity	Wired USB
Movement Detection Technology	Optical
Special Feature	Ambidextrous, Ergonomic Design
Color	Black
Product Dimensions	0.03 x 0.05 x 0.07 inches
Item Weight	3.17 ounces
Manufacturer	LOGITECH, INC.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Logitech website or the documentation included with your purchase. You can typically find support resources, FAQs, and contact information by visiting www.logitech.com/support.

