

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [rabalux](#) /
- › [RABALUX 8270 Oslo Wall Lamp Instruction Manual, Stainless Steel](#)

**rabalux 8270**

# RABALUX 8270 Oslo Wall Lamp Instruction Manual

Model: 8270 | Brand: RABALUX

## 1. INTRODUCTION

---

This instruction manual provides detailed guidance for the safe installation, operation, and maintenance of your RABALUX 8270 Oslo Wall Lamp. Please read this manual thoroughly before installation and retain it for future reference. The RABALUX 8270 Oslo Wall Lamp combines an attractive design with robust materials, featuring a stainless steel construction that is weather-resistant with an IP44 protection rating and UV-resistant plastic components. Its design allows for easy assembly and integration into various outdoor settings.



Image 1.1: RABALUX 8270 Oslo Wall Lamp, front view. This image displays the complete wall lamp assembly, featuring a brushed stainless steel finish, a curved arm, and a spherical glass diffuser beneath a wide, flat shade.

## 2. SAFETY INSTRUCTIONS

---

**WARNING:** Electrical installation should only be performed by a qualified electrician. Always disconnect the main power supply before attempting any installation, maintenance, or repair work.

- Ensure the power supply is switched off at the fuse box or circuit breaker before beginning installation.
- This product is designed for outdoor use only and has an IP44 rating, protecting against solid objects larger than 1mm and splashes of water from any direction.
- Do not exceed the maximum wattage specified for the bulb (60W E27).
- Ensure all electrical connections are secure and comply with local wiring regulations.
- The lamp must be properly grounded.
- Keep packaging materials away from children.

## 3. PACKAGE CONTENTS

---

Verify that all components are present and undamaged before proceeding with installation.

- 1 x RABALUX 8270 Oslo Wall Lamp
- 1 x Mounting Hardware Kit (screws, wall plugs)
- 1 x Instruction Manual (this document)

**Note:** The E27 bulb is not included and must be purchased separately.

## 4. SETUP AND INSTALLATION

---

Follow these steps carefully for proper installation. Refer to the diagrams for visual guidance.




Image 4.1: Dimensions of the RABALUX 8270 Oslo Wall Lamp. The diagram shows the lamp with a width of 280mm and a height of 265mm. The shade has a diameter of 240mm.




Image 4.2: Step-by-step installation guide for the RABALUX 8270 Oslo Wall Lamp. This image illustrates the process from mounting the base to securing the lamp and inserting the bulb.

1. **Preparation (Image 4.2, Step 1):** Disconnect the main power supply. Mark the desired mounting position on the wall. Drill holes for the mounting bracket and insert wall plugs if necessary.
2. **Mounting the Base Plate (Image 4.2, Step 2):** Secure the lamp's base plate to the wall using the provided screws. Connect the electrical wires (Live (L), Neutral (N), and Earth (E)) to the corresponding terminals on the base plate. Ensure connections are tight and secure.
3. **Attaching the Lamp Body (Image 4.2, Step 3):** Carefully attach the main lamp body to the mounted

base plate, ensuring the wires are not pinched. Secure it with the retaining screws.

4. **Inserting the Bulb (Image 4.2, Step 4):** Unscrew the glass diffuser. Insert an E27 bulb (max 60W) into the lamp holder. Do not overtighten.
5. **Securing the Diffuser (Image 4.2, Step 5):** Reattach the glass diffuser and the outer shade, ensuring they are securely fastened to protect the bulb and maintain the IP44 rating.
6. **Final Check:** Once installation is complete, restore power and test the lamp's functionality.

## 5. OPERATING INSTRUCTIONS

---

The RABALUX 8270 Oslo Wall Lamp operates via a standard wall switch connected to its power supply. Once installed and powered, simply use the connected switch to turn the light on or off.

- This lamp is compatible with E27 bulbs, including incandescent, LED, or energy-saving bulbs, up to a maximum of 60 watts.
- For optimal energy efficiency, consider using an LED E27 bulb.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your wall lamp.

- **Cleaning:** Disconnect power before cleaning. Clean the lamp with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or plastic components.
- **Bulb Replacement:** Always disconnect power and allow the old bulb to cool completely before attempting to replace it. Unscrew the glass diffuser, replace the E27 bulb, and then securely reattach the diffuser.
- **Inspection:** Periodically inspect the lamp for any signs of damage, such as cracked housing, frayed wires, or loose connections. If any damage is found, disconnect power immediately and have it repaired by a qualified professional.

## 7. TROUBLESHOOTING

---

If you encounter issues with your RABALUX 8270 Oslo Wall Lamp, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Lamp does not turn on	No power supply Faulty bulb Loose wiring connection	Check circuit breaker/fuse. Replace bulb with a new, working one. Disconnect power and check wiring connections (consult an electrician if unsure).
Lamp flickers	Loose bulb Incompatible bulb Faulty wiring	Tighten the bulb. Ensure bulb is compatible with the lamp. Disconnect power and check wiring connections (consult an electrician if unsure).
Water inside diffuser	Improperly sealed diffuser	Disconnect power. Remove diffuser, dry thoroughly, and reattach ensuring a tight seal. Check for any cracks in the diffuser.

If the problem persists after attempting these solutions, please contact customer support or a qualified electrician.

## 8. SPECIFICATIONS

---

- **Model Number:** 8270
- **Brand:** RABALUX
- **Product Dimensions:** 28L x 24W x 28H cm (280 x 240 x 280 mm); 950 g
- **Material:** Metal, Plastic (Stainless Steel finish)
- **Color:** Stainless Steel
- **Bulb Type:** E27
- **Max Wattage:** 60W
- **Protection Class:** IP44 (Weather-resistant)
- **Specific Use:** Outdoor only
- **Finish:** Brushed
- **Certifications:** CE
- **Mounting Required:** Yes
- **Batteries Required:** No




Image 8.1: Energy Efficiency Label for RABALUX 8270. This label indicates that the luminaire is compatible with bulbs of energy classes A++ to E.

## 9. WARRANTY INFORMATION

---

This RABALUX product comes with a standard manufacturer's warranty. Please refer to your purchase documentation, receipt, or the official RABALUX website for specific terms, conditions, and duration of the warranty applicable to your region.

## 10. SUPPORT

---

For technical assistance, spare parts, or any further inquiries regarding your RABALUX 8270 Oslo Wall Lamp, please contact your retailer or visit the official RABALUX website for customer support contact details.

**Website:** [www.rabalux.com](http://www.rabalux.com) (Please check for your regional website)