

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RASTAR](#) /

› [Instruction Manual for RASTAR 1/14 Scale Lamborghini Aventador LP700 Radio Remote Control Model Car](#)

**RASTAR 6930751304420**

# Instruction Manual for RASTAR 1/14 Scale Lamborghini Aventador LP700 Radio Remote Control Model Car

Model: 6930751304420

## PRODUCT OVERVIEW

The RASTAR 1/14 Scale Lamborghini Aventador LP700 is a highly detailed, full-function radio-controlled model car designed for enthusiasts and collectors. This model accurately replicates the iconic Lamborghini Aventador LP700, featuring a glossy exterior paint finish, detailed interior, and working headlights and rear lights. It is equipped with an independent spring suspension system and adjustable front wheel alignment for optimal control and performance.



Image: The RASTAR 1/14 Scale Lamborghini Aventador LP700 RC car in orange, showcasing its sleek design and detailed features.

## SETUP AND BATTERY INSTALLATION

Before operating your RASTAR Lamborghini Aventador LP700, ensure all necessary batteries are correctly installed in both the vehicle and the remote controller.

### Required Batteries:

- **Vehicle:** 5 x AA batteries (not included)
- **Controller:** 1 x 9V battery (not included)

## Installation Steps:

### 1. Vehicle Battery Installation:

Locate the battery compartment on the underside of the car. Open the battery cover using a small screwdriver if necessary. Insert 5 AA batteries, ensuring correct polarity (+/-). Close the battery cover securely.

### 2. Controller Battery Installation:

Locate the battery compartment on the back of the remote controller. Open the battery cover. Insert one 9V battery, observing the correct polarity. Close the battery cover securely.



Image: An illustration detailing the battery requirements for the car (5 AA) and controller (9V), along with basic control functions.

## OPERATING INSTRUCTIONS

This radio-controlled car offers full-function control for an engaging driving experience. Familiarize yourself with the controller's layout and functions before operation.

### Controller Functions:

- **Forward:** Push the trigger/joystick forward.
- **Reverse:** Pull the trigger/joystick backward.
- **Stop:** Release the trigger/joystick to the neutral position.
- **Left:** Turn the steering wheel/knob left.
- **Right:** Turn the steering wheel/knob right.

### Driving Tips:

- Operate the car on smooth, flat surfaces for best performance.
- Maintain a clear line of sight between the controller and the car.

- Avoid operating near other radio-controlled devices to prevent interference.
- The car features working headlights and rear lights that illuminate during operation.



Image: The RASTAR Lamborghini Aventador RC car positioned next to its trigger-gun type remote controller, illustrating the complete set.

## MAINTENANCE AND CARE

Proper maintenance will extend the life and performance of your RC car.

- **Cleaning:** Use a soft, dry cloth to wipe down the car's exterior. Avoid using water or chemical cleaners, as they may damage the electronics or paint finish.
- **Storage:** When not in use, store the car and controller in a cool, dry place away from direct sunlight and moisture.
- **Battery Care:** Always remove batteries from both the car and the controller when not in use for extended periods to prevent leakage and damage. Dispose of used batteries responsibly.
- **Inspection:** Periodically check for loose parts, damaged wires, or debris in the wheels.

## TROUBLESHOOTING GUIDE

If you encounter issues with your RC car, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Car does not move or respond.	<ul style="list-style-type: none"> <li>Batteries are low or incorrectly installed.</li> <li>Car or controller is turned off.</li> <li>Out of range.</li> </ul>	<ul style="list-style-type: none"> <li>Replace batteries in both car and controller, ensuring correct polarity.</li> <li>Ensure both car and controller power switches are ON.</li> <li>Move closer to the car (within 30 feet).</li> </ul>

Problem	Possible Cause	Solution
Poor control or erratic movement.	<ul style="list-style-type: none"> <li>• Battery power is low.</li> <li>• Radio interference.</li> </ul>	<ul style="list-style-type: none"> <li>• Replace batteries.</li> <li>• Move to a different location away from other electronic devices or RC toys.</li> </ul>
Steering is not straight.	<ul style="list-style-type: none"> <li>• Front wheel alignment needs adjustment.</li> </ul>	<ul style="list-style-type: none"> <li>• Adjust the steering trim knob/lever on the underside of the car or on the controller (if available) until the car drives straight.</li> </ul>

## PRODUCT SPECIFICATIONS

- **Model:** Lamborghini Aventador LP700
- **Scale:** 1:14
- **Dimensions (L x W x H):** Approximately 11.81 x 4.72 x 4.72 inches (30 x 12 x 12 cm)
- **Weight:** Approximately 1.54 pounds (0.7 kg)
- **Speed:** 8-15 mph (12-24 km/h)
- **Remote Distance:** Up to 30 feet (9 meters)
- **Control Type:** Full Function Radio Controlled (Forward, Reverse, Stop, Left, Right)
- **Features:** Adjustable Front Wheel Alignment, Independent Spring Suspension System, Detailed Interior/Exterior, Rims & Tires, Glossy Exterior Paint, Working Headlights, Working Rear lights.
- **Power Source (Car):** 5 x AA Batteries (not included)
- **Power Source (Controller):** 1 x 9V Battery (not included)
- **Recommended Age:** 6 years and up




Image: Technical drawing showing the approximate dimensions of the 1/14 scale Lamborghini Aventador RC car from top and side views.

## WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your product packaging or visit the official RASTAR website. For technical support or inquiries, please contact RASTAR customer service through their official channels.

You can often find additional support and contact information on the [RASTAR Store Page on Amazon](#).

---

© 2023 RASTAR. All rights reserved.

Lamborghini and Aventador are trademarks of Automobili Lamborghini S.p.A.