

Taurus 947245000

Taurus Alpatec Babel RC Tower Fan User Manual

Model: 947245000

1. INTRODUCTION

Thank you for purchasing the Taurus Alpatec Babel RC Tower Fan. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before use and retain it for future reference.

The Taurus Alpatec Babel RC is a 45W tower fan designed for efficient air circulation, featuring 3 speed settings, 3 operating modes (Normal, Breeze, Night), a 7.5-hour timer, oscillation function, and convenient remote control. Its compact design and integrated handle make it easy to move and store.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the fan.
- Ensure the voltage indicated on the rating label corresponds to your mains voltage.
- Do not immerse the fan, plug, or cord in water or other liquids.
- Unplug from the outlet when not in use, before cleaning, or before moving.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the fan out of reach of children and pets.
- Do not insert fingers or foreign objects into any openings of the fan.
- Do not use outdoors.
- Place the fan on a stable, flat surface.
- Ensure the fan grilles are not blocked.

3. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your Taurus Alpatec Babel RC Tower Fan:

- Control Panel with LED display
- Air Outlet Grille
- Base
- Power Cord
- Remote Control (with dedicated storage slot)
- Integrated Carry Handle






Figure 3.1: Front view of the Taurus Alpatec Babel RC Tower Fan, showing its sleek design and control panel.



Figure 3.2: Side view of the tower fan, highlighting its slim profile and stable base.

4. SETUP AND ASSEMBLY

The Taurus Alpattec Babel RC Tower Fan comes largely pre-assembled. Follow these steps for initial setup:

1. **Unpacking:** Carefully remove the fan from its packaging. Retain the packaging for future storage or transport.
2. **Base Assembly (if required):** Some models may require attaching the base. Align the base with the bottom of the fan body and secure it using the provided screws. Ensure it is firmly attached for stability.
3. **Placement:** Place the fan on a firm, level surface, away from curtains or other objects that could obstruct airflow. Ensure there is adequate space around the fan for optimal performance and oscillation.
4. **Power Connection:** Plug the power cord into a standard electrical outlet (240V).



Figure 4.1: Rear view of the fan, showing the integrated carry handle for easy portability.

5. OPERATING INSTRUCTIONS

Your Taurus Alpattec Babel RC Tower Fan can be operated using the control panel on top of the unit or the included remote control.

5.1 Control Panel and Remote Control



Figure 5.1: Close-up of the fan's control panel, showing buttons for power, speed, mode, timer, and oscillation.



Figure 5.2: A hand holding the remote control, which can be stored in a dedicated slot on the fan's top panel.

The remote control offers the same functionalities as the control panel for convenient operation from a distance. Ensure the remote control is pointed towards the fan's control panel for effective communication.

5.2 Functions


- **Power On/Off:** Press the **Power** button () to turn the fan on or off.
- **Speed Settings:** Press the **Speed** button to cycle through 3 speed settings: Low, Medium, High. The current speed will be indicated on the LED display.
- **Operating Modes:** Press the **Mode** button to select from 3 modes:
 - **Normal:** Constant airflow at the selected speed.
 - **Breeze:** Simulates natural wind with varying fan speeds.
 - **Night (Sleep):** Operates at a lower, quieter speed for undisturbed sleep.
- **Oscillation:** Press the **Oscillation** button to activate or deactivate the automatic oscillation function, which distributes air across a wider area.



Figure 5.3: The fan in oscillation mode, showing the wide air distribution.

- **Timer:** Press the **Timer** button to set the fan to automatically turn off after a specified period. The timer can be set up to 7.5 hours. Each press typically adds 0.5 hours or 1 hour, depending on the model's increment.



Figure 5.4: The fan operating in Night mode, designed for quiet performance during sleep.



Figure 5.5: Illustration of the different airflow modes: Normal, Breeze, and Night.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will help prolong the life of your fan and ensure optimal performance.

- **Before Cleaning:** Always unplug the fan from the power outlet before cleaning.
- **Exterior Cleaning:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the surface.
- **Grille Cleaning:** Use a vacuum cleaner with a brush attachment to remove dust from the air inlet and outlet grilles. This helps maintain efficient airflow.
- **Storage:** When not in use for extended periods, store the fan in its original packaging in a cool, dry place.

7. TROUBLESHOOTING

If you experience issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Power button not pressed.	Ensure the fan is plugged into a working outlet. Press the Power button on the control panel or remote.
Weak airflow.	Grilles are blocked by dust. Fan is on a low speed setting.	Clean the air inlet and outlet grilles. Increase the fan speed.
Oscillation not working.	Oscillation function is off.	Press the Oscillation button to activate.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and fan.	Replace batteries and ensure correct polarity. Ensure a clear line of sight to the fan's control panel.

If the problem persists after trying these solutions, please contact Taurus customer support.

8. PRODUCT SPECIFICATIONS

Feature	Specification
Model Number	947245000 (Babel RC)
Brand	Taurus
Power	45 Watts
Voltage	240V
Number of Speeds	3
Operating Modes	Normal, Breeze, Night
Timer	Up to 7.5 Hours
Oscillation	Yes
Dimensions (L x W x H)	26 x 26 x 75.5 cm (10.2 x 10.2 x 29.7 inches)
Net Weight	2.6 kg (5.7 lbs)
Material	Plastic
Color	Grey

LIGHT
3 Kg



Figure 8.1: Diagram showing the dimensions of the Taurus Alpatec Babel RC Tower Fan.

9. WARRANTY AND SUPPORT

Taurus products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Taurus website. Keep your proof of purchase for warranty claims.

For technical support, spare parts, or service inquiries, please contact Taurus customer service through their official channels. You can find contact information on the Taurus website or on your product packaging.

Online Resources: For additional information and product registration, visit the official Taurus website: www.taurus-home.com

10. ENVIRONMENTALLY FRIENDLY DISPOSAL





This symbol on the product or its packaging indicates that this product shall not be treated as household waste. Instead, it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring

this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



© 2024 Taurus. All rights reserved.

Related Documents - 947245000

	<p>Manual de Usuario y Consejos de Seguridad del Ventilador de Techo FRESKO INVISIBLE Taurus Alpatec</p> <p>Descubra el manual de usuario y las instrucciones de seguridad para el ventilador de techo Taurus Alpatec FRESKO INVISIBLE. Información detallada sobre instalación, funcionamiento, mantenimiento y especificaciones técnicas para un uso seguro y eficiente.</p>
	<p>Taurus Homeland Unique: Manual de Instrucciones y Seguridad</p> <p>Descubra el manual de instrucciones y seguridad para el aspirador Taurus Homeland Unique (HVCA7229B). Información detallada sobre uso, mantenimiento y precauciones para un hogar seguro y eficiente.</p>
	<p>Taurus High Landscapes Air Purifier - Manual de Usuario y Guía Completa</p> <p>Manual de usuario detallado para el purificador de aire Taurus High Landscapes. Cubre descripción del producto, instalación, uso, mantenimiento, seguridad y especificaciones técnicas en múltiples idiomas.</p>
	<p>Taurus Homeland Unique Waterpro HVC7295B: User Manual, Instructions & Troubleshooting</p> <p>Comprehensive user manual for the Taurus Homeland Unique Waterpro HVC7295B wet and dry floor cleaner. Includes setup, operation, cleaning, maintenance, troubleshooting, and warranty information.</p>

