

[manuals.plus](#) /› [Einhell](#) /› **Einhell Ash Vacuum Canister 12 Liters - Model 2351606 Instruction Manual**

## Einhell 2351606

# Einhell Ash Vacuum Canister 12 Liters

Model: 2351606

## 1. PRODUCT OVERVIEW

The Einhell Ash Vacuum Canister (Model 2351606) is a specialized accessory designed for the safe and efficient collection of cold ash. It connects to a standard wet and dry vacuum cleaner, acting as a pre-filter to protect the main vacuum from fine ash particles. This 12-liter canister is ideal for cleaning fireplaces, wood stoves, and barbecue pits.





Figure 1: Ein Hell Ash Vacuum Canister with hose and nozzle.

## 2. SAFETY INSTRUCTIONS

- **Always ensure ash is completely cold before vacuuming.** Hot ash can cause fires or damage the equipment.
- Do not vacuum any flammable liquids or materials.
- Ensure all connections are secure before operation to prevent ash leakage.
- Do not use cleaning products or solvents on the canister or its components, as they may damage plastic parts.
- Regularly empty and clean the canister and filter to maintain optimal performance and prevent fire hazards.
- Keep the appliance out of reach of children.

## 3. PACKAGE CONTENTS

Verify that all items are present upon unpacking:

- 1x Ein Hell Ash Vacuum Canister (12 Liters)
- 1x Reinforced Metal Suction Hose (approx. 1.2 meters)
- 1x Aluminum Suction Tube/Nozzle
- 1x Disc Filter (pre-installed or separate)
- Quick fasteners (for lid)







Figure 2: Components of the Einhell Ash Vacuum Canister.

## 4. SETUP

---

1. **Unpack:** Carefully remove all components from the packaging.
2. **Assemble Hose and Nozzle:** Attach the aluminum suction tube to the reinforced metal suction hose. Ensure it is securely fitted.
3. **Connect Hose to Canister:** Insert the reinforced metal suction hose into the designated inlet on the lid of the ash canister.
4. **Connect Canister to Vacuum Cleaner:** Connect the outlet on the ash canister's lid to the suction inlet of your wet and dry vacuum cleaner using an appropriate connector (not always included, may require your vacuum's hose). Ensure a tight seal to prevent loss of suction.
5. **Secure Lid:** Ensure the lid of the ash canister is securely fastened with the quick fasteners.



Figure 3: Connecting the hose to the ash canister.

## 5. OPERATING INSTRUCTIONS

- 1. Preparation:** Ensure the ash in your fireplace, stove, or barbecue pit is completely cold. Hot ash can cause severe damage and fire.
- 2. Power On:** Turn on your connected wet and dry vacuum cleaner.
- 3. Vacuuming Ash:** Use the aluminum suction tube to vacuum the cold ash. Move the nozzle slowly over the ash to ensure thorough collection.
- 4. Monitor Canister:** Periodically check the ash level in the canister. Do not overfill.
- 5. Completion:** Once cleaning is complete, turn off the vacuum cleaner.



Figure 4: Vacuuming ash from a fireplace.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and efficiency of your ash vacuum canister.

- **Emptying the Canister:** Completely empty the ash container every time you finish using it. Dispose of ash safely.
- **Cleaning the Canister:** If necessary, clean the interior of the canister with water. Ensure it is thoroughly dried before next use. Do not use cleaning products or solvents.
- **Filter Cleaning:** The disc filter should be regularly cleaned. Tap it gently to dislodge ash, or rinse with water if heavily soiled. Ensure the filter is completely dry before re-installing. A clogged filter will reduce suction power.
- **Storage:** Store the ash canister in a dry, clean place away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Reduced suction power	Clogged filter; Full canister; Loose connections.	Clean or replace the disc filter; Empty the canister; Check all hose and lid connections for tightness.
Ash escaping from canister	Lid not properly sealed; Damaged hose/canister.	Ensure lid quick fasteners are securely closed; Inspect hose and canister for cracks or damage.

Problem	Possible Cause	Solution
Canister not picking up ash effectively	Ash is not completely cold; Blockage in hose/nozzle.	Wait until ash is completely cold; Check hose and nozzle for obstructions.

## 8. SPECIFICATIONS

---

**Model:** 2351606

**Brand:** Einhell

**Capacity:** 12 Liters

**Dimensions (L x W x H):** 14 x 18 x 21 cm

**Weight:** 2 Kilograms

**Hose Length:** 1.2 Meters

**Filter Type:** Disc Filter

**Recommended Use:** Cold ash from fireplaces, stoves, barbecue pits

**Included Components:** Ash Canister, Reinforced Metal Suction Hose, Aluminum Suction Tube

**Color:** Grey

**Country of Origin:** China

## 9. WARRANTY AND SUPPORT

---

Einhell products are manufactured with quality and reliability in mind. For warranty information, please refer to the documentation provided with your purchase or visit the official Einhell website. For technical support or spare parts, please contact Einhell customer service directly.

**Contact Information:** Please refer to your regional Einhell website or product packaging for the most up-to-date contact details.