## Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Generac /
- Generac CAM LOCK Model 067042C Instruction Manual

#### Generac 067042C

# Generac CAM LOCK - Model 067042C Instruction Manual

BRAND: GENERAC

This manual provides essential information for the proper installation, operation, and maintenance of your Generac CAM LOCK, Model 067042C.

#### 1. Introduction

The Generac CAM LOCK, Model 067042C, is a component designed for securing specific Generac outdoor power equipment. This lock helps to ensure the proper closure and security of access panels or covers, contributing to the safe and reliable operation of your equipment. Please read this manual thoroughly before installation and use to ensure correct application and to prevent damage or injury.

### 2. SAFETY INFORMATION

Always observe the following safety precautions when handling or installing the CAM LOCK:

- Ensure the equipment is powered off and disconnected from any power source before attempting installation or maintenance.
- Wear appropriate personal protective equipment (PPE), such as gloves and eye protection, during installation.
- · Keep small parts away from children.
- If you are unsure about any installation step, consult a qualified technician or Generac customer support.

# 3. PRODUCT OVERVIEW

The Generac CAM LOCK 067042C is a black-colored key lock designed for outdoor equipment. It consists of a bracket and a securing screw.



Figure 3.1: Front view of the Generac CAM LOCK 067042C. This image shows the main body of the cam lock, which is a bracket with a securing screw at the top, designed to hold panels in place.



Figure 3.2: Side view of the Generac CAM LOCK 067042C. This image illustrates the profile of the cam lock, highlighting its L-shaped bracket and the screw mechanism for attachment.

# 4. SETUP AND INSTALLATION

Follow these steps to properly install your Generac CAM LOCK 067042C:

- 1. **Identify Mounting Location:** Locate the designated mounting point on your Generac equipment where the cam lock is to be installed. This is typically on an access panel or cover.
- 2. **Position the Lock:** Align the cam lock bracket with the pre-drilled holes or mounting slots on the equipment.
- 3. **Secure with Fasteners:** Insert the provided screw (or appropriate fastener if not included with the lock) through the cam lock and into the equipment's mounting point.
- 4. **Tighten Securely:** Using a suitable tool, tighten the screw until the cam lock is firmly attached and does not wobble. Do not overtighten, as this may strip the threads or damage the equipment.
- 5. **Test Functionality:** After installation, test the cam lock by attempting to secure and unsecure the panel or cover it is intended to hold. Ensure it operates smoothly and provides a secure closure.

#### 5. OPERATING INSTRUCTIONS

To operate the Generac CAM LOCK 067042C:

- **To Lock:** Ensure the panel or cover is properly closed. Rotate the cam lock mechanism until it engages with the corresponding latch point on the equipment, securing the panel.
- **To Unlock:** Rotate the cam lock mechanism in the opposite direction until it disengages from the latch point, allowing the panel or cover to be opened.

This cam lock is designed for manual operation, functioning as a latch. While the specifications indicate 'Key Lock', the visual representation suggests a simple cam mechanism. If your specific equipment configuration includes a key-operated variant, refer to your equipment's primary manual for key usage instructions.

### 6. MAINTENANCE

Regular maintenance ensures the longevity and proper function of your CAM LOCK:

- Cleaning: Periodically wipe the lock with a clean, damp cloth to remove dirt and debris. Avoid harsh chemicals that may damage the finish.
- **Inspection:** Regularly inspect the cam lock for any signs of wear, damage, or corrosion. Check that the screw remains tight.
- Lubrication (if applicable): If the mechanism feels stiff, a small amount of silicone-based lubricant can be applied to moving parts, if any, to ensure smooth operation. Avoid oil-based lubricants that can attract dirt.
- **Replacement:** If the cam lock shows significant wear or damage, replace it immediately with a genuine Generac replacement part to maintain equipment integrity and safety.

#### 7. TROUBLESHOOTING

Common issues and their solutions:

Issue: Cam lock is difficult to rotate or engage.

• **Solution:** Check for any obstructions or debris preventing smooth movement. Clean the area around the lock. If the mechanism is stiff, apply a small amount of silicone lubricant.

• **Solution:** Ensure the panel or cover is correctly aligned before attempting to engage the lock. Misalignment can cause resistance.

Issue: Cam lock feels loose after installation.

- **Solution:** Re-tighten the securing screw. If the screw continues to loosen, consider using a thread-locking compound (e.g., blue Loctite) or replacing the screw if it is stripped.
- Solution: Inspect the mounting surface for damage or wear that might prevent a secure fit.

# 8. SPECIFICATIONS

Model Number	067042C
Brand	Generac
Color	Black
Material	Plastic
Lock Type	Key Lock
Recommended Use	Outdoor Equipment (e.g., Power Generators)
Package Dimensions	7 x 5 x 1 inches
Item Weight	0.01 ounces

Note: Specifications are subject to change without notice.

# 9. WARRANTY INFORMATION

Generac products are manufactured to high-quality standards. For specific warranty details pertaining to the Generac CAM LOCK 067042C, please refer to the warranty documentation included with your original Generac equipment or visit the official Generac website. Keep your purchase receipt as proof of purchase for any warranty claims.

## 10. Customer Support

For technical assistance, replacement parts, or further information regarding your Generac CAM LOCK 067042C, please contact Generac customer support or visit their official website:

Generac Official Website: www.generac.com

Amazon Brand Store: Generac Store on Amazon

When contacting support, please have your product model number (067042C) and any relevant purchase information ready.



## Generac XG10000E Portable Generator Owner's Manual

Comprehensive owner's manual for the Generac XG Professional Series XG10000E portable generator, covering safe operation, maintenance, troubleshooting, and warranty information.



#### Generac Standby Generator Owner's Manual - QT 5.4L 80kW Models

Comprehensive owner's manual for Generac QT 5.4L and 80kW standby generator sets. Covers safety, operation, maintenance, troubleshooting, and specifications for reliable power backup.



#### Generac Protector Series Standby Generators: Specifications, Features, and Installation Guide

Explore the Generac Protector Series of liquid-cooled gaseous standby generators (25-60 kW). This document details model specifications, key features like True Power™ technology, advanced controllers, fuel consumption, and installation layout information.



#### Generac iX 2000 Digital Inverter Generator Operator's Manual

Comprehensive operator's manual for the Generac iX 2000 Digital Inverter Generator, covering safety, operation, maintenance, troubleshooting, and warranty information for reliable power generation.



# Generac 100 Amp Automatic Transfer Switch/Load Center Installation Guide with Express Install Kit

Comprehensive installation guide for Generac 100 Amp Automatic Transfer Switch/Load Center models, including the Express Install Kit. Learn how to safely install and connect your standby generator system, covering site preparation, wiring, and final connections.



# Generac GP Series Portable Generator Owner's Manual

This manual provides essential information for the safe operation, maintenance, and troubleshooting of the Generac GP Series Portable Generator. It covers safety rules, generator components, operation procedures, maintenance schedules, and troubleshooting tips.