

[Manuals.plus](#) /

› [Sunlite](#) /

› Sunlite 04130-SU 15-Foot Household Extension Cord Instruction Manual

Sunlite 04130-SU

Sunlite 04130-SU 15-Foot Household Extension Cord Instruction Manual

Model: 04130-SU | **Brand:** Sunlite

INTRODUCTION

Thank you for choosing the Sunlite 04130-SU 15-Foot Household Extension Cord. This product is designed to provide extended reach for your indoor electrical needs, featuring three 2-prong polarized outlets and built-in tamper guards for enhanced safety. It is suitable for a variety of small appliances, electronics, and lighting fixtures.

This extension cord is UL Listed, ensuring it meets rigorous safety and quality standards. Please read this manual thoroughly before use to ensure safe and proper operation.

sunlite®



13-Amps
(1,625 Watts)



Standard Volts



For Indoor Use



Multi-Purpose



15' Household Extension Cord



15-Foot Overall Length

Image: Overview of the Sunlite 15-Foot Household Extension Cord's key features, including its electrical ratings, intended use, and safety certifications.

SAFETY INFORMATION

Always follow these safety guidelines to prevent electrical shock, fire, or personal injury:

- **Indoor Use Only:** This extension cord is designed exclusively for indoor use. Do not use it outdoors or in wet conditions.
- **Do Not Overload:** Ensure the total wattage of all connected devices does not exceed the cord's maximum rating of 1625 Watts (13 Amps at 125 Volts). Overloading can cause overheating and fire.
- **Polarized Plugs:** This cord features polarized plugs (one blade wider than the other). Insert the plug fully into the outlet. Do not force a polarized plug into a non-polarized outlet or extension cord.
- **Tamper Guards:** The outlets are equipped with tamper guards. These shutters help prevent foreign objects from being inserted into the outlets, enhancing safety, especially around children.
- **Inspect Before Use:** Before each use, inspect the cord for any damage, fraying, exposed wires, or

loose connections. Do not use a damaged cord.

- **Avoid Covering:** Do not run the cord under rugs, carpets, or furniture, as this can cause overheating and damage the insulation.
- **Keep Away from Water:** Never use the cord near water or in damp environments.
- **Unplug When Not in Use:** Always unplug the extension cord from the wall outlet when not in use.



Image: Illustration of the tamper-resistant feature, demonstrating how the built-in guards protect unused outlets.

PRODUCT OVERVIEW

The Sunlite 04130-SU is a 15-foot household extension cord designed for convenience and safety. It features a durable construction and multiple outlets to power your devices.

Components:

- **Main Plug:** 2-prong polarized plug for insertion into a wall outlet.
- **Cord:** 15-foot length, 16-gauge wire, SPT (Service Parallel Thermoplastic) type with 2 copper conductors.
- **Outlet Strip:** Features three 2-prong polarized outlets with tamper guards.



sunlite®

ITEM: 04130
White

15FT

**Household
Extension Cord**

Indoor Cord

13-AMP - 125V - 1625W

EX15/W

16/2

SPT - 2

Tamper - Resistant





Image: The Sunlite 15-foot household extension cord, showing its coiled form and the three-outlet end.

sunlite[®]





-  **UL Listed for Safety and Design Quality**
-  **Tamper Resistant Extension Cord**
-  **15-Foot Long Extension Cord**
-  **Three 2-Prong Polarized Sockets**

Image: Detailed view of the polarized plug and the three 2-prong polarized outlets with their tamper-resistant shutters.

SERVICE



PARALLEL

THERMAPLASTIC




Image: Cross-section diagram of the cord, highlighting its SPT construction, 16-gauge wire, and two copper conductors.

SETUP

1. **Unpack:** Carefully remove the extension cord from its packaging.
2. **Inspect:** Before plugging in, visually inspect the entire length of the cord, the plug, and the outlets for any signs of damage. Do not use if damaged.
3. **Uncoil:** Fully uncoil the extension cord. Do not use the cord while it is coiled or bundled, as this can lead to overheating.
4. **Plug into Wall Outlet:** Insert the 2-prong polarized plug firmly into a standard 125V polarized wall outlet. Ensure the wider blade aligns with the wider slot in the outlet.

OPERATING INSTRUCTIONS

Once the extension cord is properly plugged into a wall outlet, you can connect your devices:

1. **Connect Devices:** Insert the plugs of your small appliances, electronics, lamps, fans, or mobile device chargers into the three 2-prong polarized outlets on the extension cord.

2. **Utilize Tamper Guards:** The tamper guards will automatically open when a polarized plug is inserted correctly and close when the plug is removed, protecting the unused outlets.
3. **Monitor Load:** Be mindful of the total power consumption of all connected devices. The cord is rated for a maximum of 1625 Watts (13 Amps). Do not exceed this limit.
4. **Placement:** Position the cord in a way that it does not create a tripping hazard and is not pinched by furniture or doors.



MULTI-PURPOSE

These indoor cords have multiple uses. They can be used for small appliances, fans, electronics, lamps, mobile devices, and much more.

Image: Examples of common household items such as laptops, lamps, and mobile devices that can be powered by this multi-purpose extension cord.

MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your extension cord:

- **Cleaning:** Disconnect the cord from the wall outlet before cleaning. Wipe the cord and outlets with a dry, soft cloth. Do not use liquid cleaners or immerse in water.
- **Storage:** When not in use, unplug the cord from both the wall and devices. Coil it loosely and store it in a dry, cool place away from direct sunlight and moisture. Avoid tight coiling or kinking.
- **Regular Inspection:** Periodically check the cord for any signs of wear, cuts, abrasions, or discoloration. If any damage is observed, discontinue use immediately and replace the cord.

TROUBLESHOOTING

If you encounter issues with your extension cord, consider the following:

- **No Power to Devices:**

- Ensure the extension cord's main plug is fully inserted into a functioning wall outlet.
- Check if the wall outlet itself is working by plugging in another device directly.
- Verify that the devices are properly plugged into the extension cord's outlets.
- Confirm that the total wattage of connected devices does not exceed 1625 Watts.
- Inspect the cord for visible damage. If damaged, discontinue use.

- **Overheating:**

- If the cord or plugs feel warm to the touch, immediately unplug all devices and the cord from the wall.
- This indicates an overload. Reduce the number of connected devices or use a higher-rated extension cord if necessary.

If troubleshooting steps do not resolve the issue, discontinue use and contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	04130-SU
Cord Length	15 Feet (180 Inches)
Color	White
Number of Outlets	3
Plug Type	2-Prong Polarized (Type A)
Voltage Rating	125 Volts
Wattage Rating	1625 Watts
Amperage Rating	13 Amps
Number of Conductors	2
UL Listed	Yes
Item Weight	0.01 Ounces (approximate)
Intended Use	Indoor Household Use

WARRANTY INFORMATION

The Sunlite 04130-SU 15-Foot Household Extension Cord comes with a 1-year warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the packaging of your product or contact Sunlite customer support.

Warranty Description: See Packaging for Details

SUPPORT

For further assistance, questions, or to report an issue with your Sunlite extension cord, please contact Sunlite customer support. Refer to the product packaging or the official Sunlite website for contact information.

You can also visit the official Sunlite store for more product information: [Sunlite Store](#)

© 2026 Sunlite. All rights reserved.

This manual is for informational purposes only. Sunlite reserves the right to make changes to products without prior notice.