

RIBIMEX PRCEN007

RIBIMEX Ribitech Ceneflame 1200W Electric Ash Vacuum Cleaner

Model: PRCEN007

INTRODUCTION

Thank you for choosing the RIBIMEX Ribitech Ceneflame Electric Ash Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and keep it for future reference.





Image: The RIBIMEX Ribitech Ceneflame 1200W Electric Ash Vacuum Cleaner, featuring a metallic canister, red motor housing, and a flexible hose with a nozzle.

IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **Read all instructions:** Before operating the appliance, read all instructions carefully.
- **Cold Ashes Only:** This appliance is designed exclusively for vacuuming **cold ashes**. Do not attempt to vacuum hot ashes, embers, or flammable materials, as this can cause fire or damage to the vacuum.
- **Power Supply:** Ensure the power supply voltage matches the rating indicated on the appliance.
- **Do Not Immerse:** Never immerse the motor unit, power cord, or plug in water or other liquids.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Unplug When Not in Use:** Unplug from outlet when not in use and before cleaning.
- **Damaged Cord/Plug:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- **Proper Use:** Use the appliance only for its intended purpose as described in this manual.
- **Ventilation:** Ensure adequate ventilation when operating the vacuum.

- **Filter Maintenance:** Regularly clean and replace filters as instructed to maintain optimal performance and prevent motor strain.

PACKAGE CONTENTS

Please check the package contents upon unpacking to ensure all components are present and undamaged.

- RIBIMEX Ribitech Ceneflame Ash Vacuum Cleaner Unit (18-liter lacquered sheet metal canister with motor unit)
- Flexible Suction Hose (1.10 m)
- Metallic Nozzle (20 cm)
- Interchangeable and Washable Filter with Antistatic Pre-filter
- 3 Wheels for Mobility
- Instruction Manual

SETUP AND ASSEMBLY

Follow these steps to set up your ash vacuum cleaner for first use.

1. **Unpack:** Carefully remove all components from the packaging.
2. **Attach Wheels:** Securely attach the three wheels to the base of the canister. Ensure they click into place or are firmly screwed in, depending on the design.
3. **Install Filter:** Open the motor unit lid. Ensure the interchangeable filter is correctly seated inside the canister. The antistatic pre-filter should also be in place.
4. **Attach Hose:** Connect the flexible suction hose to the designated inlet port on the motor unit. Twist or push firmly until it is secure.
5. **Attach Nozzle:** Insert the metallic nozzle into the end of the flexible suction hose.
6. **Power Connection:** Plug the power cord into a suitable electrical outlet (230 Volts).

OPERATING INSTRUCTIONS

This section details how to use your ash vacuum cleaner effectively and safely.

Vacuuming Cold Ashes

1. **Ensure Ashes are Cold:** Before vacuuming, always ensure that the ashes in your fireplace, stove, or barbecue are completely cold. This is critical for safety.
2. **Position Vacuum:** Place the ash vacuum cleaner on a stable, flat surface near the area to be cleaned. The wheels allow for easy movement.
3. **Power On:** Press the power switch (usually located on the motor unit) to turn on the vacuum cleaner.
4. **Vacuum Ashes:** Use the metallic nozzle to carefully vacuum the cold ashes. Move the nozzle slowly over the ash to ensure thorough collection.
5. **Filter Cleaning (Pneumatic Shaking):** If you notice a decrease in suction power during operation, the filter may be clogged. This model is equipped with a pneumatic shaking button. Press this button (refer to your unit for exact

location) to dislodge ash from the filter and restore suction.

6. **Power Off:** Once cleaning is complete, turn off the vacuum cleaner and unplug it from the power outlet.

Image: A person using the ash vacuum cleaner to remove cold ashes from a fireplace, demonstrating the proper use of the metallic nozzle.

Blowing Function

Your ash vacuum cleaner also features a blowing function, useful for clearing debris from hard-to-reach areas.

1. **Connect Hose to Outlet:** Disconnect the flexible hose from the suction inlet and connect it to the blowing outlet port on the motor unit (refer to your unit for exact location).
2. **Power On:** Turn on the vacuum cleaner. Air will now be expelled from the hose.
3. **Use for Blowing:** Direct the airflow to clear dust, leaves, or light debris from surfaces.
4. **Power Off:** Turn off the vacuum cleaner and unplug it when finished.

MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and optimal performance of your ash vacuum cleaner. Always unplug the appliance before performing any maintenance.

Emptying the Canister

1. **Unplug:** Ensure the vacuum is unplugged from the power outlet.
2. **Remove Motor Unit:** Unlatch the clips holding the motor unit to the canister and carefully lift the motor unit off.
3. **Empty Ashes:** Dispose of the collected cold ashes into a suitable, non-combustible container.
4. **Wipe Canister:** Wipe the inside of the canister with a dry cloth if necessary.

Cleaning and Replacing the Filter

The filter is crucial for effective operation and should be cleaned regularly.

1. **Remove Filter:** With the motor unit removed, carefully detach the filter from its housing.
2. **Clean Filter:** The filter is washable. Rinse it under cold running water until the water runs clear. Do not use hot water or detergents.
3. **Dry Filter:** Allow the filter to air dry completely before re-installing it. Ensure it is thoroughly dry to prevent damage to the motor.
4. **Re-install Filter:** Once dry, carefully place the filter back into its position within the canister. Ensure the antistatic pre-filter is also correctly seated.
5. **Replace Filter:** Filters have a limited lifespan. If the filter is damaged or cannot be cleaned effectively, replace it with a genuine RIBIMEX replacement filter.

Image: A hand holding the ash vacuum filter under a running faucet, demonstrating how to wash it.

Image: A person's hands carefully placing the filter back into the ash vacuum's canister, showing the filter replacement process.

General Cleaning

- Wipe the exterior of the vacuum cleaner with a damp cloth. Do not use abrasive cleaners or solvents.

- Clean the hose and nozzle as needed to remove any blockages.

TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	No power supply. Power switch is off.	Check if the power cord is securely plugged into a live outlet. Ensure the power switch is in the "ON" position.
Low suction power.	Clogged filter. Full ash canister. Blockage in hose or nozzle.	Clean or replace the filter. Use the pneumatic shaking button. Empty the ash canister. Check hose and nozzle for obstructions and clear them.
Ash escaping from exhaust.	Filter is damaged or improperly installed.	Check filter for damage and ensure it is correctly seated. Replace if necessary.
Unusual noise during operation.	Motor obstruction or damage.	Turn off and unplug the vacuum immediately. Inspect for any visible obstructions. If noise persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	RIBIMEX
Model Number	PRCEN007
Power	1200 Watts
Voltage	230 Volts
Canister Capacity	18 Liters
Depression	17 Kpa
Hose Length	1.10 m
Nozzle Length	20 cm
Noise Level	77 dB
Dimensions (L x W x H)	31.5 x 32.5 x 39.5 cm
Weight	4 Kilograms
Filter Type	HEPA (Interchangeable and Washable)
Special Features	Blowing Function, Pneumatic Filter Shaking Button, 3 Wheels

WARRANTY AND SUPPORT

RIBIMEX products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or to purchase replacement parts (such as filters), please contact your local retailer or visit the official RIBIMEX website.

Please retain your proof of purchase for any warranty claims.

© 2023 RIBIMEX. All rights reserved.