Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Invicta /
- > Invicta Specialty 14879 Men's Quartz Watch Instruction Manual

Invicta 14879

Invicta Specialty 14879 Men's Quartz Watch Instruction Manual

Model: 14879

Introduction

Thank you for choosing the Invicta Specialty 14879 Men's Quartz Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

PRODUCT OVERVIEW

The Invicta Specialty 14879 is a robust men's quartz chronograph watch featuring a gunmetal stainless steel case and band. It is designed for precision timekeeping and durability.



Figure 1: Front view of the Invicta Specialty 14879 watch, showcasing the gunmetal finish, black dial, and chronograph subdials.

Key Features:

- Case: Gunmetal stainless steel, 45mm diameter x 13mm thick.
- **Dial:** Grey dial with luminous hands and hour markers for visibility in low light.
- Movement: Japanese quartz movement, VD57 Caliber, ensuring accurate timekeeping.
- Band: Gunmetal stainless steel band, 185mm L x 22mm W, with a fold-over safety clasp. The band is

adjustable by adding or removing links.

- Crystal: Mineral crystal, designed for scratch resistance.
- Crown: Push/pull crown for setting time and date.
- Bezel: Unidirectional gunmetal and white stainless steel bezel for tracking elapsed time.
- Subdials: Functional subdials for 60-minute, 60-second, and 1/10th second chronograph measurements.
- Water Resistance: 50 meters (165 feet), suitable for washing hands, light splashes, and swimming in shallow depths.



Figure 2: Detailed view highlighting the watch's crown, unidirectional bezel, 45mm case size, and mineral crystal.



Figure 3: Close-up of the watch's high-grade stainless steel bracelet and foldover safety clasp.



Figure 4: Illustration of the watch's quartz chronograph movement, timekeeping functions, and date display.

Your browser does not support the video tag.

Video 1: A 21-second overview of the Invicta Men's 14879 Specialty Chronograph Stainless Steel Watch, showcasing its design and features.

SETUP

1. Setting the Time:

- 1. Pull the crown out to the second click position.
- 2. Rotate the crown to move the hour and minute hands to the desired time.
- 3. Push the crown back to the normal position.

2. Setting the Date:

- 1. Pull the crown out to the first click position.
- 2. Rotate the crown clockwise or counter-clockwise (depending on the movement) to set the correct date.
- 3. Push the crown back to the normal position.
- 4. Note: Avoid setting the date between 9 PM and 3 AM, as this can damage the movement. If the date needs adjustment during this period, first set the time outside this range, adjust the date, then reset the time.

3. Adjusting the Bracelet:

The stainless steel bracelet can be adjusted by adding or removing links to achieve a comfortable fit. This procedure typically requires specialized tools and is best performed by a qualified watch technician or jeweler to prevent damage.

OPERATING INSTRUCTIONS

1. Using the Chronograph:

The chronograph function allows for precise measurement of elapsed time.

- 1. **Start:** Press the upper pusher button to start the chronograph. The chronograph second hand will begin to move.
- 2. **Stop:** Press the upper pusher button again to stop the chronograph. The elapsed time will be indicated by the chronograph hands on the subdials.
- 3. Reset: After stopping, press the lower pusher button to reset the chronograph hands to their zero positions.
- 4. **Split Time (if applicable):** Some chronographs allow for split time measurement. Consult a detailed movement guide if this feature is desired.

2. Using the Unidirectional Bezel:

The unidirectional rotating bezel can be used to track elapsed time, typically up to 60 minutes.

- 1. Rotate the bezel counter-clockwise until the zero marker aligns with the minute hand at the desired starting point.
- 2. As time passes, the minute hand will indicate the elapsed time against the bezel's scale.

MAINTENANCE

• Cleaning: Regularly wipe your watch with a soft, dry cloth to remove dust and dirt. For stainless steel, a slightly damp cloth can be used, followed by immediate drying.

- Water Resistance: The watch is water resistant to 50 meters. This means it is suitable for washing hands, light splashes, and swimming in shallow depths. It is **not** suitable for diving, snorkeling, or high-impact water sports. Ensure the crown is fully pushed in before any contact with water.
- **Temperature:** Avoid exposing your watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect the movement and seals.
- **Chemicals:** Keep your watch away from chemicals such as solvents, detergents, perfumes, and cosmetics, which can damage the case, band, and seals.
- Magnetic Fields: Strong magnetic fields can affect the accuracy of quartz watches. Keep your watch away from strong magnets.
- **Battery Replacement:** The watch uses an SR920SW battery. When the battery runs low, the second hand may start to jump in 2-second intervals (End-of-Life indicator). Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.



Figure 5: Water resistance guide for Invicta watches, indicating that 50 meters is suitable for hand washing, rain, and shallow swimming, but not for diving.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---|--|---|
| Watch not running | Depleted battery | Replace battery (SR920SW) by a professional. |
| Incorrect time/date | Crown not pushed in, or incorrect setting. | Ensure crown is fully pushed in. Re-set time/date as per instructions. |
| Chronograph hands not resetting to zero | Requires chronograph reset procedure. | Consult a watch technician for specific chronograph hand alignment procedures if the standard reset (lower pusher) does not work. |
| Condensation inside crystal | Water ingress due to damaged seal or open crown. | Immediately take the watch to a qualified watch repair center to prevent further damage. |

SPECIFICATIONS

• Model Number: 14879

Movement: Japanese Quartz, VD57 Caliber
 Case Material: Stainless Steel (Gunmetal)

Case Diameter: 45 mm
Case Thickness: 13 mm
Crystal Type: Mineral

• Band Material: Stainless Steel (Gunmetal)

Band Length: 185 mmBand Width: 22 mm

• Clasp: Fold Over Safety Clasp

• Water Resistance: 50 meters (165 feet)

Battery: SR920SW (included)Watch Weight: 170 grams

• Product Dimensions: 4.8 x 4.3 x 3.8 inches (packaging)

WARRANTY INFORMATION

Invicta watches typically come with a manufacturer's warranty covering defects in materials and workmanship under normal use. The duration and terms of the warranty may vary by region and purchase location. Please refer to the warranty card included with your watch or visit the official Invicta website for detailed warranty information and registration procedures.

Keep your proof of purchase for any warranty claims.

SUPPORT

For further assistance, technical support, or service inquiries regarding your Invicta Specialty 14879 watch, please contact Invicta customer service through their official website or the contact information provided in your watch's packaging.

When contacting support, please have your watch model number (14879) and proof of purchase readily available.