Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Olimpia Splendid /
- > Olimpia Splendid Solaria 1100W Carbon Infrared Heater User Manual

Olimpia Splendid 99579

Olimpia Splendid Solaria 1100W Carbon Infrared Heater

USER MANUAL - MODEL 99579

1. Introduction

Thank you for choosing the Olimpia Splendid Solaria 1100W Carbon Infrared Heater. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read these instructions carefully before use and retain them for future reference.

Important Safety Information

- Always ensure the heater is placed on a stable, level surface to prevent tipping.
- Do not cover the heater or obstruct its air inlets/outlets. This can lead to overheating.
- Keep flammable materials (curtains, furniture, paper, etc.) at least 1 meter (3 feet) away from the heater.
- Do not use the heater in bathrooms, laundry areas, or similar indoor locations where it may come into contact with water.
- Unplug the heater from the power outlet when not in use or before cleaning.
- Do not operate the heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- Supervise children and individuals with reduced physical, sensory, or mental capabilities when the heater is in operation.

2. Product Overview

The Olimpia Splendid Solaria 1100W Carbon Infrared Heater is designed to provide efficient radiant heat. It features carbon fiber heating components for optimized heating with minimal light emission.



Figure 2.1: Front view of the Olimpia Splendid Solaria 1100W Carbon Infrared Heater. The image shows the black casing, the protective grille, and the glowing carbon heating elements inside.

Key Features:

- Carbon Fiber Heating: Maximizes heat output while minimizing light dispersion.
- Two Power Settings: Select between 600W and 1100W for desired heat intensity.
- 90-Degree Oscillation: Distributes heat evenly across a wider area.
- Safety Thermostat: Automatically shuts off the unit if it overheats.
- Anti-Switch Function: Enhances safety by preventing unintended operation.
- Portable Design: Equipped with a practical and ergonomic handle for easy transport.



Figure 2.2: The heater positioned in an office environment, demonstrating its compact size and suitability for various indoor spaces. It is shown next to a desk with a laptop and bookshelves in the background.

3. Setup

3.1 Unpacking

- · Carefully remove the heater from its packaging.
- Check for any signs of damage. If the unit appears damaged, do not use it and contact your retailer.
- Retain the packaging for storage or future transport.

3.2 Placement

- Place the heater on a firm, level, and stable surface.
- Ensure there is at least 1 meter (3 feet) of clear space around the heater from walls, furniture, curtains, and other combustible materials.
- Do not place the heater directly below a power outlet.
- Avoid placing the heater in high-traffic areas where it could be easily knocked over.

3.3 Power Connection

- Ensure the heater's power switch is in the 'OFF' position before plugging it in.
- Connect the power cord to a grounded 220-240V AC electrical outlet.
- Do not use extension cords or power strips with this heater unless absolutely necessary and only if they are rated for the heater's wattage (1100W).

4. Operating Instructions

Familiarize yourself with the control knobs located on the top of the heater.

4.1 Powering On/Off

- To turn the heater ON, rotate the power setting knob (typically marked with '0', 'I', 'II' or similar) to your
 desired heat level.
- To turn the heater OFF, rotate the power setting knob to the '0' position.
- · Always unplug the heater from the wall outlet when not in use.

4.2 Adjusting Power Settings

The heater offers two power settings:

- Setting I (600W): Provides a lower heat output for smaller spaces or less intense heating.
- Setting II (1100W): Provides maximum heat output for larger spaces or quicker heating.

Rotate the power setting knob to select between these two settings.

4.3 Oscillation Function

To activate the 90-degree oscillation function:

- Locate the oscillation control knob (often marked with an oscillation symbol).
- Rotate the knob to the 'ON' position to enable the heater to swing from side to side, distributing heat more broadly.
- Rotate the knob to the 'OFF' position to stop oscillation and direct heat in a fixed direction.

5. Maintenance

Regular maintenance ensures the longevity and safe operation of your heater.

5.1 Cleaning

- · Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces of the heater with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- Do not immerse the heater in water or allow water to drip into the interior.
- Use a vacuum cleaner with a brush attachment to gently remove dust from the grilles and heating elements.

5.2 Storage

- If storing the heater for an extended period, clean it thoroughly as described above.
- Store the heater in its original packaging, if possible, in a cool, dry place.
- Do not place heavy objects on top of the heater during storage.

6. Troubleshooting

If you encounter issues with your heater, please consult the following troubleshooting guide before contacting support.

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Power switch is OFF. Safety thermostat activated.	Ensure the heater is plugged into a working outlet. Turn the power setting knob to 'I' or 'II'. Unplug the heater, let it cool for 10-15 minutes, then plug it back in. Ensure proper ventilation.
No heat output.	Power setting too low. Safety thermostat activated.	Increase the power setting to 'II' (1100W). Refer to the solution for 'Heater does not turn on'.
Oscillation not working.	Oscillation function is OFF.	Turn the oscillation control knob to the 'ON' position.
Heater emits unusual noise or smell.	New unit (initial use). Internal damage.	A slight odor or noise is normal during the first few uses. If it persists or is strong, unplug immediately and contact support.

7. Specifications

Technical details for the Olimpia Splendid Solaria 1100W Carbon Infrared Heater.

Model Number: 99579Brand: Olimpia Splendid

Power Source: ACVoltage: 220-240VWattage: 1100W (Max)

• Power Settings: 600W / 1100W

• Heating Method: Radiant (Carbon Infrared)

• Product Dimensions (approx.): 31 x 17.5 x 68 cm (L x W x H)

• Weight: 2.7 kg

• Special Features: Portable, 90-degree oscillation, Safety thermostat

• Mounting Type: Floor Mount

• Color: Black




Figure 7.1: Dimensional diagram of the heater, indicating a height of 64 cm, a width of 32 cm, and a depth of 24 cm at the base.

8. Warranty and Support

For warranty information, product support, or service inquiries, please refer to the warranty card included with your purchase or contact your retailer or the manufacturer directly. Ensure you have your model number (99579) and proof of purchase available when contacting support.

Manufacturer: Olimpia Splendid

Related Documents - 99579





OSIMPIA SPENDID HOME OF COMPONT

Olimpia Splendid Caldorad Humi Electric Heater - User Manual

Comprehensive user manual for the Olimpia Splendid Caldorad Humi electric heater, detailing installation, operation, safety precautions, and maintenance for optimal performance and longevity.