

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lasko](#) /
- › [Lasko 1850 18-Inch Pedestal Stand Fan Instruction Manual](#)

Lasko 1850

Lasko 1850 18-Inch Pedestal Stand Fan Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Lasko 1850 18-Inch Pedestal Stand Fan. Please read all instructions carefully before assembly and use. This fan features an 18-inch blade, adjustable height from 38 to 54.5 inches, widespread oscillation, a tilt-back fan head, 3 energy-efficient speeds, an auto-off timer (up to 4 hours), and a multi-function remote control. It is designed for indoor use and requires simple, no-tools assembly. The fan is ETL listed and includes Lasko's patented Blue Plug safety fuse technology.



Figure 1: Fully assembled Lasko 1850 Pedestal Stand Fan.

SETUP AND ASSEMBLY

The Lasko 1850 Pedestal Stand Fan is designed for quick and easy, no-tools assembly. Follow the instructions provided in the packaging for detailed steps. Ensure all components are securely fastened before connecting the fan to a power source.

To adjust the fan's height, loosen the adjustment collar on the stand, raise or lower the fan to the desired height (between 38 and 54.5 inches), and then securely tighten the collar. The fan head can also be tilted up or down to direct airflow.





Figure 2: Demonstrating the adjustable height feature of the fan.





Figure 3: Adjusting the tilt-back fan head for optimal airflow direction.

OPERATING INSTRUCTIONS

Your Lasko 1850 fan can be operated using the control panel on the fan unit or the included multi-function remote control.

Control Panel

- **Power Button:** Press to turn the fan ON or OFF.
- **Speed Settings:** Select from 3 energy-efficient speeds (1, 2, 3) to adjust airflow intensity.
- **Timer Function:** Set the fan to automatically turn off after 1, 2, or 4 hours.
- **Oscillation:** Activate or deactivate widespread oscillation for broader air distribution.





Figure 4: The fan's integrated control panel for manual operation.

Remote Control

The remote control duplicates all functions available on the fan's control panel, allowing convenient operation from a distance. Ensure the remote has working batteries. There is a dedicated storage slot for the remote on the back of the fan unit.






Figure 5: The multi-function remote control for convenient operation.

Oscillation Feature

The widespread oscillation feature allows the fan head to move from side to side, distributing air across a larger area. Activate this function via the control panel or remote control.







Figure 6: The fan oscillating to cover a wider area.

MAINTENANCE

Regular cleaning helps maintain the fan's performance and extends its lifespan. Always unplug the fan from the power outlet before cleaning or performing any maintenance.

- **Exterior Cleaning:** Use a soft, damp cloth to wipe down the exterior surfaces. Do not use abrasive cleaners or immerse the fan in water.
- **Blade Cleaning:** The fan is designed for easy disassembly to clean the blades. Refer to the assembly instructions for safe disassembly and reassembly. Ensure blades are dry before reassembly.
- **Storage:** When not in use, store the fan in a cool, dry place.

TROUBLESHOOTING

If your fan is not operating as expected, please check the following common issues:

- **Fan Does Not Turn On:** Ensure the fan is securely plugged into a working electrical outlet. Check if the Blue Plug safety fuse has tripped. If so, unplug the fan and check for any electrical faults before resetting.
- **Reduced Airflow:** Check for any obstructions around the fan blades or grille. Clean the blades and grille if dust or debris has accumulated.
- **Unusual Noise:** Ensure all parts are securely assembled. Check for any loose components or foreign objects within the fan grille.
- **Oscillation Not Working:** Verify that the oscillation function is activated via the control panel or remote. Check for any obstructions preventing the fan head from rotating.

SPECIFICATIONS

Feature	Detail
Brand	Lasko
Model Name	Lasko 1850 18-Inch Remote Pedestal Fan
Model Number	1850
Color	White
Electric Fan Design	Floor Fan
Power Source	Corded Electric
Product Dimensions	20.5"D x 20.5"W x 54.5"H
Adjustable Height	38" to 54.5"

Special Features	Widespread oscillation, Adjustable height, Tilt-back fan head, 3 speeds, Timer, Remote Control
Number of Blades	5
Blade Length	18 Inches
Wattage	114 watts
Voltage	120V
Item Weight	8.5 Pounds
Safety Features	ETL Listed, Patented Fused Safety Plug (The Blue Plug)

WARRANTY AND SUPPORT

The Lasko 1850 18-Inch Pedestal Stand Fan comes with a 1-year limited manufacturer's warranty. For warranty claims, technical support, or replacement parts, please refer to the contact information provided in your product packaging or visit the official Lasko website.

This fan is equipped with Lasko's patented 2-pronged Blue Plug safety fuse technology, designed to cut off electric current to the fan if it detects a potentially hazardous electrical fault in the motor or power supply, enhancing user safety.