

Inter Link 19300100

Inter Link 19300100 Novi Sonoma Rolling Cabinet Instruction Manual

1. INTRODUCTION

This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your Inter Link 19300100 Novi Sonoma Rolling Cabinet. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of the product. Keep this manual for future reference.

2. SAFETY INFORMATION

- Always assemble the cabinet on a clean, flat, and soft surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.
- Do not overload drawers. Distribute weight evenly to maintain stability.
- Keep small parts and assembly hardware away from children and pets to prevent choking hazards.
- Use caution when moving the cabinet, especially on uneven surfaces, to prevent tipping.
- This product is intended for indoor use only.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- 1 x Drawer Container (main cabinet body)
- 4 x Metal Drawers
- 4 x Plastic Rollers (wheels)
- Silver-colored handles (quantity for 4 drawers)
- Assembly hardware (screws, dowels, etc.)

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two people. Please follow these steps carefully.

4.1 Unpacking and Part Identification

Carefully unpack all components from the packaging. Lay them out on a soft, clean surface. Identify each part using the provided parts list (if included in physical manual) or by comparing with the images below.



Figure 1: Front view of the assembled Inter Link Novi Sonoma Rolling Cabinet in Sonoma Oak finish. This image displays the four drawers, the top surface, and the four plastic rollers at the base.

4.2 Attaching Rollers

Attach the four plastic rollers to the bottom panel of the cabinet. Ensure they are securely fastened using the provided screws. The rollers allow for easy mobility of the cabinet.






Figure 2: A closer front view of the cabinet, highlighting the four plastic rollers attached to the base, enabling mobility.

4.3 Assembling the Cabinet Frame

Connect the side panels to the top and bottom panels using the appropriate hardware (e.g., dowels, cam locks, screws). Follow the pre-drilled holes. Ensure all connections are tight and the frame is stable.

4.4 Assembling and Installing Drawers

Assemble each of the four drawers. This typically involves connecting the front, back, and side panels, then inserting the bottom panel. Install the drawer slides onto the cabinet frame and the drawers themselves. Carefully insert each assembled drawer into its designated slot in the cabinet frame.



Figure 3: The rolling cabinet positioned in a home office environment, demonstrating its functional integration and appearance.

4.5 Attaching Handles

Attach the silver-colored handles to the front of each drawer using the provided screws. Ensure they are aligned and securely fastened.



Figure 4: A detailed view of the silver-colored handles on the drawers, showcasing their design and finish.




Figure 5: An isolated close-up of one of the silver-colored drawer handles, emphasizing its curved shape and metallic sheen.

4.6 Final Check

Once assembly is complete, gently test the drawers to ensure they open and close smoothly. Verify that the cabinet is stable and all connections are secure.

5. OPERATING INSTRUCTIONS

5.1 Using the Drawers

To open a drawer, gently pull the handle. To close, push the drawer back until it is fully seated. Avoid slamming drawers to prevent damage to the slides and contents. Distribute items evenly within the drawers to prevent imbalance and ensure smooth operation.



Figure 6: The cabinet with small office supplies placed on its top surface, illustrating its readiness for daily use.

5.2 Moving the Cabinet

Due to its plastic rollers, the cabinet can be easily moved. To move, gently push or pull the cabinet. Ensure the path is clear of obstacles. For stability, avoid moving the cabinet over very uneven surfaces or with drawers fully extended.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Dusting:** Regularly dust the cabinet to prevent buildup.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone-based lubricant can be applied to the drawer slides.
- **Environment:** Keep the cabinet away from direct sunlight and extreme temperature changes to prevent warping or fading of the wood finish.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Overloaded drawer, misaligned slides, or dirty slides.	Reduce drawer contents. Check alignment of drawer slides. Clean slides and apply silicone lubricant if needed.
Cabinet is wobbly or unstable.	Loose screws or uneven assembly.	Check and tighten all assembly screws. Ensure the cabinet is on a flat, level surface.
Rollers do not move freely.	Debris in rollers or damaged rollers.	Clean any debris from the rollers. If damaged, contact customer support for replacement parts.

8. SPECIFICATIONS

Brand:	Inter Link
Model Number:	19300100
Product Dimensions (W x D x H):	40 x 36 x 65 cm (15.7 x 14.2 x 25.6 inches)
Item Weight:	13 Kilograms (28.7 lbs)
Color:	Sonoma Oak
Material:	Oak (Wood)
Number of Drawers:	4
Special Features:	Lightweight, Rolling (with plastic rollers)
Assembly Required:	Yes

9. WARRANTY AND SUPPORT

For warranty information, missing parts, or technical support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. You may also visit the official Inter Link website for customer service contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question