

Status S32TOWERFAN1PKB

Status Tower Fan Instruction Manual

Model: S32TOWERFAN1PKB

1. IMPORTANT SAFETY INFORMATION

Please read these instructions carefully before using the appliance and retain them for future reference. Incorrect use may result in electric shock, fire, or serious injury.

- Always ensure the voltage on the rating label matches the mains voltage.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Unplug from the mains socket when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Keep the appliance out of reach of children.
- Ensure the fan is placed on a stable, flat surface to prevent tipping.
- Do not insert fingers or any objects into the fan grille.

2. PRODUCT OVERVIEW

The Status 32 Inch Tower Fan is designed to provide efficient and portable cooling for your home or office. It features multiple speed settings and an oscillating function for wider air distribution.



Figure 2.1: Front view of the Status 32 Inch Tower Fan. This image shows the fan's tall, slender white body with a vertical grille for air output and a stable circular base. A small control panel is visible at the top.

Key Features:

- 3 Speed Settings: Low, Medium, High for customized airflow.
- Oscillating Function: Distributes air across a wider area.
- Portable Design: Lightweight with a built-in carry handle for easy relocation.
- 1.8 Metre Cable: Provides ample reach to power outlets.

3. SETUP AND ASSEMBLY

The Status Tower Fan requires minimal assembly before first use.

1. **Unpack:** Carefully remove the fan and all components from the packaging. Retain packaging for future storage or transport.
2. **Base Assembly:** The fan typically comes with the base detached. Align the two halves of the circular base and snap them together around the bottom of the fan unit. Secure with any provided screws if applicable (refer to diagram in physical manual if present).
3. **Placement:** Place the fan on a firm, level surface, ensuring there is adequate space around it for proper airflow and oscillation. Avoid placing near curtains or other objects that could obstruct the

fan's operation.

4. **Power Connection:** Plug the power cord into a standard electrical outlet.

4. OPERATION

The fan is operated via controls located on the top panel of the unit.

Control Panel:

- **Power Button:** Press to turn the fan ON or OFF.
- **Speed Button:** Press repeatedly to cycle through the 3 speed settings: Low (I), Medium (II), High (III).
- **Oscillation Button:** Press to activate or deactivate the oscillating (swinging) function. When active, the fan will rotate from side to side to cover a wider area.

For optimal cooling, position the fan in a location where it can circulate air effectively throughout the room.

5. MAINTENANCE AND CARE

Regular cleaning and proper care will ensure the longevity and efficient operation of your tower fan.

- **Cleaning:** Clean dust and debris from the fan grills and blades every two to three weeks. Always unplug the fan from the mains power supply before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, unplug the fan and store it in a cool, dry place, preferably in its original packaging to protect it from dust and damage.
- **Moving:** Always unplug the fan before moving it. Use the built-in carry handle for safe and easy transport.

6. TROUBLESHOOTING

If you experience issues with your Status Tower Fan, please consult the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; power outlet not working; power button not pressed.	Ensure plug is fully inserted. Test outlet with another device. Press the power button firmly.

Problem	Possible Cause	Solution
Weak airflow.	Fan speed set too low; air intake/output blocked; dust accumulation.	Increase fan speed. Clear any obstructions. Clean fan grills and blades.
Fan makes unusual noise.	Fan not on a level surface; internal obstruction; loose parts.	Place fan on a stable, flat surface. Unplug and check for any visible obstructions. If noise persists, contact customer support.
Oscillation not working.	Oscillation button not pressed; mechanism obstructed.	Press the oscillation button. Ensure no objects are blocking the fan's rotation.

If the problem persists after trying these solutions, please contact Status customer support.

7. SPECIFICATIONS

Attribute	Detail
Brand	Status
Model Number	S32TOWERFAN1PKB
Product Dimensions	24D x 24W x 76H centimetres
Item Weight	2.4 kg
Power Source	Corded Electric
Speed Settings	3
Special Feature	Portable, Oscillating
Colour	White
Cable Length (approx)	1.8 metres

8. WARRANTY AND SUPPORT






This Status Tower Fan comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Status customer service. Contact information can typically be found on the product packaging, the official Status website, or your purchase receipt.

Please retain your proof of purchase for any warranty claims.

© 2025 Status. All rights reserved.

Related Documents - S32TOWERFAN1PKB

	<p>Status Solid 300 Semi-Professional Vacuum Packing Machine User Manual</p> <p>This user manual provides comprehensive instructions for the Status Solid 300 semi-professional vacuum packing machine. Learn how to preserve food freshness, extend shelf life, and utilize its features for efficient food storage and preparation.</p>
	<p>Status BVP130 Electric Vacuum Pump User Manual</p> <p>User manual for the Status BVP130 Electric Vacuum Pump, covering safety instructions, operation, maintenance, troubleshooting, and warranty.</p>
	<p>Status Between Micro User Guide: Charging, Pairing, Controls, and Safety</p> <p>This user guide provides comprehensive instructions for the Status Between Micro wireless earbuds, covering charging, Bluetooth pairing, touch controls, fit, safety precautions, and regulatory information.</p>
	<p>Status Between 3ANC User Guide: Features, Safety, and FCC Compliance</p> <p>Comprehensive user guide for Status Between 3ANC earbuds, detailing features, safety precautions, and FCC compliance information. Learn about active noise cancelling, transparency mode, and Bluetooth connectivity.</p>
	<p>Specialized STATUS Torque Wrench User Guide: Proper Bicycle Assembly</p> <p>Learn how to properly use the Specialized STATUS torque wrench for bicycle assembly. This guide provides step-by-step instructions, safety warnings, and tips for accurate bolt tightening to Nm specifications.</p>

<div data-bbox="142 143 188 165" data-label="Text"><p>Status</p></div> <div data-bbox="148 165 181 170" data-label="Text"><p>Model: SBW-1000</p></div> <div data-bbox="237 143 284 165" data-label="Text"><p>Status</p></div> <div data-bbox="237 165 284 170" data-label="Text"><p>Model: SBW-1000</p></div>	<div data-bbox="341 107 868 138" data-label="Section-Header"><p>Status Between Wireless Earbuds User Guide</p></div> <div data-bbox="341 147 1430 219" data-label="Text"><p>User guide for Status Between Wireless Earbuds, covering features, charging, operation, safety information, and Bluetooth pairing.</p></div>
---	--