

## Leviton 003-84026-0

# Leviton 003-84026-0 Stainless Steel 2-Gang Power Outlet Receptacle Wallplate Instruction Manual

## INTRODUCTION

This manual provides instructions for the proper installation and maintenance of the Leviton 003-84026-0 Stainless Steel 2-Gang Power Outlet Receptacle Wallplate. Please read these instructions carefully before beginning installation.

## SAFETY INFORMATION

- Always turn off power at the circuit breaker or fuse box before installation or maintenance.
- Ensure all wiring connections comply with local electrical codes.
- If you are unsure about any part of these instructions, consult a qualified electrician.
- This product is designed for indoor use only.

## PACKAGE CONTENTS

- Leviton 003-84026-0 Stainless Steel 2-Gang Wallplate
- Mounting Screws (typically included with wallplate)

## SETUP AND INSTALLATION

1. **Turn Off Power:** Locate the circuit breaker or fuse that controls the power to the outlet where the wallplate will be installed. Turn off the power completely. Verify power is off using a voltage tester.
2. **Remove Old Wallplate:** Carefully unscrew and remove the existing wallplate, if any.
3. **Position New Wallplate:** Align the Leviton 003-84026-0 wallplate over the electrical box, ensuring the openings match the receptacles.
4. **Secure Wallplate:** Insert the provided mounting screws into the designated holes on the wallplate and tighten them gently until the wallplate is flush with the wall. Do not overtighten, as this can damage the wallplate or the electrical box.
5. **Restore Power:** Once the wallplate is securely installed, restore power at the circuit breaker or fuse box.

## OPERATING INSTRUCTIONS

The Leviton 003-84026-0 wallplate is a passive component designed to cover and protect electrical outlets. No specific operational steps are required beyond its proper installation. Ensure that the receptacles are fully accessible and that the wallplate does not obstruct their use.

## MAINTENANCE

- **Cleaning:** To clean the stainless steel wallplate, use a soft, damp cloth. For stubborn marks, a mild, non-abrasive cleaner suitable for stainless steel can be used. Avoid harsh chemicals or abrasive scrubbers, which can scratch the finish.
- **Inspection:** Periodically inspect the wallplate for any signs of damage, such as cracks, discoloration, or loose screws. If damage is observed, turn off power and replace the wallplate.

## TROUBLESHOOTING

- **Wallplate is Loose:** Ensure mounting screws are tightened appropriately. Do not overtighten.
- **Wallplate Does Not Sit Flush:** Check for obstructions behind the wallplate or ensure the electrical box is properly recessed.
- **Scratches or Discoloration:** Refer to the Maintenance section for cleaning instructions. Deep scratches may require replacement.

## SPECIFICATIONS

Brand	Leviton
Model Number	003-84026-0
Configuration	2-Gang (Double)
Color	Stainless-Steel
Finish Type	Painted
Installation Type	Screw-In
Item Weight	2.56 ounces
Product Dimensions	4.5 x 4.5 x 0.33 inches
UPC	078477431306



This diagram illustrates the precise dimensions of the 2-gang wallplate. It shows a width of 2.750 inches (69.85 mm) for each opening, a total width of 4.56 inches (115.9 mm) for the 2-gang configuration, and a height of 4.500 inches (114.30 mm). The thickness is 0.220 inches (5.59 mm). Screw hole spacing and opening dimensions are also detailed.

## WARRANTY INFORMATION

Leviton products are backed by a limited warranty. For specific warranty terms and conditions, please refer to the official Leviton website or contact customer support. Keep your proof of purchase for warranty claims.

# SUPPORT AND CONTACT

---

For technical assistance, product inquiries, or support, please visit the official Leviton website or contact their customer service department. Contact information can typically be found on the manufacturer's website or product packaging.

**Manufacturer:** Leviton

**Website:** [www.leviton.com](http://www.leviton.com)

