

[Manuals.plus](#) /

> [Puig](#) /

> Puig 7023J Rear Fender for BMW R Nine T Series, Matte Black Instruction Manual

Puig 7023J

Puig 7023J Rear Fender Instruction Manual

Model: 7023J | Brand: Puig

1. PRODUCT OVERVIEW

The Puig 7023J Rear Fender is designed to provide protection for the rear wheel area of your motorcycle. Constructed from durable ABS plastic and aluminum, this matte black fender integrates with the aesthetic of compatible BMW R Nine T series motorcycles. It helps to reduce spray and debris from the rear tire, keeping the undertail cleaner.

Compatibility:

- BMW R NINE T (2014-2022)
- BMW R NINE T PURE (2017-2022)
- BMW R NINE T RACER (2017-2020)
- BMW R NINE T URBAN G/S (2017-2020)
- BMW R NINE T URBAN S (2017-2020)



Figure 1: The Puig 7023J Rear Fender in matte black, showcasing its design and construction.

2. SETUP AND INSTALLATION

Installation of the Puig 7023J Rear Fender requires basic mechanical knowledge and tools. It is recommended to consult a qualified motorcycle technician if you are unsure about any steps. Ensure the motorcycle is stable on a stand before beginning installation.

2.1. Required Tools (Not Included)

- Appropriate wrenches or sockets for motorcycle fasteners.
- Torque wrench for precise tightening.
- Degreaser and cleaning cloths.

2.2. Installation Steps

1. Park the motorcycle on a level surface and secure it using a suitable stand.
2. Identify the mounting points on the motorcycle's swingarm or frame where the fender will attach. Refer to your motorcycle's service manual for specific details regarding rear wheel components.
3. Clean the mounting area thoroughly to ensure a secure fit and prevent debris from interfering with the installation.
4. Position the Puig 7023J Rear Fender against the identified mounting points.
5. Align the fender with the pre-drilled holes and secure it using the provided hardware. Do not fully tighten bolts at this stage.
6. Once all bolts are in place, gradually tighten them to the manufacturer's specified torque settings. Ensure even tightening to prevent stress on the fender or motorcycle components.
7. Verify that the fender is securely mounted and does not interfere with the movement of the rear wheel, suspension, or any other motorcycle parts.



Figure 2: The Puig 7023J Rear Fender shown installed on a BMW R Nine T series motorcycle, illustrating its position relative to the rear wheel and suspension.

Important: Incorrect installation can lead to product failure or damage to your motorcycle. If you encounter any difficulties, seek professional assistance.

3. OPERATING INSTRUCTIONS

The Puig 7023J Rear Fender operates passively by deflecting water, mud, and road debris away from the motorcycle's undertail and rear suspension components. No active operation is required from the user after proper installation. Ensure the fender remains securely attached and free from obstructions during motorcycle operation. Periodically check mounting bolts for tightness, especially after riding on rough terrain or after significant mileage.

4. MAINTENANCE

Regular maintenance will ensure the longevity and effectiveness of your Puig 7023J Rear Fender.

- **Cleaning:** Clean the fender regularly with mild soap and water. Avoid abrasive cleaners or solvents that could damage the ABS plastic or matte finish. A soft cloth or sponge is recommended.
- **Inspection:** Periodically inspect the fender for any signs of damage, cracks, or loose mounting hardware. Address any issues promptly to prevent further damage or detachment.
- **Fastener Check:** Check all mounting bolts for proper tightness at least once a month or every 500 km (300 miles), whichever comes first. Re-tighten to specified torque if necessary.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with the rear fender.

Problem	Possible Cause	Solution
Fender feels loose or rattles.	Loose mounting bolts.	Check and tighten all mounting bolts to the recommended torque specifications.
Excessive spray from the rear wheel.	Fender misalignment or damage.	Inspect fender for proper alignment and ensure it is not damaged. Realign or replace if necessary.
Cracks or visible damage on the fender.	Impact from debris or stress.	Minor cracks may be repaired with appropriate plastic repair kits. For significant damage, replacement is recommended.

If troubleshooting steps do not resolve the issue, contact Puig customer support or a certified motorcycle mechanic.

6. SPECIFICATIONS

- **Model Number:** 7023J
- **Brand:** Puig
- **Material:** ABS Plastic, Aluminum
- **Color:** Matte Black
- **Dimensions (L x W x H):** Approximately 45.7 x 35.6 x 20.3 cm (18 x 14 x 8 inches)
- **Number of Pieces:** 1
- **Vehicle Service Type:** Motorcycle
- **Fitment Type:** Universal (specific to BMW R Nine T series)
- **Position:** Rear
- **Country of Origin:** Spain

7. WARRANTY AND SUPPORT

Puig products are manufactured to high standards. For specific warranty information, please refer to the official Puig website or contact your authorized dealer. Keep your proof of purchase for any warranty claims.

7.1. Customer Support

For technical assistance, installation queries, or parts inquiries, please contact Puig customer support through their official website:

[Visit Puig Official Website](#)

When contacting support, please have your product model number (7023J) and purchase details ready.

