

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Diversitech](#) /

› [Diversitech ED1262-2 Double Pole Toggle Switch Instruction Manual](#)

Diversitech ED1262-2

Diversitech ED1262-2 Double Pole Toggle Switch Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and effective installation, operation, and maintenance of your Diversitech ED1262-2 Double Pole (D.P.) Toggle Switch. Please read this manual thoroughly before use and retain it for future reference. This product is designed for reliable performance in appropriate electrical applications.

SAFETY INFORMATION

Adherence to the following safety guidelines is crucial to prevent electrical shock, fire, or personal injury.

- **Always disconnect power** at the circuit breaker or fuse box before installing, servicing, or removing the switch. Failure to do so can result in severe injury or death.
- Installation should be performed by a **qualified electrician** in accordance with all local and national electrical codes and regulations.
- Do not exceed the specified voltage (277 Volts) or current rating (15 Amps) of this device. Overloading can cause overheating and fire.
- Ensure all wiring connections are secure, tight, and properly insulated to prevent short circuits.
- This switch is designed for indoor use in dry locations unless otherwise specified by local codes for specific applications.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- 1 x Diversitech ED1262-2 Double Pole Toggle Switch
- Rough Electrical Components (if included with your specific purchase)

SPECIFICATIONS

Property	Value
Brand	Diversitech
Model Number	ED1262-2
Material	Metal
Voltage Rating	277 Volts
Current Rating	15 Amps
Operation Mode	ON-OFF
Product Dimensions	7.5 x 3 x 1.75 inches
Item Weight	3.2 ounces
UPC / GTIN	780653021439

INSTALLATION INSTRUCTIONS

Installation of electrical components should only be performed by a qualified professional.

- Safety First:** Turn off power to the circuit at the main service panel (circuit breaker or fuse box) before starting any work. Verify power is off using a voltage tester.
- Prepare Wiring:** Identify the load and line wires. This is a Double Pole (D.P.) switch, meaning it controls two separate circuits or both hot legs of a 240V circuit. Consult wiring diagrams specific to your application and local electrical codes.
- Connect Wires:** Connect the appropriate wires to the switch terminals. Ensure connections are tight and secure. For a D.P. switch, there will typically be four terminals for line and load connections. Refer to the wiring diagram provided with your specific application or consult a qualified electrician.
- Mount Switch:** Carefully position the switch into the electrical box and secure it using appropriate mounting screws. Ensure no wires are pinched or damaged during this process.
- Restore Power:** Once installation is complete and all connections are verified to be correct and secure, restore power at the main service panel.

OPERATING INSTRUCTIONS

The Diversitech ED1262-2 Toggle Switch operates with a simple ON-OFF mechanism.

- To turn the connected device or circuit **ON**, push the toggle lever to the 'ON' position.
- To turn the connected device or circuit **OFF**, push the toggle lever to the 'OFF' position.

MAINTENANCE

The Diversitech ED1262-2 Toggle Switch is designed for durability and requires minimal maintenance.

- Periodically inspect the switch for any visible signs of damage, wear, or loose connections.
- Ensure the switch and surrounding area are kept clean and free from dust and debris. Use a dry, soft cloth for cleaning; do not use liquid cleaners or abrasive materials.

- If any issues are observed, such as unusual heat, sparking, or difficulty operating the switch, disconnect power immediately and consult a qualified electrician.

TROUBLESHOOTING

If you encounter problems with your toggle switch, consider the following common issues:

- **Switch Not Functioning:**
 - Check if the power supply to the circuit is active at the main service panel.
 - Verify all wiring connections are secure and correct according to the installation instructions.
 - Ensure the switch's current and voltage ratings are not exceeded by the connected load.
- **Overheating:** Disconnect power immediately. Overheating can indicate an overload, a faulty connection, or an internal defect. Do not attempt to operate the switch if it is overheating. Consult a qualified electrician.
- For persistent issues or any concerns regarding electrical safety, contact a qualified electrician or the manufacturer's support.

WARRANTY INFORMATION

For specific warranty details regarding the Diversitech ED1262-2 Toggle Switch, please refer to the documentation provided with your purchase or contact Diversitech directly. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you require further assistance, technical support, or have questions not covered in this manual, please contact Diversitech customer service. Visit the official Diversitech website for current contact information.

Note: Always provide the model number (ED1262-2) when contacting support to ensure efficient service.