

## AC Adapter for Vivitar ViviCam X30 X60 4000

# Generic AC Adapter Charger for Vivitar ViviCam X30 X60 4000 Camera - Instruction Manual

*Model: AC Adapter for Vivitar ViviCam X30 X60 4000*

## 1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Generic Compatible Replacement AC Adapter Charger. This adapter is designed to provide power and charge batteries for Vivitar ViviCam X30, X60, and 4000 camera models. Please read this manual thoroughly before use and retain it for future reference.

## 2. SAFETY INFORMATION

Observe the following safety precautions to prevent damage to the product or injury to yourself:

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not disassemble or modify the adapter.
- Ensure the power outlet voltage matches the adapter's input specifications (AC 110V-220V).
- Avoid using the adapter with damaged cords or plugs.
- Keep out of reach of children.
- Unplug the adapter from the power outlet when not in use or during electrical storms.

## 3. PACKAGE CONTENTS

- 1 x Generic Compatible Replacement AC Adapter Charger

## 4. PRODUCT OVERVIEW



**Figure 1:** The Generic AC Adapter Charger. This image displays the black rectangular adapter unit with a standard two-prong US-style plug on one side and a coiled black power cord extending from the other side, terminating in a proprietary connector (not fully visible).

The AC Adapter Charger consists of a main power brick with integrated prongs for wall outlets and an attached cable with a proprietary connector designed for compatible Vivitar ViviCam camera models.

## 5. SETUP

1. **Verify Compatibility:** Ensure your camera model is Vivitar ViviCam X30, X60, or 4000.
2. **Inspect Adapter:** Before first use, visually inspect the adapter and cable for any signs of damage. Do not use if damaged.
3. **Connect to Camera:** Carefully insert the adapter's proprietary connector into the power input port of your Vivitar ViviCam camera. Ensure a secure connection.
4. **Connect to Power Outlet:** Plug the adapter's two-prong plug into a standard AC wall outlet (110V-220V).

## 6. OPERATING INSTRUCTIONS

Once connected, the adapter will begin to supply power to your camera and/or charge its battery, depending on the camera's design and current power state.

- The camera's charging indicator (if present) should illuminate, indicating that charging is in progress.
- You can typically operate the camera while it is connected to the AC adapter, provided the battery is sufficiently charged or the camera supports direct power operation.
- To disconnect, first unplug the adapter from the wall outlet, then carefully remove the connector from the camera.

## 7. MAINTENANCE

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a soft, dry cloth to wipe the adapter. Do not use liquid cleaners or solvents.

- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and connector for any signs of wear, cuts, or bends.

## 8. TROUBLESHOOTING







Problem	Possible Cause	Solution
Adapter not providing power/charging.	No power from outlet.	Test outlet with another device.
	Loose connection.	Ensure all connections are secure.
	Damaged adapter/cable.	Inspect adapter for damage; discontinue use if damaged.
	Camera issue.	Consult your camera's manual for troubleshooting power issues.
Adapter gets unusually hot.	Overload or internal fault.	Unplug immediately. Discontinue use.
	Poor ventilation.	Ensure adapter is in a well-ventilated area.

## 9. SPECIFICATIONS

Brand	Generic
Compatible Devices	Vivitar ViviCam X30, X60, 4000 Cameras
Input Voltage	AC 110V-220V
Output Voltage	5 Volts (DC)
Connector Type	Proprietary
Main Power Connector Type	2 Pin (US Standard)
Special Feature	Travel (Wide International Voltages Input)
Manufacturer	DPDUSA

## 10. WARRANTY AND SUPPORT

As a generic compatible replacement product, warranty and support are typically provided by the seller. Please refer to your purchase documentation or contact the seller directly for information regarding warranty coverage, returns, or technical assistance.

	<p><a href="#">Vivitar Product Guide 2004: Cameras, Lenses, Flashes, Binoculars &amp; More</a></p> <p>A comprehensive 2004 product catalog from Vivitar, detailing a wide array of photography equipment including digital cameras, SLR cameras, lenses, flash units, binoculars, tripods, projectors, and accessories.</p>
	<p><a href="#">ViviCam X020 Digital Camera User Manual - Vivitar</a></p> <p>User manual for the Vivitar ViviCam X020 digital camera, covering setup, operation, features, technical specifications, and troubleshooting. Learn how to capture photos and videos with your Vivitar camera.</p>
	<p><a href="#">ViviCam S524 Digital Camera User's Manual</a></p> <p>User's manual for the Vivitar ViviCam S524 digital camera, covering setup, operation, features, technical specifications, and troubleshooting.</p>
	<p><a href="#">ViviCam S524 Digital Camera User's Manual</a></p> <p>Comprehensive user manual for the Vivitar ViviCam S524 Digital Camera, detailing setup, operation, features, technical specifications, and troubleshooting. Learn to capture photos and videos, manage files, and utilize the Vivitar Experience™ Image Manager software.</p>
	<p><a href="#">ViviCam T125 Digital Camera User Manual</a></p> <p>User manual for the Vivitar ViviCam T125 digital camera, covering setup, operation, modes, menus, technical specifications, and troubleshooting.</p>
	<p><a href="#">Vivitar ViviCam F128 Digital Camera User Manual - Setup, Features, and Operation</a></p> <p>Comprehensive user manual for the Vivitar ViviCam F128 digital camera. Learn about setup, camera modes, technical specifications, and how to capture and manage photos and videos.</p>