Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Linq /
- › Linq MK1338 2.4 GHz Wireless Keyboard and Mouse Kit User Manual

Linq MK1338

Linq MK1338 2.4 GHz Wireless Keyboard and Mouse Kit User Manual

Model: MK1338 | Brand: Ling

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Linq MK1338 2.4 GHz Wireless Keyboard and Mouse Kit. Please read this manual carefully before using the product to ensure optimal performance and longevity.



Image 1: Linq MK1338 Wireless Keyboard and Mouse Kit. This image displays the black wireless keyboard and mouse, along with their product packaging, highlighting the 2.4 GHz wireless technology and 10m operating range.

2. PACKAGE CONTENTS

- 1 x Linq MK1338 Wireless Keyboard
- 1 x Linq MK1338 Wireless Mouse
- 1 x USB Receiver (typically stored inside the mouse battery compartment)
- 1 x User Manual (this document)

3. SETUP INSTRUCTIONS

1. Install Batteries:

- **Keyboard:** Open the battery compartment on the underside of the keyboard. Insert two (2) AAA alkaline batteries, ensuring correct polarity (+/-). Close the compartment.
- Mouse: Open the battery compartment on the underside of the mouse. Insert two (2) AAA alkaline batteries, ensuring correct polarity (+/-). The USB receiver is typically stored in this compartment; remove it before inserting batteries. Close the compartment.

2. Connect USB Receiver:

Plug the USB receiver into an available USB port on your computer. The system will automatically detect and install the necessary drivers. This process may take a few moments.

3. Automatic Connection:

The keyboard and mouse are designed for automatic connection. Once the batteries are installed and the USB receiver is plugged in, the devices should connect wirelessly to your computer. No manual pairing is typically required.

4. OPERATING INSTRUCTIONS

4.1 Keyboard Operation

- **Typing:** Use the keyboard as a standard input device for text and commands.
- Silent Keys: The keyboard features silent keys for a comfortable and quiet typing experience.
- **Power Off Key:** The keyboard includes a dedicated key to comfortably power off your computer. Refer to your operating system's settings for specific power management configurations.

4.2 Mouse Operation

- Movement: Move the mouse on a flat surface to control the cursor on your screen.
- Buttons: The mouse features standard left-click, right-click, and scroll wheel functionality.
- **Power Saving:** The mouse is equipped with an automatic power-saving feature. It will enter a low-power state after a period of inactivity. Move the mouse or click a button to wake it up.
- Resolution: The mouse operates at a resolution of 1200 DPI, providing precise cursor control.

4.3 Wireless Range

The Linq MK1338 kit operates wirelessly with an effective range of up to 10 meters (approximately 33 feet) from the USB receiver. Performance may vary depending on environmental factors and obstacles.

5. MAINTENANCE

Cleaning:

To clean the keyboard and mouse, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or submerging the devices in liquid.

• Battery Replacement:

When the devices stop responding or exhibit intermittent connectivity, it is likely time to replace the batteries. Follow the battery installation steps in Section 3.1. Always use new AAA alkaline batteries for optimal performance.

Storage:

When not in use for extended periods, remove the batteries from both the keyboard and mouse to prevent leakage and potential damage. Store the USB receiver in the mouse's battery compartment to prevent loss.

6. TROUBLESHOOTING

• Devices Not Responding:

- Ensure batteries are correctly installed and not depleted. Replace if necessary.
- Verify the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- Ensure the devices are within the 10-meter operating range of the receiver.
- · Restart your computer.

• Intermittent Connection:

- Move the keyboard and mouse closer to the USB receiver.
- Avoid placing the receiver near other wireless devices (e.g., Wi-Fi routers, cordless phones)
 that may cause interference.
- Ensure there are no large metal objects between the devices and the receiver.

• Mouse Cursor Jumps or is Inaccurate:

- Clean the optical sensor on the underside of the mouse.
- Use the mouse on a clean, non-reflective, and uniform surface.


7. SPECIFICATIONS

Model	MK1338
Brand	Linq
Connectivity	2.4 GHz Wireless
Operating Distance	Up to 10 meters
Mouse Resolution	1200 DPI
Mouse Sensor Speed	4800 times/second
Power Supply (Keyboard)	2 x AAA Alkaline Batteries (not included)
Power Supply (Mouse)	2 x AAA Alkaline Batteries (not included)
USB Receiver Power	5V DC (via USB port)

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Linq website. Keep your proof of purchase for any warranty claims.

© 2023 Linq. All rights reserved.



options.