

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [LGM](#) /

> [LGM AC Adapter User Manual for Innotek ADV-1000P, ADV-1000, ADV-1002, ADV-300P Trainer Devices](#)

LGM AC Adapter (Compatible with Innotek ADV-1000P, ADV-1000, ADV-1002, ADV-300P)

LGM AC Adapter User Manual

For Innotek ADV-1000P, ADV-1000, ADV-1002, ADV-300P Trainer Devices

1. INTRODUCTION

Thank you for choosing the LGM AC Adapter. This adapter is designed to provide reliable power to your Innotek ADV-1000P, ADV-1000, ADV-1002, and ADV-300P trainer devices. It converts standard AC wall power into the DC power required by your device, allowing for operation or battery charging. This manual provides important information regarding the safe and effective use of your LGM AC Adapter.

2. SAFETY INFORMATION

- **Read all instructions:** Before using the adapter, read and understand all safety and operating instructions.
- **Indoor use only:** This adapter is intended for indoor use in dry locations only. Do not expose to rain, moisture, or extreme temperatures.
- **Proper voltage:** Ensure the wall outlet voltage matches the input voltage range specified on the adapter (100V-240V AC).
- **Avoid damage:** Do not use the adapter if the cord or plug is damaged. Do not attempt to open or modify the adapter.
- **Keep away from children:** Store the adapter out of reach of children.
- **Unplug when not in use:** Disconnect the adapter from the power outlet when not in use for extended periods.
- **Ventilation:** Ensure adequate ventilation around the adapter during use to prevent overheating.

3. PACKAGE CONTENTS

Verify that your package contains the following item:

- 1 x LGM AC Adapter with integrated power cable

4. SETUP

Follow these steps to set up your LGM AC Adapter:

1. **Inspect the adapter:** Before connecting, visually inspect the adapter and its cable for any signs of damage.
2. **Connect to device:** Plug the barrel connector end of the LGM AC Adapter into the power input port of your Innotek ADV-1000P, ADV-1000, ADV-1002, or ADV-300P trainer device. Ensure a secure connection.
3. **Connect to power outlet:** Plug the 2-pin AC plug of the adapter into a standard 100V-240V AC wall power outlet.



Figure 1: LGM AC Adapter showing the barrel connector and cord length.



Figure 2: LGM AC Adapter connected to a power strip, ready for use.

5. OPERATING INSTRUCTIONS

Once the LGM AC Adapter is properly connected to both your device and a power outlet, your Innotek trainer device should receive power. The adapter is designed for continuous operation, providing a stable power source for your device or charging its internal battery if applicable.

- **Powering your device:** The adapter will supply power to your device as soon as it is plugged into a live electrical outlet and connected to the device.
- **Charging:** If your Innotek device has a rechargeable battery, the adapter will initiate charging when connected. Refer to your Innotek device's manual for specific charging indicators.

6. MAINTENANCE

The LGM AC Adapter requires minimal maintenance to ensure long-term performance:

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme

temperatures. Avoid tightly winding the cable to prevent damage.

- **Cable care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable.

7. TROUBLESHOOTING

If you encounter issues with your LGM AC Adapter, refer to the following common solutions:

- **No power to device:**
 - Ensure the adapter is securely plugged into a working wall outlet. Test the outlet with another device.
 - Verify that the barrel connector is fully inserted into your Innotek device's power port.
 - Check the adapter cable for any visible damage (cuts, kinks). If damaged, discontinue use.
- **Adapter feels hot:**
 - It is normal for power adapters to feel warm during operation. However, if it is excessively hot to the touch, unplug it immediately.
 - Ensure the adapter is not covered or placed in an enclosed space, allowing for proper ventilation.

If these steps do not resolve the issue, please contact customer support.

8. SPECIFICATIONS



Figure 3: Front view of the LGM AC Adapter with specifications label.

Feature	Specification
Brand	LGM
Compatible Devices	Innotek ADV-1000P, ADV-1000, ADV-1002, ADV-300P Trainer Devices
Input Voltage	100V-240V AC
Current Rating	1 Amps
Connector Type	Barrel Connector
Main Power Connector Type	2 Pin (US Standard)
Special Feature	Travel-friendly design
ASIN	B015PUS5DS

9. WARRANTY AND SUPPORT

LGM AC Adapters are tested units and designed for reliable performance. This product is typically covered

by a standard return policy, which may vary by retailer. Please refer to your purchase documentation for specific return and warranty details.

For technical assistance or inquiries, please contact the seller or retailer from whom you purchased this product. Provide your product model (LGM AC Adapter) and ASIN (B015PUS5DS) for faster service.