

## Possini Euro Design 8J021

# Possini Euro Design Rivulet 18-inch Flush Mount Ceiling Light Instruction Manual

Model: 8J021

## 1. IMPORTANT SAFETY INFORMATION

---

Please read and understand all instructions before beginning assembly and installation. Failure to do so could lead to fire, electric shock, or other injuries.

- **WARNING:** To avoid electric shock, ensure electricity is turned off at the main circuit breaker box before installation.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
- Consult a qualified electrician if you are unsure about wiring or installation procedures.
- Use only the recommended bulb type and wattage specified in the specifications section.
- Do not install this fixture in wet locations. Suitable for indoor use only.
- Keep combustible materials away from the light fixture when in operation.

## 2. PACKAGE CONTENTS

---

Carefully unpack the fixture and check that all parts are present. Refer to the diagram below for identification.

- A. Mounting Bracket
- B. Fixture Canopy
- C. Inner Drum Shade
- D. Wavy Spun Metal Frame
- E. Glass Diffuser
- F. Finial
- G. Wire Nuts (3)
- H. Mounting Screws (2)
- I. Outlet Box Screws (2)
- J. Bulbs (not included)



Figure 1: Assembled Rivulet Flush Mount Ceiling Light. This image shows the complete light fixture with its antique silver leaf wavy spun metal frame, white drum shade, and glass diffuser, mounted flush against a ceiling.

### 3. PRODUCT SPECIFICATIONS

<b>Brand</b>	Possini Euro Design
<b>Model Number</b>	8J021
<b>Dimensions (Overall)</b>	18" L x 18" W x 7.5" H
<b>Inner Shade Dimensions</b>	15.75" W x 5.75" H
<b>Canopy Width</b>	5.5"
<b>Weight</b>	7.4 lbs
<b>Material</b>	Metal, Glass
<b>Finish</b>	Antique Silver Leaf (Brushed)
<b>Shade Color</b>	White

<b>Light Source Type</b>	Incandescent (compatible with LED)
<b>Number of Light Sources</b>	3
<b>Maximum Wattage</b>	60 Watts per bulb
<b>Bulb Base</b>	E26 (Standard-Medium Base)
<b>Voltage</b>	120 Volts
<b>Installation Type</b>	Flush Mount
<b>Indoor/Outdoor Usage</b>	Indoor



Figure 2: Detailed dimensions of the light fixture, showing an 18-inch width, 7.5-inch height, 5.5-inch canopy, and 15.75-inch inner shade width.

## 4. INSTALLATION INSTRUCTIONS

Before you begin, ensure the power is turned off at the circuit breaker.

### 1. Prepare the Mounting Bracket:

Attach the mounting bracket (A) to the outlet box in the ceiling using the provided outlet box screws (I). Ensure the bracket is securely fastened.

### 2. Make Electrical Connections:

Connect the fixture's wires to the house wires:

- Connect the black wire from the fixture to the black (hot) wire from the outlet box using a wire nut (G).
- Connect the white wire from the fixture to the white (neutral) wire from the outlet box using a wire nut (G).
- Connect the bare copper or green ground wire from the fixture to the green or bare copper ground wire from the outlet box, and to the mounting bracket (A) using a ground screw if available, then secure with a wire nut (G).

Carefully tuck all wires into the outlet box.

### 3. Attach the Fixture Canopy:

Align the fixture canopy (B) with the mounting bracket (A) and secure it using the mounting screws (H). Ensure the canopy is flush against the ceiling.



Figure 3: An angled view of the installed light fixture, showing the antique silver leaf wavy metal frame and the white drum shade. This illustrates the fixture's appearance once mounted.

**4. Install Bulbs:**

Insert three E26 base bulbs (J, not included) into the sockets. Do not exceed the maximum wattage of 60 watts per bulb.

**5. Attach Glass Diffuser and Finial:**

Place the glass diffuser (E) over the inner drum shade (C) and secure it by screwing the finial (F) onto the threaded rod at the center of the fixture. Tighten gently to avoid overtightening.



Figure 4: A close-up view of the central finial, which secures the glass diffuser to the light fixture. This component is crucial for the final assembly step.

#### 6. Restore Power:

Once installation is complete, restore power at the main circuit breaker.

## 5. OPERATING INSTRUCTIONS

---

This light fixture operates via a standard wall switch (not included).

- Ensure the light fixture is properly installed and power is restored.
- Flip the wall switch to the "ON" position to illuminate the fixture.
- Flip the wall switch to the "OFF" position to turn off the fixture.

## 6. MAINTENANCE

---

- **Cleaning:**

Always turn off the power and allow the fixture to cool before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.

- **Bulb Replacement:**

Turn off the power at the circuit breaker. Allow bulbs to cool completely. Unscrew the finial (F) and carefully remove the glass diffuser (E). Unscrew the old bulbs and replace them with new E26 base bulbs, not exceeding 60 watts each. Reattach the glass diffuser and finial.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	<ul style="list-style-type: none"><li>• Power is off at the circuit breaker.</li><li>• Loose wire connections.</li><li>• Defective bulb(s).</li></ul>	<ul style="list-style-type: none"><li>• Check the circuit breaker and turn it on.</li><li>• Turn off power, check all wire connections.</li><li>• Replace bulb(s).</li></ul>
Flickering light.	<ul style="list-style-type: none"><li>• Loose bulb.</li><li>• Incorrect bulb type/wattage.</li><li>• Loose wire connection.</li></ul>	<ul style="list-style-type: none"><li>• Tighten bulb(s).</li><li>• Ensure bulbs meet specifications.</li><li>• Turn off power, check wire connections.</li></ul>
Fixture hums.	<ul style="list-style-type: none"><li>• Incompatible dimmer switch (if applicable).</li><li>• Loose wiring.</li></ul>	<ul style="list-style-type: none"><li>• Ensure dimmer switch is compatible with bulb type.</li><li>• Turn off power, check wire connections.</li></ul>

## 8. WARRANTY AND SUPPORT

This Possini Euro Design product is manufactured with quality materials and craftsmanship. For specific warranty details and customer support, please refer to the documentation included with your purchase or visit the official Possini Euro Design website.

**Manufacturer:** Lamps Plus



Figure 5: The official logo for the Possini Euro Design Collection.