

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Troy Lighting](#) /
- › [Troy Lighting B5311 Transitional One Light Wall Sconce Instruction Manual](#)

## Troy Lighting B5311

# Troy Lighting B5311 Transitional One Light Wall Sconce Instruction Manual

Model: B5311

## 1. PRODUCT OVERVIEW

---

The Troy Lighting B5311 is a transitional one-light wall sconce from the Equilibrium collection, featuring a textured bronze finish. This fixture is designed for indoor use and provides ambient lighting.





Image 1.1: Front view of the Troy Lighting B5311 Wall Sconce, showcasing its textured bronze finish and glass shade.





Image 1.2: Angled view of the Troy Lighting B5311 Wall Sconce, highlighting the design and proportions.

## 2. SAFETY INFORMATION

---

- Always turn off the electrical power at the main fuse or circuit breaker box before beginning installation.
- Consult a qualified electrician if you are unsure about the installation process.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).

- Use only the specified bulb type and wattage to avoid overheating or damage.
- Do not install this fixture in wet or damp locations. It is designed for dry, indoor use only.
- Handle glass components with care to prevent breakage.

### 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not attempt to assemble or install the fixture.

- Wall Sconce Fixture (Model B5311)
- Glass Shade
- Mounting Hardware (Crossbar, mounting screws, wire nuts)
- Instruction Manual

### 4. INSTALLATION

---

Follow these steps carefully for proper installation of your wall sconce.

1. **Turn Off Power:** Before starting, ensure the power to the junction box is turned off at the circuit breaker or fuse box.
2. **Prepare Mounting:** Attach the mounting crossbar to the junction box using the provided mounting screws. Ensure the crossbar is securely fastened.
3. **Wire Connections:** Connect the fixture's wires to the corresponding house wires. Connect the black (hot) fixture wire to the black (hot) house wire, the white (neutral) fixture wire to the white (neutral) house wire, and the green or bare copper (ground) fixture wire to the green or bare copper (ground) house wire. Secure connections with wire nuts and wrap with electrical tape for added safety.
4. **Mount Fixture:** Carefully tuck the wires into the junction box. Align the fixture's backplate with the mounting screws on the crossbar and secure the fixture in place with the decorative nuts or screws.
5. **Install Bulb:** Insert one (1) 60-watt maximum incandescent or equivalent LED bulb into the socket. (Bulb not included).
6. **Attach Glass Shade:** Carefully place the glass shade onto the fixture according to the design. Ensure it is stable and secure.
7. **Restore Power:** Once installation is complete and all components are secure, restore power at the circuit breaker.

### 5. OPERATION

---

The Troy Lighting B5311 wall sconce operates via a standard wall switch connected to the electrical circuit. Simply toggle the wall switch to turn the light fixture on or off.

### 6. MAINTENANCE

---

- **Cleaning:** To clean the fixture, turn off the power and allow it to cool. Wipe with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.
- **Bulb Replacement:** Ensure power is off and the bulb has cooled before replacing. Unscrew the old bulb and screw in a new one of the same type and wattage (max 60W).

- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

## 7. TROUBLESHOOTING

If your wall sconce is not functioning correctly, refer to the following table for common issues and solutions.

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture	Check circuit breaker or fuse. Ensure wall switch is on.
Light bulb is faulty	Bulb has burned out or is not properly seated	Replace bulb with a new one. Ensure bulb is screwed in tightly.
Loose wire connections	Wires are not securely connected	Turn off power, then check and tighten all wire connections.
Fixture flickers	Loose bulb or wiring	Turn off power, check bulb seating and wire connections.

If the problem persists after attempting these solutions, contact a qualified electrician or Troy Lighting customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Troy Lighting
Model Number	B5311
Style	Transitional
Finish	Textured Bronze
Material	Metal, Glass
Shade Color	Plated Topaz
Number of Lights	1
Wattage	60 watts (max)
Voltage	120 Volts
Power Source	Corded Electric
Product Dimensions	10.25 x 5 x 28.5 inches (L x W x H)
Item Weight	10 Pounds
Mounting Type	Wall Mount

## 9. WARRANTY AND SUPPORT

---

This Troy Lighting B5311 wall sconce comes with a **1-year limited manufacturer warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or inquiries regarding your product, please contact Troy Lighting customer service directly. Keep your proof of purchase for warranty validation.

For further assistance, please refer to the official Troy Lighting website or contact their customer support channels.