



Manuals.plus /

› GPO /

› GPO Bermuda Classic Turntable USB User Manual

## GPO Bermuda Classic

# GPO Bermuda Classic Turntable USB User Manual

Model: Bermuda Classic

## 1. INTRODUCTION

---

Thank you for purchasing the GPO Bermuda Classic Turntable USB. This manual provides essential information for the safe and correct operation of your new record player. Please read it thoroughly before use and retain it for future reference.

## 2. PACKAGE CONTENTS

---

Carefully unpack all items and ensure you have received the following:

- GPO Bermuda Classic Turntable Unit
- Removable Legs (4 pieces)
- 45-RPM Adaptor
- USB Stick
- Power Adaptor
- User Manual (this document)

## 3. PRODUCT FEATURES

---

The GPO Bermuda Classic Turntable USB combines vintage aesthetics with modern functionality. Key features include:

- **Bluetooth Connectivity:** Stream music wirelessly from your compatible devices.
- **USB Recording:** Convert your vinyl records directly to digital MP3 files via USB.
- **Multi-Speed Playback:** Supports 33, 45, and 78 RPM records.
- **Built-in Stereo Speakers:** Enjoy audio directly from the unit.
- **Auto-Stop / Auto-Return:** Automatically stops playback and returns the tone arm at the end of a record.
- **Removable Legs:** Allows for versatile placement as a standalone unit or tabletop player.
- **AUX-in Jack:** Connect external audio sources.

- **RCA Line Out:** Connect to external amplifiers or powered speakers.
- **Headphone Output:** For private listening.

## 4. SETUP

---

### 4.1 Attaching the Legs

If you wish to use the turntable as a freestanding unit, attach the four removable legs to the designated sockets on the underside of the unit. Ensure they are securely tightened.



Image: The GPO Bermuda Classic Turntable shown with its four removable legs attached, illustrating the overall dimensions of the unit (34cm width, 38cm depth, 21cm height for the unit, 44cm for the legs, total height 64cm).

## 4.2 Power Connection

Connect the provided power adaptor to the **9V-DC-IN** port on the rear of the turntable and then plug it into a wall outlet. The unit will power on when connected.

## 4.3 Audio Connections (Optional)

**External Speakers:** To connect to an external amplifier or powered speakers, use RCA cables (not included) to connect the **LINE OUT** ports on the rear of the turntable to the corresponding input on your audio system.

**Headphones:** For private listening, plug 3.5mm headphones into the **EAR OUT** jack on the rear panel.




Image: A detailed view of the rear connection panel, showing the 9V-DC-IN power input, LINE OUT (RCA) ports for external audio, and the EAR OUT (headphone) jack.

## 5. OPERATING INSTRUCTIONS

### 5.1 Basic Record Playback

1. Open the lid of the turntable.
2. Place a record on the platter. For 7-inch singles with a large center hole, use the 45-RPM adaptor.
3. Select the appropriate speed (33, 45, or 78 RPM) using the speed selector switch located near the tone arm base.
4. Release the tone arm from its rest by gently pushing the arm locking clip to the side.
5. Use the tone arm lever to raise the tone arm.
6. Carefully position the stylus over the desired starting groove of the record.
7. Lower the tone arm gently onto the record using the tone arm lever. Playback will begin.
8. Adjust the volume using the control knob on the front panel.
9. At the end of the record, the auto-stop feature will stop the platter rotation. Use the tone arm lever to raise the arm and return it to its rest, then secure it with the arm locking clip.



Image: The GPO Bermuda Classic Turntable with its lid open, revealing the record platter, tone arm, and stylus, ready for record playback.




Image: A close-up view of the tone arm mechanism, highlighting the arm locking clip, the tone arm lever for raising and lowering the arm, and the switch for selecting playback speeds (33, 45, 78 RPM).

## 5.2 Bluetooth Pairing

1. Ensure the turntable is powered on.
2. Press the 'BT' button on the control panel to switch to Bluetooth mode. The Bluetooth indicator light will flash.
3. On your Bluetooth-enabled device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select 'GPO Bermuda' from the list of devices.
5. Once paired, the Bluetooth indicator light on the turntable will stop flashing and remain solid. You can now stream audio from your device to the turntable's speakers.

## 5.3 USB Recording

The GPO Bermuda allows you to record your vinyl records directly to a USB stick as MP3 files.

1. Insert the provided USB stick into the **USB** port on the control panel.
2. Place a record on the platter and prepare it for playback as described in section 5.1.

3. Press the 'REC' button on the control panel. The recording indicator light will illuminate.
4. Start playing your record. The turntable will begin recording the audio to the USB stick.
5. To stop recording, press the 'REC' button again. The recording indicator light will turn off.
6. To delete the last recorded track, press the 'DEL' button.



Device or Vinyl >>>> USB



Device or USB >>>> Speakers

Image: A detailed view of the control panel, featuring the AUX IN jack, REC (record) button, AUX mode button, USB/BT (Bluetooth) indicator lights, LP indicator, USB port, and playback control buttons (previous, play/pause, next, REC, DEL).

## 5.4 AUX-in Function

Connect an external audio device (e.g., MP3 player, smartphone) to the **AUX IN** jack on the control panel using a 3.5mm audio cable (not included). Press the 'AUX' button to switch to AUX input mode. Audio from the connected device will play through the turntable's speakers.

## 6. MAINTENANCE

## 6.1 Cleaning the Unit

Wipe the turntable's exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.

## 6.2 Stylus Care

The stylus (needle) is a delicate component. Handle it with care. Clean the stylus periodically using a soft brush designed for stylus cleaning, brushing gently from back to front. A worn or damaged stylus can harm your records and degrade sound quality. Replace the stylus when necessary.




Image: A magnified view of the turntable's stylus, highlighting its robust construction as it rests on a vinyl record groove.

## 7. TROUBLESHOOTING

If you encounter issues with your GPO Bermuda Classic Turntable, please refer to the following common problems and solutions:

- **No Power:**
  - Ensure the power adaptor is securely connected to the unit and a working wall outlet.
  - Check if the wall outlet is functioning correctly.
- **No Sound:**
  - Check the volume level on the turntable and any connected external audio system.
  - Ensure the correct input source (Phono, Bluetooth, AUX) is selected.
  - If using external speakers, verify connections to the LINE OUT ports.
  - Ensure the stylus guard is removed and the stylus is properly seated.
- **Skipping or Distorted Sound:**
  - Ensure the record is clean and free of dust or debris.
  - Check the stylus for damage or wear; replace if necessary.
  - Ensure the turntable is placed on a stable, level surface.
  - Clean the stylus gently.
- **Bluetooth Not Connecting:**
  - Ensure the turntable is in Bluetooth mode (BT indicator flashing).
  - Make sure your device's Bluetooth is enabled and within range.
  - Try unpairing and re-pairing the device.
  - Ensure no other devices are currently connected to the turntable via Bluetooth.
- **USB Recording Not Working:**
  - Ensure the USB stick is properly inserted.
  - Check if the USB stick has sufficient free space.
  - Ensure the 'REC' button was pressed to start recording.

## 8. SPECIFICATIONS

<b>Model Name</b>	Bermuda Classic
<b>Item Model Number</b>	GPO Bermuda Blue
<b>Brand</b>	GPO
<b>Product Dimensions</b>	15.04 x 14.49 x 8.46 inches (38.2 x 36.8 x 21.5 cm)
<b>Item Weight</b>	19.84 Pounds (9 Kilograms)
<b>Material</b>	Plastic
<b>Playback Speeds</b>	33, 45, 78 RPM
<b>Special Features</b>	Removable Legs, USB Recording, Bluetooth, Auto-Stop / Auto-Return, Built-In Speakers
<b>Included Components</b>	45-RPM adaptor, USB stick
<b>Motor Type</b>	DC Motor
<b>Power Consumption</b>	5 Watts

