

Transcend Prime X-SDC4/64GB

Transcend 64GB microSDHC Memory Card with SD Adapter User Manual

Model: Prime X-SDC4/64GB

1. PRODUCT OVERVIEW

This manual provides instructions for the Transcend 64GB microSDHC Memory Card with SD Adapter. This product is designed to expand the storage capacity of compatible electronic devices, such as camcorders, digital cameras, and other devices that support microSDHC cards.

The package includes one 64GB microSDHC memory card and one SD card adapter, allowing the microSDHC card to be used in devices with a standard SD card slot.



Image 1.1: The Transcend 64GB microSDHC memory card (red and black) shown next to its black SD adapter. The microSDHC card is small, while the adapter is larger, resembling a standard SD card.

2. SETUP AND INSTALLATION

Follow these steps to properly install your Transcend microSDHC memory card:

- 1. Identify the Card Slot:** Locate the memory card slot on your device (e.g., camcorder, camera, smartphone, tablet). This slot may be for a microSD card or a standard SD card.
- 2. For microSD Slot:** If your device has a microSD card slot, gently insert the 64GB microSDHC card directly into the slot with the gold contacts facing down (or as indicated by your device's manual) until it clicks into place.

3. **For Standard SD Slot (Using Adapter):** If your device has a standard SD card slot, first insert the 64GB microSDHC card into the provided SD adapter. Ensure the microSD card is fully seated in the adapter. Then, insert the adapter with the microSD card into your device's standard SD card slot with the gold contacts facing down (or as indicated by your device's manual) until it clicks into place.
4. **Formatting (Optional but Recommended):** For optimal performance and compatibility, it is often recommended to format the memory card using your device's internal formatting function before first use. Refer to your device's user manual for specific instructions on how to format a memory card.
Note: Formatting will erase all data on the card.

3. OPERATING INSTRUCTIONS

Once installed and formatted, the Transcend 64GB microSDHC card functions as an extended storage medium for your device.

- **Saving Data:** When recording videos, taking photos, or saving files, your device will automatically detect the memory card and use it for storage, provided it is set as the default storage location.
- **Accessing Data:** You can access files stored on the card directly through your device's file manager, gallery, or playback functions.
- **Transferring Data to Computer:**
 - **Via Device:** Connect your device (with the card inserted) to a computer using a USB cable. The card will appear as a removable drive.
 - **Via Card Reader:** Remove the microSDHC card (or the SD adapter with the microSDHC card) from your device and insert it into a compatible card reader connected to your computer. The card will appear as a removable drive.
- **Safe Removal:** Always ensure that your device is powered off or that the "Safely Remove Hardware" option (on computers) is used before physically removing the memory card to prevent data corruption.

4. MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your memory card, follow these guidelines:

- **Handle with Care:** Avoid bending, dropping, or applying excessive force to the card.
- **Keep Clean:** Do not touch the gold contacts on the card. If necessary, gently wipe the contacts with a clean, dry, lint-free cloth.
- **Storage:** Store the card in its protective case or a suitable storage solution when not in use to protect it from dust, moisture, and static electricity.
- **Temperature:** Avoid exposing the card to extreme temperatures (very hot or very cold) or direct sunlight for prolonged periods.
- **Water Resistance:** The card is designed to be water-resistant. However, prolonged submersion or exposure to corrosive liquids should be avoided. Ensure the card is completely dry before inserting it into any electronic device.
- **Backup Data:** Regularly back up important data from the memory card to another storage device (e.g., computer hard drive, cloud storage) to prevent data loss.

5. TROUBLESHOOTING

If you encounter issues with your Transcend memory card, consider the following common solutions:

Problem	Possible Solution
Card not detected by device.	<p>Ensure the card is fully and correctly inserted into the slot.</p> <p>If using the SD adapter, ensure the microSD card is fully seated in the adapter.</p> <p>Check if the device supports microSDHC cards of 64GB capacity.</p> <p>Try the card in another compatible device or a computer with a card reader to rule out device issues.</p> <p>Clean the gold contacts on the card with a dry, lint-free cloth.</p>
Cannot write or delete files.	<p>Check if the SD adapter's write-protect switch is in the "unlocked" position. The small switch on the side of the SD adapter should be slid upwards, away from the "Lock" position.</p> <p>Ensure the card is not full. Delete unnecessary files or transfer them to another storage.</p> <p>The card might be corrupted. Try formatting the card <i>(Note: This will erase all data)</i>.</p>
Slow data transfer speeds.	<p>Ensure your device or card reader supports the card's speed class (e.g., Class 10).</p> <p>Avoid running multiple applications during data transfer.</p> <p>The card might be fragmented. Back up data and then format the card.</p>
Data corruption or errors.	<p>Always safely remove the card from devices or computers.</p> <p>Avoid sudden power loss during read/write operations.</p> <p>If issues persist, the card may be faulty. Contact Transcend support.</p>

6. SPECIFICATIONS

Feature	Detail
Model Number	Prime X-SDC4/64GB
Capacity	64 GB
Flash Memory Type	Micro SDHC
Hardware Interface	microSDHC
Compatible Devices	Camera, Camcorders, Smartphones, Tablets, etc. (devices supporting microSDHC)
Special Feature	Water Proof
Product Dimensions	2 x 2 x 2 inches (approximate, for packaging/adapter)
Item Weight	0.13 Pounds / 2.08 ounces (approximate, for packaging/adapter)
Manufacturer	Transcend
UPC	724327596014

7. WARRANTY AND SUPPORT

Transcend products are manufactured to the highest standards and undergo rigorous testing. This product is covered by Transcend's limited warranty, which protects against defects in material and workmanship under normal use.


For detailed warranty terms, product registration, technical support, or service inquiries, please visit the official Transcend website or contact their customer support directly. Keep your proof of purchase for warranty claims.

Transcend Official Website: www.transcend-info.com

© 2024 Transcend. All rights reserved.

Related Documents - Prime X-SDC4/64GB

	<p><u>Raspberry Pi SD Cards: High-Performance A2 microSD Cards</u></p> <p>Explore the specifications and safety guidelines for Raspberry Pi's high-quality A2 microSD cards, available in 32GB, 64GB, and 128GB variants for optimal performance with Raspberry Pi computers.</p>
	<p><u>SanDisk SD Card OEM Product Manual - Technical Specifications and Features</u></p> <p>Comprehensive OEM product manual for SanDisk SD Cards, detailing technical specifications, interface descriptions, protocol details, power requirements, physical dimensions, and ordering information.</p>
	<p><u>User Manual: Range Tour Car Dash Cam - Operation and Specifications</u></p> <p>Comprehensive user manual for the Range Tour Car Dash Cam, covering precautions, operation instructions, motion detection, parking monitor, G-sensor, emergency file locking, PC connection, menu settings, troubleshooting, and detailed specifications. Includes a list of included accessories.</p>




[ASUS PRIME A620M-A Motherboard Quick Start Guide](#)

Concise guide to installing and setting up the ASUS PRIME A620M-A motherboard, including CPU, memory, storage, and system connections.



[Understanding microSD and SD Cards: Speeds, Markings, and More](#)

A comprehensive guide to understanding microSD and SD cards, covering their speeds, markings, classes, capacities, and how to choose the right card for various devices like cameras, smartphones, and Raspberry Pi.



[ASUS PRIME H610M-K ARGB Motherboard Quick Start Guide](#)

This guide provides step-by-step instructions for installing the ASUS PRIME H610M-K ARGB motherboard, including CPU, fan, memory modules, storage devices, and expansion cards, as well as connecting system panel and power connectors, and input/output devices.