

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LG](#) /

› [LG Electronics 34UB88-P 34-inch UltraWide WQHD IPS Monitor User Manual](#)

## LG 34UB88-P

# LG Electronics 34UB88-P 34-inch UltraWide WQHD IPS Monitor User Manual

Model: 34UB88-P

## INTRODUCTION

---

This user manual provides essential information for the safe and efficient use of your LG Electronics 34UB88-P 34-inch UltraWide WQHD IPS Monitor. Please read this manual thoroughly before operating the product and retain it for future reference.

## IMPORTANT SAFETY INFORMATION

---

- Always disconnect the power cord from the wall outlet before cleaning the product.
- Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
- Do not place the product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the product.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the product has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

## SETUP GUIDE

---

### 1. Unpacking and Contents

Carefully remove all components from the packaging. Ensure all items listed below are present:

- LG 34UB88-P 34-inch LED LCD Monitor
- Power Cord

- HDMI Cable (may vary by region)
- DisplayPort Cable (may vary by region)
- USB Upstream Cable (may vary by region)
- Stand Base and Neck
- Documentation (Quick Setup Guide, Warranty Card)

## 2. Assembling the Stand

Follow these steps to attach the stand to your monitor:

1. Place the monitor face down on a soft, clean cloth to prevent scratches.
2. Attach the stand neck to the monitor panel. Ensure it clicks securely into place.
3. Attach the stand base to the stand neck and tighten the screw located at the bottom of the base.

**Note:** The monitor also supports VESA standard mount interface (100 x 100 mm) for wall mounting or alternative stand options. Refer to the separate mounting instructions if using a VESA mount.

## 3. Connecting the Monitor

Connect the monitor to your computer and power source using the appropriate cables.

- **Power Connection:** Connect the power cord to the monitor's power input and then to a wall outlet.
- **Video Connection:**
  - **HDMI:** Connect an HDMI cable from your computer's HDMI output to the monitor's HDMI input.
  - **DisplayPort:** Connect a DisplayPort cable from your computer's DisplayPort output to the monitor's DisplayPort input.
  - **Thunderbolt:** For compatible devices, use a Thunderbolt cable to connect to the monitor's Thunderbolt port.
- **USB Connection:** Connect the USB upstream cable from your computer to the monitor's USB upstream port to enable the monitor's USB 3.0 ports.



Image: LG 34UB88-P monitor showing its overall dimensions. The monitor measures approximately 16.9 inches in height, 9.9 inches in depth (including the stand), and 32.7 inches in width.

## OPERATING INSTRUCTIONS

---

### 1. Powering On/Off

Press the power button, usually located on the bottom center or right side of the monitor, to turn the monitor on or off. The power indicator light will illuminate when the monitor is on.

### 2. On-Screen Display (OSD) Menu

The monitor features an intuitive OSD menu for adjusting various settings. Access the OSD menu by pressing the joystick button (often located on the bottom center of the monitor). Navigate through the menu using the joystick to adjust settings such as:

- **Picture:** Brightness, Contrast, Sharpness, Gamma, Color Temperature.
- **Color:** Adjust color modes, sRGB settings. This monitor supports sRGB over 99% for accurate color reproduction.
- **Input:** Select input source (HDMI, DisplayPort, Thunderbolt).

- **General:** Language, OSD Lock, Power LED settings.

### 3. Display Settings

For optimal viewing, ensure your computer's display settings are configured correctly:

- **Resolution:** Set the resolution to **3440 x 1440 (WQHD)** for the sharpest image.
- **Refresh Rate:** The recommended refresh rate is 60Hz. Some users may experience issues at other refresh rates.
- **Aspect Ratio:** The monitor's native aspect ratio is 2.39:1.

## MAINTENANCE

---

### 1. Cleaning the Monitor

To clean the monitor screen and cabinet:

- Always unplug the monitor from the power outlet before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a mild, non-abrasive screen cleaner.
- Do not spray cleaner directly onto the screen or cabinet.
- Wipe gently to avoid scratching the screen surface.

### 2. General Care

- Avoid placing heavy objects on the monitor or its cables.
- Do not expose the monitor to direct sunlight, high temperatures, or high humidity.
- Keep the monitor away from sources of strong electromagnetic fields.

## TROUBLESHOOTING

---

If you encounter issues with your monitor, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No Power	Ensure the power cord is securely connected to the monitor and the wall outlet. Check if the power outlet is functioning correctly.
No Signal / Blank Screen	Verify that the video cable (HDMI, DisplayPort, Thunderbolt) is securely connected to both the monitor and the computer. Select the correct input source using the OSD menu. Ensure your computer is powered on and not in sleep mode.
Image is Choppy or Distorted	Ensure your computer's display resolution is set to 3440 x 1440. Check the refresh rate setting on your computer. The monitor is designed for 60Hz. Some users have reported issues with 50Hz or other non-standard refresh rates. Try a different video cable.
Power Indicator Blinks Continuously	This may indicate the monitor is in a power-saving mode or not receiving a signal. Check video connections and computer status. Refer to the full LG support documentation for specific power LED behavior.

If the problem persists after trying these solutions, please contact LG customer support.

## SPECIFICATIONS

---

Model Name	34UB88-P
Screen Size	34 inches
Panel Type	IPS
Resolution	3440 x 1440 (WQHD)
Aspect Ratio	2.39:1
Contrast Ratio (DFC)	Mega (1,000:1)
Color Gamut	sRGB over 99%
Connectors	HDMI, DisplayPort, USB 3.0, Thunderbolt
Mounting Type	VESA standard mount interface 100 x 100 mm
Product Dimensions (LxWxH)	39 x 20.6 x 8.1 inches (with stand)
Item Weight	13.89 pounds (with stand)
Manufacturer	LG Electronics
Color	Black

## WARRANTY AND SUPPORT

---

### Warranty Information

For detailed warranty information, please refer to the warranty card included with your product or visit the official LG Electronics website. Warranty terms and conditions may vary by region and purchase date.

### Customer Support

If you require technical assistance, have questions about your product, or need to arrange service, please contact LG Electronics customer support. Contact details can typically be found on the LG website or in the documentation provided with your monitor.

**Online Support:** Visit the official LG Electronics website for FAQs, driver downloads, and support resources.

**Telephone Support:** Refer to your regional LG website for local contact numbers.