

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Medeli](#) /
- › [Medeli DD315 7-Pad Electronic Drum Kit User Manual](#)

## Medeli DD315

# Medeli DD315 7-Pad Electronic Drum Kit User Manual

Model: DD315

## INTRODUCTION

The Medeli DD315 is a portable electronic drum kit designed for practice, study, and creative pattern creation. It features 7 velocity-sensitive pads and 2 pedals, offering a comprehensive drumming experience in a compact form factor. With a wide array of sounds and pre-set kits, along with versatile connectivity options, the DD315 is suitable for musicians of all levels.



## SETUP

---

Follow these steps to set up your Medeli DD315 electronic drum kit:

1. **Power Connection:** Connect the included power adapter to the DC IN jack on the unit and then to a standard electrical outlet. Alternatively, for maximum portability, the DD315 can be powered by batteries (not included).
2. **Pedal Connection:** Connect the two included pedals to their respective jacks on the unit. One pedal is typically for the bass drum and the other for the hi-hat.
3. **Headphones/External Speaker (Optional):** For private practice, connect headphones to the HEADPHONE output jack. To connect to an external amplifier or speaker system, use the appropriate audio output.
4. **External Device (Optional):** To play along with your favorite music, connect an external device such as an MP3 player or smartphone to the AUX IN jack using a stereo audio cable.
5. **USB-MIDI Connection (Optional):** For advanced use with computer software (DAW), connect a USB cable from the USB-MIDI port on the DD315 to your PC or Mac.
6. **Positioning:** Place the DD315 on a stable, flat surface. Ensure there is enough space to comfortably use the pads and pedals.

## OPERATING INSTRUCTIONS

---

The Medeli DD315 offers a variety of functions for drumming and music creation:

### Basic Operation

- **Power On/Off:** Press the POWER button to turn the unit on or off.
- **Volume Control:** Use the MASTER VOLUME knob to adjust the overall output volume.
- **Playing Pads:** Strike the 7 velocity-sensitive pads with the included drumsticks to produce sounds. The sound produced will vary based on the selected drum kit.
- **Using Pedals:** Press the bass drum pedal for kick sounds and the hi-hat pedal to control the hi-hat sound (open/closed).

### Drum Kits and Sounds

- **Selecting Drum Kits:** The DD315 comes with 45 preset drum kits and allows for 5 user-defined drum kits. Use the dedicated buttons or navigation controls to browse and select different kits.
- **Accessing Sounds:** There are 265 individual sounds available. These sounds are assigned to the pads within each drum kit. Refer to the sound list in the appendix (if available in full manual) for details.

### Songs and Recording

- **Playing Preset Songs:** The unit includes 100 preset songs. Use the SONG selection buttons to choose a song and the PLAY/STOP button to start or stop playback.
- **Recording Function:** The DD315 features a recording function, allowing you to capture your performances. Consult the detailed instructions in the full manual for recording procedures.

### Practice Tools

- **Metronome Function:** Activate the metronome to practice with a steady tempo. Adjust the tempo using the dedicated controls.

- **Hand Percussion Mode:** This mode allows for perfect response when using hands instead of drumsticks, ideal for practicing hand percussion techniques.

## Connectivity

- **USB-MIDI Output:** Connect the DD315 to a PC or Mac via USB-MIDI to expand the range of available sounds using your favorite DAW software or to use the DD315 as a MIDI controller.
- **AUX Input:** Use the AUX IN to connect external audio devices like MP3 players or smartphones, allowing you to play along with your favorite tracks through the DD315's speakers or connected headphones.
- **Headphone Output:** Connect standard stereo headphones for silent practice.

## Maintenance

Proper care and maintenance will ensure the longevity of your Medeli DD315:

- **Cleaning:** Use a soft, dry cloth to wipe down the unit. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the unit. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, store the DD315 in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Handle the unit with care. Avoid dropping it or subjecting it to strong impacts.
- **Power:** Disconnect the power adapter when the unit is not in use for extended periods. If using batteries, remove them if the unit will not be used for a long time to prevent leakage.

## Troubleshooting

If you encounter issues with your Medeli DD315, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power adapter not connected properly; Batteries drained or incorrectly inserted.	Ensure power adapter is securely connected to the unit and outlet. Check battery orientation and replace if necessary.
No sound	Volume too low; Headphones/speakers not connected; Incorrect output selected.	Increase MASTER VOLUME. Ensure headphones or external speakers are properly connected. Check if the correct output (e.g., headphone, line out) is being used.
Pads not responding	Pad sensitivity setting; Damaged pad.	Check the pad sensitivity settings (refer to full manual). If a specific pad is consistently unresponsive, contact customer support.
Pedals not working	Pedals not connected properly; Pedal malfunction.	Ensure pedals are fully inserted into their respective jacks. Test with another pedal if available, or contact support.
Distorted sound	Volume too high; Faulty cable; External device issue.	Lower the MASTER VOLUME. Try a different audio cable. Check the volume and output of any connected external devices.

## Specifications

- **Pads:** 7 Velocity Sensitive Pads

- **Pedals:** 2 (for Bass Drum and Hi-Hat)
- **Drum Kits:** 45 Preset Drum Kits, 5 User Drum Kits
- **Sounds:** 265
- **Songs:** 100 Preset Songs
- **Functions:** Recording, Metronome, Hand Percussion Mode
- **Connectivity:** USB-MIDI Out, Headphone Out, AUX In
- **Power:** AC Adapter (included), Battery operation (batteries not included)
- **Dimensions (L x W x H):** 500 mm x 370 mm x 157.4 mm (19.7 in x 14.6 in x 6.2 in)
- **Weight:** 3.3 kg (7.3 lbs)
- **Included Accessories:** Drumsticks, Power Adapter

## WARRANTY AND SUPPORT




For warranty information and technical support, please refer to the warranty card included with your product or visit the official Medeli website. Keep your proof of purchase for any warranty claims.




For further assistance, you may contact Medeli customer service through their official channels. Please have your product model number (DD315) and serial number ready when contacting support.



© 2023 Medeli. All rights reserved.

## Related Documents - DD315

	<p><a href="#">Medeli MZ538 Electronic Drum Kit: Setup and Assembly Guide</a></p> <p>Detailed setup and assembly instructions for the Medeli MZ538 electronic drum kit. Includes packing list, component identification, step-by-step assembly, and adjustment procedures for optimal performance.</p>
<p><b>DIGITAL DRUM</b></p> <p><a href="#">Instruction Manual</a></p> 	<p><a href="#">Medeli DD502 Digital Drum Module Instruction Manual</a></p> <p>Comprehensive instruction manual for the Medeli DD502 Digital Drum Module, covering setup, functions, care, specifications, and MIDI implementation.</p>
	<p><a href="#">MEDELI TP110 Digital Drum Owner's Manual</a></p> <p>Comprehensive owner's manual for the MEDELI TP110 Digital Drum, covering safety, setup, features, operation, coach modes, sound settings, troubleshooting, and specifications.</p>

 <p>Instruction Manual <b>DIGITAL DRUM</b></p>	<p><a href="#">Medeli DD-602 Digital Drum Module Instruction Manual</a></p> <p>Official instruction manual for the Medeli DD-602 Digital Drum Module. Learn about setup, operation, features, and maintenance for this versatile electronic drum instrument.</p>
 <p><b>Digital Drum</b> Owner's Manual</p>	<p><a href="#">Medeli DD309G Digital Drum Owner's Manual - Setup, Operation, and Features</a></p> <p>Explore the Medeli DD309G Digital Drum with this comprehensive owner's manual. Learn about its 310 sounds, 120 songs, advanced features like Learning Mode and MIDI connectivity, and troubleshooting tips.</p>
	<p><a href="#">Medeli MZ537 Electronic Drum Kit Setup Guide</a></p> <p>Step-by-step instructions and packing list for setting up the Medeli MZ537 electronic drum kit, including assembly of the drum stand, pads, module, and accessories.</p>