

SYSKA LB300

Syska LB300 Bluetooth Headset User Manual

By SYSKA

Introduction

This manual provides comprehensive instructions for the operation, maintenance, and troubleshooting of your Syska LB300 Bluetooth Headset. Designed for seamless connectivity, the LB300 offers multi-point connection, allowing you to pair with two different mobile phones simultaneously, delivering clear audio for calls and music.

Package Contents

Please verify that all items listed below are included in your package:

- Syska LB300 Bluetooth Headset
- Ear Gel
- User Manual (this document)
- Warranty Card
- Ear Hooks

Product Overview

Familiarize yourself with the components and design of your Syska LB300 Bluetooth Headset.



Figure 1: Side view of the Syska LB300 Bluetooth Headset, showcasing its sleek design and the transparent ear hook for secure fit. The main control button is visible on the side.



Figure 2: Top-down view of the Syska LB300 Bluetooth Headset, highlighting its compact and lightweight form factor. The earpiece is designed for in-ear comfort.



Figure 3: Front view of the Syska LB300 Bluetooth Headset, showing the earpiece and the main body. The SYSKA ACCESSORIES logo is visible on the side.

Setup

Charging the Headset

Before first use, fully charge your Syska LB300 headset. Connect the charging cable (not included, typically a micro-USB) to the headset's charging port and the other end to a USB power source. The indicator light will show charging status and turn off or change color when fully charged. A full charge provides up to 4 hours of talk time or play time.

Initial Pairing (Connecting to a Device)

1. Ensure the headset is turned off.
2. Press and hold the Multi-function Button (MFB) on the headset until the indicator light flashes red and blue alternately. This indicates pairing mode.
3. On your mobile phone or Bluetooth-enabled device, enable Bluetooth and search for new devices.
4. Select "Syska LB300" from the list of available devices.
5. If prompted for a password, enter "0000" (four zeros).
6. Once successfully paired, the indicator light will flash blue slowly, and you may hear a confirmation

tone.

Multi-Point Connection

The Syska LB300 supports connecting to two mobile phones simultaneously. Follow these steps:

1. Pair the headset with the first phone as described in "Initial Pairing".
2. Disable Bluetooth on the first phone.
3. Put the headset back into pairing mode (red and blue flashing).
4. Pair the headset with the second phone.
5. Once the second phone is paired, re-enable Bluetooth on the first phone. The headset should automatically connect to both phones.
6. To switch between phones for calls, simply answer the incoming call on the desired phone.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the MFB for approximately 3 seconds until the blue indicator light flashes.
- **Power Off:** Press and hold the MFB for approximately 5 seconds until the red indicator light flashes and then turns off.

Call Management

- **Answer Call:** Press the MFB once when an incoming call rings.
- **End Call:** Press the MFB once during a call.
- **Reject Call:** Press and hold the MFB for approximately 2 seconds when an incoming call rings.
- **Redial Last Number:** Double-press the MFB when the headset is idle.

Music Playback

- **Play/Pause:** Press the MFB once during music playback.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.

Volume Control

- **Increase Volume:** Press the Volume Up button.
- **Decrease Volume:** Press the Volume Down button.

Maintenance

Proper care ensures the longevity and optimal performance of your headset.

- **Cleaning:** Use a soft, dry cloth to wipe the headset. Do not use harsh chemicals, cleaning solvents, or strong detergents.
- **Storage:** When not in use, store the headset in a cool, dry place, away from extreme temperatures and direct sunlight.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in constant use.
- **Water Exposure:** This headset is not waterproof. Avoid exposure to water or excessive moisture.

Troubleshooting

If you encounter issues with your Syska LB300 headset, refer to the following common problems and solutions:

Problem	Possible Solution
Headset does not power on.	Ensure the headset is charged. Connect it to a power source and try again.
Cannot pair with device.	<ul style="list-style-type: none">◦ Ensure the headset is in pairing mode (red and blue flashing).◦ Make sure Bluetooth is enabled on your device.◦ Move the headset closer to your device (within 10 meters).◦ Clear previous Bluetooth connections on your device and try pairing again.◦ Restart both the headset and your device.
No sound or low volume.	<ul style="list-style-type: none">◦ Increase the volume on both the headset and your connected device.◦ Ensure the headset is properly connected to your device.◦ Check if the audio output is set to the Bluetooth headset on your device.
Poor call quality or intermittent connection.	<ul style="list-style-type: none">◦ Move closer to your connected device.◦ Avoid obstacles between the headset and device (e.g., walls, large metal objects).◦ Minimize interference from other wireless devices.◦ Ensure the headset is fully charged.

Specifications

Key technical specifications for the Syska LB300 Bluetooth Headset:

Feature	Detail
Model Name	LB300
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	V4.1+EDR
Wireless Range	Up to 10 meters (33 feet)
Talk Time	Up to 4 hours
Play Time	Up to 4 hours
Chipset	ISSC2008
Item Weight	6 grams
Product Dimensions (LxWxH)	1.2 x 2.1 x 5.7 cm
Control Method	Touch (referring to button presses)

Feature	Detail
Form Factor	In Ear
Special Features	Lightweight, Multi-point connection

Warranty and Support

Your Syska LB300 Bluetooth Headset comes with a **1-year warranty** from the date of purchase. Please retain your purchase receipt and the warranty card included in the package for any warranty claims. For technical support, service, or further inquiries, please refer to the contact information provided on your warranty card or visit the official SYSKA website. Do not attempt to disassemble or repair the headset yourself, as this may void the warranty.