

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [ANNOVI REVERBERI](#) /
- › [ANNOVI REVERBERI 588 AR Cold Water Pressure Washer User Manual](#)

## ANNOVI REVERBERI 588 AR

# ANNOVI REVERBERI 588 AR Cold Water Pressure Washer User Manual

Model: 588 AR

## INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your ANNOVI REVERBERI 588 AR Cold Water Pressure Washer. Please read this manual thoroughly before using the appliance.

## SAFETY INFORMATION

### General Safety Rules

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and hearing protection.
- Do not direct the water jet at people, animals, electrical equipment, or the appliance itself.
- Ensure the power supply matches the specifications on the product label.
- Never operate the pressure washer with damaged cords or hoses.
- Keep children and pets away from the operating area.
- Disconnect from power supply before performing any maintenance or cleaning.

### Electrical Safety

- Use only grounded outlets.
- Do not use extension cords unless absolutely necessary and ensure they are rated for outdoor use and the appliance's power requirements.
- Avoid operating the pressure washer in wet conditions or standing in water.

## PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- ANNOVI REVERBERI 588 AR Pressure Washer Unit
- High-Pressure Hose (8 meters)

- Spray Gun
- Turbo Nozzle
- Detergent Tank (1.2 liters capacity)
- Water Filter
- User Manual

## PRODUCT OVERVIEW

Familiarize yourself with the components of your pressure washer.



Figure 1: ANNOVI REVERBERI 588 AR Cold Water Pressure Washer. This image shows the complete blue and grey pressure washer unit with its integrated hose reel, handle, wheels, and front panel controls.

## Key Components

- **Hose Reel:** For convenient storage and deployment of the high-pressure hose.
- **Handle:** Ergonomic handle for easy transport.
- **Wheels:** Two robust wheels for mobility.
- **Power Switch:** On/Off control for the unit.

- **Water Inlet:** Connection point for the garden hose.
- **High-Pressure Outlet:** Connection point for the high-pressure hose.
- **Detergent Tank:** Integrated tank for cleaning solutions.
- **Pressure Gauge:** Displays current operating pressure.

## SETUP

1. **Unpacking:** Carefully remove all components from the packaging.
2. **Assembly:**
  - Attach the handle to the main unit if it's not pre-assembled.
  - Ensure the wheels are securely in place.
3. **Water Connection:**
  - Connect a garden hose to the water inlet of the pressure washer. Ensure the water filter is in place.
  - Connect the other end of the garden hose to a water tap and turn on the water supply fully.
4. **High-Pressure Hose Connection:**
  - Connect one end of the high-pressure hose to the high-pressure outlet on the unit.
  - Connect the other end of the high-pressure hose to the spray gun.
5. **Electrical Connection:**
  - Plug the power cord into a grounded electrical outlet.
6. **Priming the Pump:**
  - Before turning on the power, squeeze the trigger on the spray gun to allow air to escape and water to flow through the system until a steady stream emerges. This helps to prime the pump and prevent damage.

## OPERATING INSTRUCTIONS

1. **Starting the Unit:**
  - Once primed, turn the power switch to the "ON" position. The motor will start.
  - Allow the motor to run for a few seconds to build pressure.
2. **Using the Spray Gun:**
  - Aim the spray gun at the surface to be cleaned.
  - Squeeze the trigger to activate the high-pressure spray.
  - Release the trigger to stop the spray. The motor may continue to run briefly due to the automatic By-Pass valve.
3. **Using Detergent (if applicable):**
  - Fill the integrated detergent tank with an appropriate pressure washer detergent.
  - The detergent suction system allows for adjustable mixing. Refer to the detergent manufacturer's instructions for dilution.
  - To apply detergent, typically a low-pressure nozzle or the detergent setting on a multi-function nozzle is required.
4. **Using the Turbo Nozzle:**
  - The turbo nozzle provides a rotating jet for powerful cleaning of stubborn dirt.
  - Use with caution on delicate surfaces as it delivers a very concentrated force.

## 5. Shutting Down:

- Turn the power switch to the "OFF" position.
- Turn off the water supply.
- Squeeze the spray gun trigger to release any remaining pressure in the system.
- Disconnect the high-pressure hose and garden hose.
- Unplug the power cord.

## MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your pressure washer.

### After Each Use

- **Clean the Unit:** Wipe down the exterior of the pressure washer with a damp cloth.
- **Flush Detergent System:** If detergent was used, flush the system by running clean water through it for a few minutes.
- **Drain Water:** Ensure all water is drained from the pump, hoses, and spray gun, especially before storing in freezing temperatures.
- **Hose and Cord Storage:** Neatly wind the high-pressure hose onto the integrated reel and coil the power cord.

### Periodic Maintenance

- **Water Filter Cleaning:** Regularly check and clean the water inlet filter to prevent debris from entering the pump.
- **Nozzle Cleaning:** Clear any blockages from the nozzles using the provided nozzle cleaning tool (if included) or a thin wire.
- **Pump Care:** For long-term storage, especially in cold climates, consider using a pump protector solution.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not start	No power supply	Check power cord, outlet, and circuit breaker.
Low pressure	Insufficient water supply	Ensure water tap is fully open; check for kinks in garden hose.
Low pressure	Clogged nozzle	Clean the nozzle.
Motor runs, but no water	Air in the pump	Prime the pump by squeezing the trigger with the unit off and water on until a steady stream emerges.
Water leaks	Loose connections or damaged O-rings	Tighten connections; inspect and replace O-rings if damaged.

## SPECIFICATIONS

**Model:** 588 AR

**Brand:** ANNOVI REVERBERI

**Type:** Cold Water Pressure Washer

**Maximum Pressure:** 150 Bar

**Power:** 2500 W

**Pump:** 3 axial pistons, hardened stainless steel piston, brass pump head

**Detergent Tank Capacity:** 1.2 Liters

**High-Pressure Hose Length:** 8 meters

**Motor Type:** Induction with thermal protection

**Mobility:** Two-wheeled trolley

**ASIN:** B01MU2F4WZ


## WARRANTY AND SUPPORT

For warranty information, technical support, or to order replacement parts, please contact ANNOVI REVERBERI customer service or visit their official website. Keep your purchase receipt as proof of purchase.

**Manufacturer:** ANNOVI REVERBERI

**First Available Date:** January 24, 2021

## Related Documents - 588 AR

	<p><a href="#">Anovi Reverberi ARXP 120 High Pressure Washer User Manual and Safety Guide</a></p> <p>Official user manual for the Anovi Reverberi ARXP 120 high-pressure washer. Includes assembly instructions, operating procedures, safety warnings, technical specifications, and warranty information.</p>
	<p><a href="#">Anovi Reverberi RC Series Plunger Pumps: Operating Instructions and Parts Manual</a></p> <p>Comprehensive operating instructions, parts lists, installation guides, and troubleshooting tips for Anovi Reverberi RC Series Plunger Pumps, including models like RC11.17N, RC13.17N, RCA series, and RCV series.</p>
	<p><a href="#">Anovi Reverberi Product Range Overview</a></p> <p>An overview of the Anovi Reverberi Group's extensive product range, including pumps, control units, and accessories for agriculture, industry, and cleaning applications. Features information on various divisions and global presence.</p>
	<p><a href="#">BLACK+DECKER BXPW1800XE High Pressure Washer User Manual</a></p> <p>Official user manual for the BLACK+DECKER BXPW1800XE high pressure washer, providing essential safety instructions, operating guidelines, and maintenance information.</p>

 <p>ARXP BOX4 180DSS</p> 	<p><b><a href="#">ARXP BOX4 180DSS High Pressure Washer User Manual</a></b></p> <p>Comprehensive user manual for the ARXP BOX4 180DSS high-pressure washer by ARXP. This guide details safety, operation, installation, maintenance, troubleshooting, and technical specifications for effective and safe use.</p>
 <p>STANLEY</p> 	<p><b><a href="#">STANLEY High Pressure Washer SXPW14E SXPW14PE SXPW16E SXPW16PE User Manual</a></b></p> <p>User manual for STANLEY high pressure washers (models SXPW14E, SXPW14PE, SXPW16E, SXPW16PE) including safety instructions, assembly, operation, maintenance, troubleshooting, technical data, and warranty information.</p>