

[Manuals.plus](#) /

> [Pocketman](#) /

> Pocketman Mini 3 Modes Cree Q5 7W 300lm LED Flashlight Torch User Manual

## Pocketman B01N02OSAF

# Pocketman Mini LED Flashlight Torch User Manual

Model: B01N02OSAF

## 1. INTRODUCTION

---

This manual provides essential instructions for the safe and effective use of your Pocketman Mini LED Flashlight Torch. Please read this manual thoroughly before operating the device and retain it for future reference. This product is designed for general illumination and emergency use, featuring a compact design, multiple lighting modes, and durable construction.



**Image 1.1:** The Pocketman Mini LED Flashlight Torch, shown individually and as a 10-pack. These compact flashlights are designed for portability and versatile use.

## 2. PRODUCT FEATURES

---

- **Compact Design:** Super mini size for easy portability.
- **LED Technology:** Utilizes a Cree Q5 LED for efficient illumination.
- **Durable Construction:** Made from robust aluminum alloy casing.
- **Adjustable Focus:** Zoom in or out to adjust the beam from a spotlight to a floodlight.
- **Multiple Lighting Modes:** Features High, Low, and Strobe modes.
- **Water Resistant:** Designed to withstand splashes and light rain.
- **Skid-Proof Design:** Textured surface for a secure grip.
- **Convenient Clip:** Integrated steel body clip for attaching to pockets or belts.
- **Power Source:** Compatible with one 14500 3.7V battery or one AA battery (batteries not included).



**Image 2.1:** The Pocketman Mini LED Flashlight shown held in a hand and clipped to a pocket, demonstrating its compact size and portability.

### 3. PACKAGE CONTENTS

---

Your package should contain the following items:

- Pocketman Mini LED Flashlight Torch (Quantity as per purchase, e.g., 10 units for a 10-pack)

*Note: Batteries are not included and must be purchased separately.*

### 4. SETUP

---

#### 4.1 Battery Installation

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert one AA battery or one 14500 3.7V rechargeable battery into the battery compartment. Ensure the positive (+) end of the battery faces towards the head of the flashlight (towards the LED).
3. Screw the tail cap back on clockwise until it is securely tightened.

**Caution: Incorrect battery polarity can damage the flashlight. Always ensure the battery is inserted with the correct orientation.**



**Image 4.1:** An exploded view of the flashlight, illustrating its main components including the battery compartment (located within the main body, accessible by removing the tail cap) and the LED lampwick.

## 5. OPERATION

---

### 5.1 Power On/Off

To turn the flashlight on or off, firmly press the push-button switch located on the tail cap.

### 5.2 Mode Selection

With the flashlight turned on, lightly press the push-button switch (without fully clicking it off) to cycle through the three available lighting modes:

1. **High:** Maximum brightness output.
2. **Low:** Reduced brightness for extended battery life.
3. **Strobe:** Flashing light for signaling or emergency situations.

A full click of the switch will turn the flashlight off. When turned back on, it will typically resume the last used mode.

### 5.3 Focus Adjustment

The flashlight features an adjustable focus beam. To change the beam width:

- **Zoom In (Spotlight):** Gently pull the head of the flashlight forward to narrow the beam, creating a focused spotlight.
- **Zoom Out (Floodlight):** Push the head of the flashlight backward to widen the beam, creating a broad floodlight.



**Image 5.1:** The Pocketman Mini LED Flashlight demonstrating its zoomable head, allowing users to adjust the beam from a narrow spotlight to a wide floodlight.



**Image 5.2:** The Pocketman Mini LED Flashlight in operation, emitting a bright, clear beam of light.

## 6. MAINTENANCE

---

### 6.1 Cleaning

- Wipe the exterior of the flashlight with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as these can damage the finish or internal components.
- Keep the lens clean for optimal light output. Use a lens cleaning cloth if necessary.

## 6.2 Storage

- If the flashlight will not be used for an extended period, remove the battery to prevent leakage and potential damage.
- Store the flashlight in a cool, dry place, away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on	<ul style="list-style-type: none"><li>• Incorrect battery installation</li><li>• Dead or low battery</li><li>• Loose tail cap</li></ul>	<ul style="list-style-type: none"><li>• Check battery polarity and reinsert correctly</li><li>• Replace with a fresh battery</li><li>• Ensure tail cap is fully tightened</li></ul>
Light is dim or flickers	<ul style="list-style-type: none"><li>• Low battery power</li><li>• Dirty battery contacts</li><li>• Incorrect battery type (e.g., using a standard AA when 14500 is preferred for brightness)</li></ul>	<ul style="list-style-type: none"><li>• Replace battery</li><li>• Clean battery contacts with a clean cloth</li><li>• Ensure correct battery type is used for desired brightness</li></ul>
Mode cycling issues	<ul style="list-style-type: none"><li>• Switch not fully pressed</li><li>• Switch malfunction</li></ul>	<ul style="list-style-type: none"><li>• Ensure firm, light presses for mode changes</li><li>• If persistent, contact customer support</li></ul>

## 8. SPECIFICATIONS

Feature	Specification
Model Number	B01N02OSAF
Light Source	Cree Q5 LED
Brightness	Up to 300 Lumens
Power Source	1 x AA Battery OR 1 x 14500 3.7V Battery (not included)
Lighting Modes	High, Low, Strobe
Material	Durable Aluminum Alloy

Feature	Specification
Special Features	Adjustable Focus, Skid-proof, Water Resistant
Product Dimensions	Approximately 1.2"D x 1.2"W x 3.7"H
Item Weight	Approximately 1.28 ounces per flashlight (12.8 ounces for 10-pack)
UPC	732240709886

## 9. WARRANTY AND SUPPORT

---

For any questions, concerns, or support regarding your Pocketman Mini LED Flashlight Torch, please refer to your purchase documentation or contact the retailer/manufacturer directly. Specific warranty details may vary based on your region and point of purchase.

Always ensure you are purchasing from authorized sellers to guarantee product authenticity and access to customer support.