

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Continental Edison](#) /
- › [Continental Edison CEBL15IX6 Blender User Manual](#)

Continental Edison CEBL15IX6

Continental Edison CEBL15IX6 Blender User Manual

Model: CEBL15IX6

[Introduction](#) [Components](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)
[Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the Continental Edison CEBL15IX6 Blender. This manual provides important information regarding the safe use, operation, and maintenance of your appliance. Please read it thoroughly before first use and keep it for future reference.

1.1 Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions.

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids. Clean with a damp cloth only.
- Always unplug the blender from the power outlet before assembling, disassembling, or cleaning.
- Avoid contact with moving parts. Keep hands and utensils out of the blending jar while blending to prevent severe injury and/or damage to the blender.
- The blades are sharp. Handle with extreme care when cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Ensure the lid is securely locked in place before operating the appliance.
- Do not blend hot liquids without proper ventilation, as pressure buildup can cause the lid to eject and result in burns.
- Do not use attachments not recommended or sold by the manufacturer.

2. COMPONENTS IDENTIFICATION

Familiarize yourself with the parts of your Continental Edison CEBL15IX6 Blender:

- **Motor Base:** Contains the motor and control panel.
- **Glass Blending Jar (1.5L):** The main container for ingredients.
- **Blade Assembly:** Integrated into the bottom of the blending jar.
- **Lid:** Covers the blending jar during operation.
- **Filler Cap:** Small removable cap in the lid for adding ingredients during blending.



Image: Continental Edison CEBL15IX6 Blender showing the motor base, glass blending jar, and lid. This illustrates the main components of the appliance.

3. SETUP AND ASSEMBLY

Before first use, wash all parts that will come into contact with food. Ensure the blender is unplugged from the power outlet during assembly.

1. **Unpack:** Carefully remove all components from the packaging.

2. **Clean:** Wash the glass blending jar, lid, and filler cap in warm, soapy water. Rinse thoroughly and dry. The glass jar is dishwasher safe.
3. **Assemble Jar:** Ensure the blade assembly is securely attached to the bottom of the glass blending jar.
4. **Place Jar on Base:** Place the assembled blending jar onto the motor base. Ensure it is seated correctly and locked into position (if applicable to your model, some models have a locking mechanism).
5. **Secure Lid:** Place the lid onto the blending jar and ensure it is securely fitted. Insert the filler cap into the lid opening.
6. **Position:** Place the blender on a stable, flat, and dry surface.

4. OPERATING INSTRUCTIONS

Follow these steps for safe and effective blending:

1. **Prepare Ingredients:** Cut solid ingredients into small pieces (approximately 2-3 cm) to facilitate blending. Add liquids first, then soft ingredients, and finally harder ingredients or ice. Do not overfill the jar; ensure the liquid level does not exceed the maximum fill line.
2. **Secure Lid:** Place the lid firmly on the blending jar and insert the filler cap.
3. **Plug In:** Connect the power cord to a suitable electrical outlet (220 Volts).
4. **Select Speed:** Turn the control dial to the desired speed setting. Start with a low speed and gradually increase if needed. For short bursts of power, use the pulse function (if available).
5. **Blend:** Allow the blender to operate until the desired consistency is achieved. Do not operate continuously for more than 60 seconds to prevent overheating. If blending for longer, allow a short break between cycles.
6. **Add Ingredients During Blending:** If necessary, remove the filler cap and add small ingredients while the blender is running. Never remove the main lid during operation.
7. **Finish:** Once blending is complete, turn the control dial to the "OFF" position.
8. **Unplug:** Always unplug the blender from the power outlet before removing the jar or pouring contents.

4.1 Tips for Best Results

- For crushing ice, use the pulse function in short bursts.
- When blending thick mixtures, use a tamper (if provided, or stop and stir with a spatula) to push ingredients towards the blades. Never use your fingers.
- Avoid blending extremely hot liquids. If blending warm liquids, ensure the filler cap is slightly ajar to allow steam to escape and prevent pressure buildup.

5. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your blender.

1. **Unplug:** Always ensure the blender is unplugged before cleaning.
2. **Disassemble:** Remove the blending jar from the motor base. Carefully detach the lid and filler cap.
3. **Clean Jar and Lid:**
 - **Quick Clean:** For light cleaning, fill the jar halfway with warm water and a drop of dish soap. Secure the lid and run the blender on low speed for a few seconds. Rinse thoroughly.
 - **Deep Clean:** Wash the glass blending jar, lid, and filler cap in warm, soapy water. Rinse thoroughly. The glass jar and lid are dishwasher safe. Handle the blade assembly with extreme care due to sharp edges.

4. **Clean Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid. Do not use abrasive cleaners or scouring pads.
5. **Dry:** Ensure all parts are completely dry before reassembling or storing.
6. **Storage:** Store the blender in a clean, dry place, away from direct sunlight and out of reach of children.

6. TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Not plugged in; Jar not correctly seated; Overload protection activated.	Ensure power cord is securely plugged in. Check if the blending jar is correctly placed and locked onto the motor base. Unplug, wait 15 minutes for the motor to cool, then try again with fewer ingredients.
Ingredients are not blending smoothly.	Too little liquid; Too many ingredients; Ingredients are too large.	Add more liquid. Reduce the amount of ingredients. Cut ingredients into smaller pieces. Use the pulse function.
Lid comes off during blending (especially with hot liquids).	Pressure buildup from hot liquids; Lid not securely fastened.	Ensure the lid is securely fastened. When blending warm liquids, remove the filler cap to allow steam to escape. Do not blend extremely hot liquids.
Burning smell from motor.	Overheating due to continuous operation or overload.	Turn off and unplug the blender immediately. Allow it to cool down for at least 30 minutes. Reduce load and blending time. If the smell persists, contact customer support.

7. SPECIFICATIONS

Technical details for the Continental Edison CEBL15IX6 Blender:

- **Model:** CEBL15IX6
- **Brand:** Continental Edison
- **Capacity:** 1.5 Liters (Glass Jar)
- **Power:** 600 Watts
- **Voltage:** 220 Volts
- **Material:** Metal, Glass
- **Weight:** Approximately 3.58 kg (7.89 lbs)
- **Dishwasher Safe Parts:** Glass Jar, Lid
- **Recommended Uses:** Blending, Pureeing, Crushing

8. WARRANTY AND SUPPORT

Continental Edison products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Continental Edison website. Keep your proof of purchase for any warranty claims.

For technical support, spare parts, or service inquiries, please contact Continental Edison customer service. Contact details can typically be found on the manufacturer's website or in the product packaging.