

Manuals.plus /

- › Digipartspower /
- › Digipartspower AC DC Adapter for GGMM M4 WS-401 Speaker - User Manual

Digipartspower B071GQ4RZP

Digipartspower AC DC Adapter for GGMM M4 WS-401 Speaker - User Manual

Model: B071GQ4RZP

Introduction

This manual provides instructions for the safe and efficient use of your Digipartspower AC DC Adapter, model B071GQ4RZP. This adapter is specifically designed to provide power to the GGMM M4 WS-401 Portable Wireless Speaker System. It ensures reliable power delivery with built-in safety features to protect your devices.

Setup

Follow these steps to properly set up your AC DC adapter:

1. **Unpack the Adapter:** Carefully remove the adapter and its cables from the packaging. Inspect for any visible damage.
2. **Connect to Speaker:** Locate the power input port on your GGMM M4 WS-401 Portable Wireless Speaker System. Insert the round connector of the adapter's output cable firmly into this port.
3. **Connect to Power Outlet:** Plug the AC input cable (the cable with the two-prong plug) into a standard 120V AC wall outlet. Ensure the outlet is easily accessible.
4. **Verify Connection:** Once connected, the speaker should indicate that it is receiving power or charging, typically via an LED indicator.



Figure 1: The Digipartpower AC DC Adapter with its connected cables, ready for use.

Operating Instructions

The Digipartpower AC DC Adapter is designed for straightforward operation:

- **Powering On:** After connecting the adapter to both the speaker and a power outlet, the speaker should automatically begin to receive power or charge its internal battery. Refer to your GGMM M4 WS-401 speaker's manual for specific power-on procedures.
- **Safety Features:** This adapter includes multiple protection features:
 - **Over Current Protection (OCP):** Prevents damage from excessive current flow.
 - **Over Voltage Protection (OVP):** Safeguards against voltage surges.
 - **Over Temperature Protection (OTP):** Protects against overheating.
 - **Short Circuit Protection (SCP):** Prevents damage from short circuits.
- **Usage Environment:** Use the adapter in a dry, well-ventilated area. Avoid exposing it to moisture, extreme temperatures, or direct sunlight.



Figure 2: Compact design of the adapter, highlighting its portability.

Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the speaker before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly winding the cables to prevent damage. The included cable strap can assist with neat storage.
- **Cable Care:** Regularly inspect the cables for any signs of fraying, cuts, or damage. Do not use the adapter if the cables are damaged. Avoid bending the cables sharply or placing heavy objects on them.

Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker not receiving power/charging.	Adapter not properly connected. Power outlet not active. Damaged adapter or cable.	Ensure all connections are secure. Test the power outlet with another device. Inspect adapter and cables for damage; replace if necessary.
Adapter feels unusually hot.	Poor ventilation. Overload or internal fault.	Ensure the adapter is in a well-ventilated area. Disconnect immediately and contact support if overheating persists or is extreme.
Intermittent power supply.	Loose connection. Cable damage.	Check all connections. Inspect cables for damage; replace adapter if cables are faulty.

Specifications

Brand	Digipartspower
Model Number (ASIN)	B071GQ4RZP
Compatible Devices	GGMM M4 WS-401 Portable Wireless Speaker System
Connector Type	Round
Input Voltage	120 Volts (AC)
Cable Length	3 Feet
Item Weight	9 Ounces
Color	Black
Special Features	Over Current Protection, Over Voltage Protection, Over Temperature Protection, Short Circuit Protection, Portable, Travel-friendly
Power Source	Corded Electric
UPC	753038278988

Warranty Information

This Digipartspower AC DC Adapter comes with a **3-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product performs as described under normal use. Please retain your proof of purchase for warranty claims.

For warranty service or to report a defect, please contact Digipartspower customer support with your purchase details.

Support

If you require further assistance or have questions not covered in this manual, please contact Digipartspower customer support. Refer to the contact information provided with your product packaging or visit the official Digipartspower website for support options.

Note: Always ensure you are using the correct adapter for your device to prevent damage.