

RASTAR 47600

RASTAR 1:14 RC Mercedes-Benz SLS AMG Model Car Instruction Manual

1. INTRODUCTION

Thank you for purchasing the RASTAR 1:14 RC Mercedes-Benz SLS AMG Model Car. This manual provides essential information for the safe and optimal use of your remote control car. Please read it thoroughly before operating the product and retain it for future reference.

2. SAFETY INFORMATION

Choking Hazard - Small Parts: This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended during operation.

- Do not operate the vehicle near people, pets, or obstacles.
- Avoid operating in wet conditions or on public roads.
- Ensure batteries are inserted with correct polarity.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries from the vehicle and remote control when not in use for extended periods.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x 1/14 Rastar Mercedes remote controlled car
- 1 x Dual-grip remote-controller
- 1 x User guide



Figure 3.1: RASTAR 1:14 RC Mercedes-Benz SLS AMG Model Car and Remote Control.

4. SETUP

4.1 Battery Installation (Vehicle)

1. Locate the battery compartment on the underside of the car.
2. Use a small screwdriver (not included) to open the battery compartment cover.
3. Insert 5 x AA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the cover and secure it with the screw.



Mercedes-Benz



Figure 4.1: Underside of the RASTAR RC car with battery compartment.

4.2 Battery Installation (Remote Control)

1. Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover.
3. Insert 1 x 9V battery (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the cover.

4.3 Pairing the Remote Control and Vehicle

1. Turn on the vehicle using the ON/OFF switch located on its underside.
2. Turn on the remote control. The indicator light on the remote will flash.
3. Once the indicator light on the remote control becomes solid, the pairing is complete.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

- **Forward:** Pull the trigger on the remote control towards you.
- **Reverse:** Push the trigger on the remote control away from you.
- **Stop:** Release the trigger to its neutral position.
- **Left/Right:** Turn the steering wheel on the side of the remote control left or right.

5.2 Driving Surfaces

The RASTAR RC car performs best on flat, smooth surfaces. It can be used both indoors and outdoors. Avoid rough terrain, water, or sand to prevent damage.

5.3 Special Features

- **Gull-wing Doors:** The car features manually opening gull-wing doors for realistic play.
- **LED Lights:** LED headlamps and taillights illuminate when the car moves forward and reverses, enhancing realism.
- **Suspension System:** Equipped with shock absorption in the front wheels and a differential mechanism in the rear wheels, along with a 4-wheel independent suspension system for improved handling.



Figure 5.1: RASTAR RC Mercedes-Benz SLS AMG with gull-wing doors open.



Figure 5.2: Detailed interior of the RASTAR RC Mercedes-Benz SLS AMG.

6. MAINTENANCE

- Clean the vehicle regularly with a soft, dry cloth. Do not use water or chemical cleaners.
- Store the vehicle and remote control in a cool, dry place away from direct sunlight.
- Remove all batteries if the product will not be used for an extended period to prevent leakage.

7. TROUBLESHOOTING

- **No Power:** Ensure batteries are correctly installed in both the vehicle and remote control, and that they are not depleted. Check the ON/OFF switches.
- **Poor Control/Interference:** Ensure the vehicle and remote are properly paired. Operate within the specified remote range (up to 98 feet). Avoid areas with strong electromagnetic interference.
- **Vehicle Not Moving Straight:** Check the steering alignment on the underside of the car and adjust if necessary.

8. SPECIFICATIONS

Product Dimensions	13.6 x 5.3 x 5.3 inches
Item Weight	2.63 pounds







Model Number	47600
Scale	1:14
Recommended Age	6 years and up
Vehicle Batteries	5 x AA batteries (not included)
Remote Control Batteries	1 x 9V battery (not included)
Remote Range	Up to 98 feet
Frequency	2.4GHz



Figure 8.1: Dimensions of the RASTAR RC Mercedes-Benz SLS AMG.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official RASTAR website. Keep your purchase receipt as proof of purchase.

	<p>Инструкция по эксплуатации робота RASTAR 77900</p> <p>Полное руководство по использованию игрушечного робота RASTAR 77900. Включает настройку, управление, функции, программирование и меры безопасности.</p>
	<p>RASTAR 2.4GHz Remote Control Car Instructions - Models 92000-96300</p> <p>User manual and operation guide for RASTAR 2.4GHz remote control cars, including setup, features, functions, maintenance, and safety warnings for models 92000, 94500, 94600, 94900, and 96300.</p>
	<p>RASTAR Scuderia Ferrari Racing Ride-On Car Instructions Manual</p> <p>Comprehensive instructions manual for the RASTAR Scuderia Ferrari racing ride-on car (Model 82700), covering assembly, operation, maintenance, safety guidelines, and troubleshooting.</p>
	<p>Rastar LaFerrari Ride-on Instruction Manual</p> <p>This instruction manual provides detailed information on the Rastar LaFerrari ride-on toy car, covering specifications, assembly, operation, maintenance, troubleshooting, and safety warnings for children aged 37-96 months.</p>
	<p>RASTAR 98700 Remote Control Car: Operation Guide and Safety Instructions</p> <p>Detailed instructions for the RASTAR 98700 remote control car, covering setup, operation, maintenance, and important safety precautions for safe and enjoyable play.</p>
	<p>RASTAR 92200 Radio-Controlled Car Instruction Manual</p> <p>Comprehensive instruction manual for the RASTAR 92200 radio-controlled car, covering battery installation, pairing, operation, wheel changes, and safety guidelines.</p>