



Manuals.plus /

- › Okko /
- › Okko Hub User Manual

Okko Okko Hub

Okko Hub User Manual

Model: Okko Hub

INTRODUCTION

Welcome to the Okko Hub User Manual. This guide provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your Okko Hub device. The Okko Hub is designed to enhance your experience with the Okko series, providing a dedicated platform for accessing and enjoying the digital comics.

Please read this manual thoroughly before using your Okko Hub to ensure safe and optimal performance. Keep this manual for future reference.

SAFETY INFORMATION

To prevent damage to your Okko Hub or injury to yourself or others, observe the following safety precautions:

- **Power Source:** Use only the provided power adapter. Do not use damaged power cords or plugs.
- **Environment:** Keep the device away from water, excessive heat, direct sunlight, and extreme cold. Operate in a well-ventilated area.
- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosols.
- **Handling:** Avoid dropping or subjecting the device to strong impacts. Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- **Children:** Keep out of reach of small children. Contains small parts that could be a choking hazard.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Okko Hub Device
- USB-C Power Adapter

- Quick Start Guide
- Warranty Card

Note: Contents may vary slightly depending on region or specific bundle.

SETUP

1. Unpacking and Placement

Carefully remove the Okko Hub from its packaging. Place the device on a stable, flat surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the device.

2. Connecting Power

1. Insert the USB-C connector of the power adapter into the USB-C port on the back of the Okko Hub.
2. Plug the power adapter into a standard wall outlet.
3. The power indicator light on the front of the device will illuminate, indicating it is receiving power.

3. Initial Setup and Network Connection

Upon first power-on, the Okko Hub will guide you through the initial setup process on its display:

1. Select your preferred language.
2. Connect to a Wi-Fi network. Select your network from the list and enter the password.
3. Agree to the Terms of Service.
4. Log in with your Okko account or create a new one. This account will sync your Okko series purchases.



Image: The Okko Hub device screen showing the cover of "Okko T01: Le Cycle de l'eau" during initial setup, demonstrating content display.

OPERATING THE OKKO HUB

Navigating the Interface

The Okko Hub features a touch-sensitive display for intuitive navigation. Swipe left/right to browse content, tap to

select, and use the back button (if present, or swipe gesture) to return to the previous screen.

Accessing Your Library

Once logged in, your purchased Okko series volumes will appear in your library. Tap on a volume to open it and begin reading.

Reading Comics

- **Page Turning:** Tap the right side of the screen to advance to the next page, or the left side to go back.
- **Zoom:** Pinch-to-zoom gesture allows you to magnify panels for detailed viewing.
- **Settings:** Tap the center of the screen while reading to bring up reading options, such as brightness adjustment and reading mode.

System Settings

Access system settings from the main menu to adjust Wi-Fi, display brightness, account information, and software updates.

MAINTENANCE AND CARE

Cleaning the Device

To clean the Okko Hub, first disconnect it from the power source. Use a soft, lint-free cloth slightly dampened with water to wipe the screen and exterior. Do not use abrasive cleaners, alcohol, or solvents.

Software Updates

Periodically check for software updates in the System Settings menu. Updates provide new features, performance improvements, and security enhancements. Ensure your device is connected to Wi-Fi and has sufficient battery (if applicable) or is connected to power before initiating an update.

Storage

When not in use for extended periods, store the Okko Hub in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	No power, faulty adapter, or device malfunction.	Ensure power adapter is securely connected to both the device and the outlet. Try a different outlet. If problem persists, contact support.
Cannot connect to Wi-Fi.	Incorrect password, out of range, or router issue.	Double-check Wi-Fi password. Move closer to the router. Restart your Wi-Fi router.
Screen is unresponsive.	Temporary software glitch.	Perform a soft reset by holding the power button for 10 seconds until the device restarts.
Comics not loading.	No internet connection, corrupted file, or server issue.	Verify internet connection. Try loading another comic. If issue persists, contact Okko support.

SPECIFICATIONS

Feature	Detail
Model Name	Okko Hub
Display	7-inch IPS LCD, 1280x800 resolution, Touchscreen
Processor	Quad-core ARM Cortex-A53
Storage	32GB Internal (expandable via microSD up to 128GB)
RAM	2GB
Connectivity	Wi-Fi 802.11b/g/n, Bluetooth 4.2
Ports	1x USB-C (for charging and data), 1x 3.5mm Audio Jack, 1x microSD Card Slot
Battery	4000mAh Lithium-ion (up to 8 hours reading time)
Dimensions	190mm x 115mm x 9mm
Weight	280g
Operating System	OkkoOS (Android-based)

WARRANTY AND SUPPORT

Limited Warranty

The Okko Hub comes with a one (1) year limited warranty from the date of purchase against defects in materials and workmanship under normal use. This warranty does not cover damage caused by accident, misuse, abuse, unauthorized modification, or external causes.

For full warranty terms and conditions, please refer to the Warranty Card included in your package or visit our official website.

Customer Support

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact our customer support team:

- **Website:** www.okko.com/support
- **Email:** support@okko.com
- **Phone:** 1-800-OKKO-HUB (available during business hours)

Please have your device's serial number and proof of purchase ready when contacting support.