

## SIEMENS TE657503DE

# Siemens EQ.6 plus s700 Automatic Coffee Machine User Manual

Model: TE657503DE | Brand: SIEMENS

[Introduction](#)   [Safety Information](#)   [Product Overview](#)   [Setup](#)   [Operating](#)  
[Instructions](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

Welcome to the user manual for your new Siemens EQ.6 plus s700 Automatic Coffee Machine. This appliance is designed to provide a wide range of coffee and milk specialties with ease and precision. Featuring a powerful 1500 W heating element, SensoFlow System for optimal brewing temperature, aromaDouble Shot for extra strong coffee without bitterness, and a durable ceramic grinder, your machine ensures a perfect cup every time. The intuitive CoffeeSelect Display allows for direct selection and preparation of your favorite beverages, and the OneTouch DoubleCup function enables simultaneous preparation of two cups.

This manual provides essential information on setting up, operating, maintaining, and troubleshooting your coffee machine to ensure its longevity and optimal performance.

## 2. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance. Keep this manual for future reference.

- **Electrical Safety:** Ensure the voltage specified on the rating plate matches your mains supply. Do not immerse the appliance, power cord, or plug in water or other liquids. Do not operate the appliance with a damaged cord or plug.
- **Hot Surfaces & Liquids:** The appliance produces hot water, steam, and coffee. Be careful of hot surfaces and avoid direct contact with hot liquids. Use handles and knobs.
- **Children:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Proper Use:** Use the appliance only for preparing coffee and hot beverages. Any other use is considered

improper and may result in injury or damage.

- **Cleaning:** Always unplug the appliance before cleaning. Do not use abrasive cleaning agents or harsh chemicals.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the main components of your Siemens EQ.6 plus s700 coffee machine.



Figure 3.1: Front view of the Siemens EQ.6 plus s700 Automatic Coffee Machine, showing the display, coffee spouts, and drip tray.



Figure 3.2: The coffee machine preparing two latte macchiatos simultaneously, demonstrating the dual cup function and milk frothing capability.



Figure 3.3: The coffee machine displayed with a selection of prepared coffee beverages, highlighting its versatility.

### Key Components:

- **CoffeeSelect Display:** Intuitive touch display for beverage selection.
- **Bean Container:** For whole coffee beans.
- **Water Tank:** Removable tank for fresh water.
- **Coffee Spout:** Height-adjustable for various cup sizes (8.6 to 14.1 cm).
- **Milk Frother Nozzle:** For preparing milk-based beverages.
- **Drip Tray & Coffee Grounds Container:** Collects excess liquid and used coffee grounds.
- **Brewing Unit:** Removable for cleaning.
- **Ground Coffee Chute:** For pre-ground coffee.

## 4. SETUP AND FIRST USE

### 4.1 Unpacking and Initial Cleaning

1. Carefully remove the appliance from its packaging.
2. Remove all packaging materials and protective films.
3. Clean the water tank, drip tray, and coffee grounds container with warm water and a mild detergent. Rinse thoroughly.

## 4.2 Filling the Water Tank

- Remove the water tank from the side of the machine.
- Fill the tank with fresh, non-carbonated tap water up to the MAX mark.
- Insert the BRITA INTENZA water filter cartridge if desired (one included).
- Place the water tank back into the machine securely.

## 4.3 Filling the Bean Container

- Open the lid of the bean container on top of the machine.
- Fill with whole roasted coffee beans. Do not use ground coffee, instant coffee, or caramelized beans.
- Close the lid firmly.

## 4.4 Power Connection and First Rinse Cycle

1. Plug the power cord into a grounded electrical outlet.
2. Switch on the appliance using the main power switch.
3. The machine will perform an automatic rinse cycle. Follow the instructions on the CoffeeSelect Display.

## 4.5 Setting Water Hardness

The machine comes with test strips to determine your water hardness. Setting the correct water hardness is crucial for optimal descaling intervals and machine longevity.

- Dip a test strip into tap water for one second.
- Compare the color change with the provided chart.
- Access the water hardness setting in the machine's menu (refer to the display instructions) and adjust accordingly.

# 5. OPERATING INSTRUCTIONS

---

## 5.1 Using the CoffeeSelect Display

The CoffeeSelect Display is your primary interface for operating the machine. Simply touch the sensor fields to select and prepare your desired aromatic coffee and milk specialties.

## 5.2 Preparing Coffee Beverages

1. Place one or two cups under the coffee spout. Adjust the spout height as needed.
2. On the CoffeeSelect Display, select your desired beverage (e.g., Espresso, Coffee, Latte Macchiato).
3. For two cups, select the OneTouch DoubleCup option if available for your chosen drink.
4. The machine will automatically grind the beans, brew, and dispense the coffee.
5. **aromaDouble Shot:** For an extra strong coffee with less bitterness, select the aromaDouble Shot option if available for your chosen drink. This involves two grinding and brewing processes.

## 5.3 Preparing Milk-Based Beverages

For milk-based drinks like Latte Macchiato or Cappuccino, ensure the milk frother hose is connected and immersed in a container of fresh milk.



Figure 5.1: Close-up view of two latte macchiatos being dispensed, showing the layered milk and coffee.

1. Place your cup(s) under the coffee spout.
2. Select a milk-based beverage from the display.
3. The machine will automatically froth the milk and then dispense the coffee.

## 5.4 Customizing Beverages

You can customize various settings for your drinks:

- **Coffee Strength:** Adjust the strength (e.g., mild, normal, strong) before brewing.
- **Cup Volume:** Adjust the desired volume of coffee or milk.
- **Grind Setting:** The ceramic grinder allows for adjustment of the grind fineness. Refer to the machine's internal settings for this adjustment.
- **Personalized Beverages:** The machine allows you to store up to four personalized beverage settings for quick access.

## 6. CLEANING AND MAINTENANCE

Regular cleaning and maintenance are essential for the longevity and optimal performance of your coffee machine.



Figure 6.1: The Siemens EQ.6 plus s700 coffee machine shown alongside a box of Siemens EQ.series cleaning tablets, essential for maintenance.

### 6.1 AutoMilk Clean

The AutoMilk Clean function provides fully automatic steam cleaning of the milk system after every beverage, eliminating the need for daily manual cleaning of the milk system.

- Ensure the milk frother hose is correctly positioned for the cleaning cycle.
- The machine will prompt you when this cleaning is performed.

### 6.2 Descaling

Limescale buildup can affect coffee quality and machine performance. The machine will prompt you when descaling is required.

- Use only Siemens-approved descaling tablets or solutions.
- Follow the instructions on the display for the descaling program. This process typically takes about 30-45 minutes.

### 6.3 Cleaning the Brewing Unit

The brewing unit should be cleaned regularly (e.g., weekly) to prevent coffee residue buildup.



Figure 6.2: A hand demonstrating the removal of the brewing unit from the side of the coffee machine for cleaning.

1. Switch off the appliance and unplug it.
2. Open the service door on the side of the machine.
3. Press the PUSH button and pull out the brewing unit.
4. Rinse the brewing unit thoroughly under running water. Do not use detergent.
5. Allow it to air dry completely before reinserting.

#### **6.4 Cleaning Drip Tray and Coffee Grounds Container**

- Empty and clean the drip tray and coffee grounds container daily or when prompted by the machine.
- Wash with warm water and mild detergent, then rinse and dry.

#### **6.5 Water Filter Replacement**

If you use a BRITA INTENZA water filter, replace it regularly as indicated by the machine or after approximately two months, whichever comes first.

## 7. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your coffee machine.

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
No coffee dispensed / Machine not brewing.	Water tank empty; Bean container empty; Brewing unit blocked.	Fill water tank; Fill bean container; Clean brewing unit.
Coffee is too weak or too strong.	Incorrect coffee strength setting; Grind fineness incorrect.	Adjust coffee strength on display; Adjust grind fineness (refer to manual for specific steps).
Milk foam quality is poor or inconsistent.	Limescale buildup in the machine; Milk system dirty; Type of milk used.	Perform descaling program; Clean milk system thoroughly; Use fresh, cold milk (preferably whole milk).
Error message on display.	Specific error condition.	Refer to the display message for specific instructions. Often requires cleaning, refilling, or descaling.
Coffee beans cannot be refilled.	Bean container full or jammed.	Check for blockages in the bean container or grinder. Ensure only whole beans are used.
Water is not carbonated.	Using carbonated water.	Only use non-carbonated water in the water tank.

## 8. TECHNICAL SPECIFICATIONS

---

Feature	Specification
Brand	SIEMENS
Model Number	TE657503DE
Color	Stainless Steel
Product Dimensions (L x W x H)	46.5 x 28 x 38.5 cm
Weight	10.3 Kilograms
Capacity	2 Cups (simultaneous)
Water Tank Volume	1.7 Liters
Power	1500 Watts
Voltage	220 V
Material	Stainless Steel
Pressure	19 Bars
Special Feature	Integrated Coffee Grinder
Coffee Maker Type	Espresso Machine (Bean-to-Cup)

## 9. WARRANTY AND SUPPORT

Your Siemens EQ.6 plus s700 Automatic Coffee Machine is manufactured with high-quality materials and undergoes rigorous quality control. For information regarding warranty coverage, please refer to the warranty card included with your purchase or contact Siemens customer service.

For technical support, spare parts, or service inquiries, please visit the official Siemens Home Appliances website or contact their authorized service centers. Always provide your model number (TE657503DE) and serial number when seeking support.