

[manuals.plus](#) /› [Verbatim](#) /› [Verbatim 2.4G Wireless LED Silent Mouse \(Model 99770\) Instruction Manual](#)

## Verbatim 99770

# Verbatim 2.4G Wireless LED Silent Mouse (Model 99770) Instruction Manual

Model: 99770

## INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Verbatim 2.4G Wireless LED Silent Mouse. Designed for a quiet computing experience, this mouse features silent click switches, 2.4GHz wireless connectivity, and Blue LED technology for versatile surface tracking. It is compatible with both Mac and Windows platforms.

## SETUP GUIDE

### 1. Package Contents

- 1 x Verbatim 2.4G Wireless LED Silent Mouse
- 1 x Nano USB Receiver
- 2 x AAA Batteries

### 2. Installing Batteries

1. Locate the battery compartment on the underside of the mouse.
2. Slide the battery compartment cover open.
3. Insert the two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Figure 1: Underside of the mouse with the battery compartment open, showing where to insert AAA batteries.

### 3. Connecting the Nano USB Receiver

1. Remove the nano USB receiver from its storage slot, usually located inside the battery compartment or near it.
2. Plug the nano USB receiver into an available USB port on your computer (PC or Mac).
3. Turn on the mouse using the ON/OFF switch located on the underside.
4. Your computer should automatically detect and install the necessary drivers. The mouse will be ready for use shortly.



Figure 2: The nano USB receiver stored in its slot on the underside of the mouse.

## OPERATING INSTRUCTIONS

---

### Basic Functions

- **Left Click:** Primary selection and activation.
- **Right Click:** Accesses contextual menus.
- **Scroll Wheel:** Scrolls documents and web pages vertically. The scroll wheel also functions as a middle click button.

### Silent Click Technology

The Verbatim Silent Mouse features silent click switches and rubber covers, significantly reducing clicking noise for a quieter work environment.

### 2.4GHz Wireless Connectivity

Enjoy lag-free performance with the 2.4GHz wireless connection, providing reliable and responsive cursor movement.

### Blue LED Technology

The Blue LED sensor allows the mouse to track accurately on a wide variety of surfaces, including glass tabletops and granite counters, offering precision and control.



## The Sound of Silence

Silent Technology and rubber-covered switches deliver a whisper-quiet click with every press—great for anywhere you need focus without noise.

Figure 3: The Verbatim Silent Mouse being used on a desk, demonstrating its ergonomic design.

### Power Saving Feature

To conserve battery life, the mouse enters a sleep mode after a period of inactivity. To reactivate it, simply click any button.

## MAINTENANCE

---

### Battery Replacement

When the mouse performance degrades or stops responding, it is likely time to replace the AAA batteries. Follow the steps outlined in the "Installing Batteries" section of this manual.

### Cleaning

To clean your mouse, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the mouse. Avoid abrasive cleaners or solvents.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Mouse not responding or freezing intermittently.	Low battery, loose nano receiver, interference, mouse in sleep mode.	<ul style="list-style-type: none"> <li>Replace batteries with fresh ones.</li> <li>Ensure the nano receiver is securely plugged into a USB port. Try a different USB port.</li> <li>Move the mouse closer to the receiver.</li> <li>Click any mouse button to wake it from sleep mode.</li> <li>Avoid using the mouse on highly reflective or transparent surfaces without a mouse pad.</li> </ul>
Mouse clicks are no longer silent.	Wear and tear on silent click mechanisms.	This may indicate normal wear over extended use. If the issue persists and affects functionality, refer to the warranty section.
Cursor movement is erratic or inaccurate.	Dirty sensor, unsuitable surface, low battery.	<ul style="list-style-type: none"> <li>Clean the optical sensor on the underside of the mouse with a soft cloth.</li> <li>Use the mouse on a non-reflective, opaque surface or a mouse pad.</li> <li>Replace batteries.</li> </ul>
Nano receiver not recognized by computer.	Driver issue, faulty USB port, receiver not fully inserted.	<ul style="list-style-type: none"> <li>Try plugging the receiver into a different USB port.</li> <li>Restart your computer.</li> <li>Ensure the mouse is turned ON.</li> <li>Visit the Verbatim support website for driver downloads if necessary (though typically plug-and-play).</li> </ul>

## SPECIFICATIONS

<b>Brand</b>	Verbatim
<b>Model Number</b>	99770
<b>Connectivity Technology</b>	2.4GHz Wireless
<b>Movement Detection Technology</b>	Optical (Blue LED)
<b>Hardware Platform</b>	PC, Mac, Linux
<b>Operating System Compatibility</b>	Mac OS X 10.7 Lion, Windows 10 (and newer)
<b>Item Weight</b>	2.08 ounces
<b>Product Dimensions (LxWxH)</b>	3.74 x 2.28 x 1.4 inches
<b>Color</b>	Blue (for this variant)

Power Source	Battery Powered (2 x AAA batteries)
Average Battery Life	Up to 18 months (may vary with usage)

## WARRANTY INFORMATION

---

The Verbatim 2.4G Wireless LED Silent Mouse is backed by a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by accident, abuse, misuse, or unauthorized modification.

For warranty claims, please retain your proof of purchase. Contact Verbatim customer support for assistance.

## SUPPORT AND CONTACT

---

For technical support, product inquiries, or warranty assistance, please visit the official Verbatim website or contact their customer service department.

**Verbatim Official Website:** [www.verbatim.com](http://www.verbatim.com)

Please have your product model number (99770) and proof of purchase ready when contacting support.

---

© 2024 Verbatim. All rights reserved.