

Fellow Stagg EKG

Fellow Stagg EKG Electric Gooseneck Kettle User Manual

Model: Stagg EKG (1137)

INTRODUCTION

The Fellow Stagg EKG Electric Gooseneck Kettle is designed for precision and efficiency in brewing pour-over coffee and steeped tea. Its sleek design and advanced features provide an optimal brewing experience. This manual provides essential information for the safe and effective use of your new kettle.



Figure 1: Fellow Stagg EKG Electric Gooseneck Kettle

SAFETY INFORMATION

Please read all safety instructions carefully before using the kettle. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the kettle or base in water or other liquids.
- Ensure the kettle is placed on a stable, level, and heat-resistant surface.

- Do not operate the kettle if the cord or plug is damaged.
- Keep out of reach of children.
- Always unplug the kettle when not in use and before cleaning.
- Do not use the kettle for anything other than heating water.
- The kettle is designed for use with its electric base only. Do not use on a stovetop.

PRODUCT OVERVIEW

The Stagg EKG kettle features a minimalist design with intuitive controls.

- **Gooseneck Spout:** Designed for precise pour-over flow rate.
- **Kettle Body:** Constructed from durable 304 stainless steel.
- **Lid:** Secure and easy to remove for filling.
- **Handle:** Counterbalanced for comfortable and controlled pouring.
- **Base:** Houses the 1200-watt heating element, LCD screen, and control dial.




Figure 2: Key Features of Stagg EKG



Figure 3: Kettle Dimensions

SETUP

1. **Unpacking:** Carefully remove all components from the packaging.
2. **Placement:** Place the kettle base on a dry, flat, and stable surface near a power outlet.
3. **Initial Cleaning:** Before first use, fill the kettle with water to the MAX fill line, boil, and discard the water. Repeat this process 2-3 times to ensure cleanliness.

OPERATING INSTRUCTIONS

Follow these steps to heat water with your Stagg EKG kettle:

1. **Fill Kettle:** Remove the lid and fill the kettle with fresh water. Do not exceed the 0.9-liter capacity or the MAX fill line indicated inside the kettle.
2. **Place on Base:** Ensure the kettle is properly seated on its electric base.
3. **Power On:** Plug the base into a standard electrical outlet. Press the main button on the base to power on the kettle. The LCD screen will illuminate.
4. **Set Temperature:** Use the control dial to select your desired temperature. The kettle offers to-the-degree temperature control for precise brewing.
5. **Start Heating:** The 1200-watt heating element will quickly bring the water to the set temperature. The real-time temperature will be displayed on the LCD screen.
6. **Temperature Hold (Optional):** Engage the toggle on the base to activate the temperature hold function, keeping your water hot for up to 60 minutes.
7. **Brew Stopwatch (Optional):** Use the built-in Brew Stopwatch to time your extraction for pour-over coffee or steeped tea.
8. **Pouring:** The gooseneck spout is designed for a powerful yet precise stream, ideal for controlled pour-over methods. The counterbalanced handle provides a sturdy grip for slower, more deliberate pouring.



Figure 4: Precision Pouring

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your kettle.

- **Daily Cleaning:** Wipe the exterior of the kettle and base with a damp cloth. Hand wash the interior of the kettle with mild soap and water.
- **Descaling:** Over time, mineral deposits may build up inside the kettle. To descale, fill the kettle with a solution of equal parts white vinegar and water. Bring to a boil and let it sit for at least 30 minutes, or longer for heavy buildup. Rinse thoroughly with fresh water.
- Do not use abrasive cleaners or scouring pads, as they may damage the finish.

TROUBLESHOOTING

If you encounter issues with your kettle, refer to the following common solutions:

- **Kettle not heating:** Ensure the power cord is securely plugged into both the base and the wall outlet. Check if the kettle is properly seated on the base.
- **Water not reaching desired temperature:** Verify the temperature setting on the LCD screen. Ensure the lid is securely placed on the kettle during heating.
- **Kettle leaks:** Ensure the lid is properly sealed and the kettle is not overfilled beyond the MAX line.

For further assistance, please contact Fellow customer support.

SPECIFICATIONS

Brand	Fellow
Model Name	Stagg EKG
Item Model Number	1137

Color	Matte Black
Special Feature	Temperature Control
Finish Type	Matte, Stainless Steel
Product Dimensions	11.5"L x 6.73"W x 8"H
Item Weight	0.176 ounces (5 Grams)
Capacity	0.9 Liters
Power	1200 Watts (Quick Heating)
Cable Length	2.5 Feet
UPC	852212007526, 852212007151
Date First Available	November 16, 2017

WARRANTY AND SUPPORT

For warranty information or technical support, please visit the official Fellow website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Official Fellow Store: [Fellow Store on Amazon](#)