

Lindby 4018063

Lindby Lago LED Solar Garden Light - Instruction Manual

Model: 4018063

1. PRODUCT OVERVIEW

The Lindby Lago LED Solar Garden Light is a modern, spherical outdoor lighting solution designed for decorative and functional illumination of gardens, paths, and outdoor areas. This solar-powered light is made from durable plastic and features an integrated LED light source.

Its design allows for versatile placement, enhancing the ambiance of flowerbeds, garden paths, entrances, terraces, or carports. The light operates using solar energy, eliminating the need for external power sources or complex wiring. It is rated IP44, ensuring its suitability for outdoor use and resistance to splashing water.



Image: The Lindby Lago LED Solar Garden Light, illuminated, placed in a garden bed with wood chips and stone borders.

2. SAFETY INFORMATION

- Read all instructions before installation and use.
- Do not attempt to modify or disassemble the product beyond what is described in this manual.
- Ensure the solar panel is clean and unobstructed to allow for optimal charging.
- Keep the product away from open flames or extreme heat sources.
- Dispose of batteries and electronic components according to local regulations.
- This product is designed for outdoor use (IP44). Do not submerge in water.

3. PACKAGE CONTENTS

Verify that all components are present:

- 1x Lindby Lago LED Solar Garden Light Sphere
- 1x Ground Spike (consisting of two parts)



Image: The main light sphere and the two-part ground spike.

4. SETUP AND INSTALLATION

1. **Assemble the Ground Spike:** Connect the two parts of the ground spike firmly together.
2. **Attach to Light Sphere:** Insert the assembled ground spike into the designated opening at the bottom of the light sphere. Ensure it is securely fitted.



Image: The ground spike being attached to the light sphere.

3. **Activate the Light:** Locate the push-button switch at the base of the light sphere. Press it to turn the light 'ON'.



Image: The underside of the light sphere, showing the power button.

4. **Choose Location:** Select an outdoor location that receives direct sunlight for at least 6-8 hours daily. This is crucial for optimal battery charging and light performance.
5. **Install in Ground:** Firmly insert the assembled light with the ground spike into the soil. Ensure it is stable and upright.



Image: The Lindby Lago LED Solar Garden Light installed in a garden bed, showing the black stem and white sphere.

5. OPERATING INSTRUCTIONS

- **Automatic Operation:** Once activated and sufficiently charged, the Lindby Lago LED Solar Garden Light will automatically turn on at dusk and turn off at dawn.
- **Manual Control:** The push-button switch at the base can be used to manually turn the light on or off at any time.
- **Initial Charge:** For first-time use, allow the light to charge in direct sunlight for a full day (6-8 hours) with the switch in the 'ON' position before expecting full performance.

6. MAINTENANCE

- **Clean Solar Panel:** Regularly wipe the solar panel with a soft, damp cloth to remove dust, dirt, or debris. A clean panel ensures maximum sunlight absorption and charging efficiency.
- **Clean Light Sphere:** Clean the plastic light sphere with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the material.
- **Seasonal Storage:** If storing the light for an extended period, ensure it is fully charged, then turn it off and store it in a dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on at night.	<ol style="list-style-type: none">1. Switch is OFF.2. Insufficient sunlight for charging.3. Solar panel is dirty or obstructed.4. Battery is depleted or faulty.	<ol style="list-style-type: none">1. Ensure the switch at the base is in the 'ON' position.2. Relocate the light to an area with direct sunlight for 6-8 hours daily.3. Clean the solar panel. Remove any obstructions.4. Allow several days of full charge. If problem persists, battery may need replacement (contact support).
Light illuminates for a short period only.	<ol style="list-style-type: none">1. Insufficient battery charge.2. Battery capacity reduced due to age or temperature.	<ol style="list-style-type: none">1. Ensure the light receives maximum direct sunlight for charging.2. Battery performance can decrease over time. Consider battery replacement if available.

8. SPECIFICATIONS

- **Model Number:** 4018063
- **Dimensions (L x W x H):** 25 cm x 25 cm x 46 cm
- **Material:** Plastic
- **Color:** White
- **Style:** Modern
- **Power Source:** Solar panel
- **Light Source:** Integrated LED
- **Light Color:** Cold white
- **Brightness:** Max. 20 Lumen
- **IP Rating:** IP44 (Water-resistant)
- **Control Method:** Push-button switch
- **Mounting Type:** Floor mounted (with ground spike)
- **Energy Efficiency Class:** E



Image: Energy efficiency label for the product, indicating class E.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase documentation or contact your retailer. Keep your proof of purchase for any warranty claims.

Manufacturer: Lindby