



Manuals.plus /

› RYRA /

› Klone Overdrive Pedal User Manual

RYRA Klone Overdrive Pedal

Klone Overdrive Pedal User Manual

Brand: RYRA | Model: Klone Overdrive Pedal

1. INTRODUCTION

Thank you for choosing the RYRA Klone Overdrive Pedal. This manual provides detailed instructions for setting up, operating, and maintaining your pedal to ensure optimal performance and longevity. The RYRA Klone is a meticulously crafted replica of a renowned transparent overdrive pedal, designed to deliver a big, 3D, open sound that cuts through any mix.

2. KEY FEATURES

- **Handcrafted Quality:** Each pedal is built with the best components and craftsmanship.
- **Transparent Overdrive:** Delivers a clear, articulate overdrive that enhances your guitar's natural tone.
- **Buffered Bypass:** Ensures signal integrity even when the pedal is disengaged.
- **Versatile Power Options:** Can be powered by a 9V battery or a standard 9V DC power supply.
- **Durable Construction:** Features a beautifully powder-coated gold finish for aesthetic appeal and durability.
- **Compact Design:** Exterior dimensions of 4.7" x 3.7" x 1.18" for easy integration into any pedalboard.
- **Made in the United States:** Proudly manufactured with attention to detail.

3. SETUP GUIDE

3.1 Powering the Pedal

The RYRA Klone Overdrive Pedal can be powered in two ways:

- **9V Battery:** Open the battery compartment (usually on the bottom or side, depending on the enclosure design) and connect a standard 9V alkaline battery.
- **9V DC Power Supply:** Connect a standard 9V DC (center-negative) power adapter to the DC jack on the

pedal. Ensure the power supply provides at least 100mA.

Note: Disconnect the input cable from the pedal when not in use to conserve battery life.

3.2 Connecting to Your Rig

1. Connect your guitar or previous effect pedal to the **INPUT** jack on the RYRA Klone.
2. Connect the **OUTPUT** jack of the RYRA Klone to your amplifier or the next effect pedal in your signal chain.



Image: Rear view of the RYRA Klone Overdrive Pedal. This image displays the input jack on the left, the 9V DC power input in the center, and the output jack on the right. These are essential connection points for integrating the pedal into a guitar setup.

4. OPERATING THE PEDAL

The RYRA Klone Overdrive Pedal features three primary control knobs and a footswitch for engaging the effect.



Image: Top-down view of the RYRA Klone Overdrive Pedal. This image highlights the three control knobs: Gain (left), Treble (middle), and Output (right), along with the footswitch at the bottom right. The pedal's gold finish and blue RYRA logo are also visible.

4.1 Control Knobs

- **GAIN:** Controls the amount of overdrive or distortion. Turning this knob clockwise increases the saturation and sustain. At lower settings, it can act as a clean boost.
- **TREBLE:** Adjusts the high-frequency content of the signal. Use this to brighten or darken your tone. Turning it clockwise increases treble.
- **OUTPUT:** Sets the overall volume level of the effect. Use this to match the volume with your bypassed signal or to boost your amplifier.

4.2 Footswitch

The footswitch engages or bypasses the effect. When the effect is engaged, the LED indicator (small dot near the GAIN knob) will illuminate. When bypassed, the LED will be off, and your signal will pass through the pedal unaffected (buffered bypass).



Image: Angled view of the RYRA Klone Overdrive Pedal. This perspective shows the pedal's top surface, including the three control knobs (Gain, Treble, Output) and the footswitch. The gold finish and the RYRA logo are prominent.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the pedal's exterior. Avoid abrasive cleaners or solvents.
- **Storage:** Store the pedal in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If using battery power, replace the 9V battery when the LED indicator dims or the sound quality degrades.
- **Connections:** Periodically check all cables and jacks for secure connections and signs of wear.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound when pedal is engaged.	<ul style="list-style-type: none"> Incorrect power supply. Dead battery. Loose cable connections. Pedal not receiving input signal. 	<ul style="list-style-type: none"> Ensure 9V DC (center-negative) power supply is used. Replace 9V battery. Check all input and output cables are securely connected. Verify signal from guitar/previous pedal.
Weak or distorted sound.	<ul style="list-style-type: none"> Low battery. Incorrect knob settings. Faulty cables. 	<ul style="list-style-type: none"> Replace 9V battery or use DC power supply. Adjust GAIN, TREBLE, and OUTPUT knobs. Try different cables.
LED not illuminating.	<ul style="list-style-type: none"> No power. Faulty LED. 	<ul style="list-style-type: none"> Check power supply/battery. If power is confirmed, contact support.

7. SPECIFICATIONS

Feature	Detail
Effect Type	Overdrive
Signal Format	Analog
Bypass Type	Buffered Bypass
Power Source	9V DC (center-negative) or 9V Battery
Voltage	9 Volts (DC)
Dimensions (L x W x H)	4.7" x 3.7" x 1.18" (approx. 11.9 cm x 9.4 cm x 3 cm)
Color	Multicolor (Powder Coated Gold)
ASIN	B078KNDPFY
Manufacturing Origin	United States

8. WARRANTY AND SUPPORT

For warranty information or technical support regarding your RYRA Klone Overdrive Pedal, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: Rock Your Repaired Amp

For further assistance, please visit the [product page on Amazon](#) or the [official RYRA website](#) (if available).