

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Quorum International](#) /
- › [Quorum International Breeze 52" Satin Nickel Ceiling Fan Instruction Manual](#)

### Quorum International 70525-365

# Quorum International Breeze 52" Ceiling Fan Instruction Manual

Model: 70525-365

## INTRODUCTION

Thank you for choosing the Quorum International Breeze 52" Ceiling Fan. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new ceiling fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: The Quorum International Breeze 52-inch ceiling fan, featuring a satin nickel motor housing, five reversible blades (silver on one side, walnut on the other), and a three-light kit with seeded glass shades. The fan is suspended from a downrod.

## IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Read all instructions before installing the fan.
- Ensure the installation site allows the fan blades to rotate without obstruction. Maintain a minimum clearance of 7 feet from the floor to the blade trailing edge.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Before installation or servicing, disconnect power by turning off the circuit breaker at the main fuse box.
- The outlet box and support structure must be securely mounted and capable of supporting a minimum of 35 lbs (15.9 kg). Use only UL Listed outlet boxes marked "FOR FAN SUPPORT."
- Do not operate the fan with damaged power cords or plugs.
- Avoid placing fingers or objects into the fan blades while the fan is operating.
- Do not use this fan with a dimmer switch.

## COMPONENTS AND PARTS LIST

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact Quorum International customer service.

- Fan Motor Housing (Satin Nickel Finish)
- Reversible Fan Blades (5x, Silver/Walnut)
- Blade Brackets/Arms (5x)
- Light Kit Assembly (Integrated 3-Light)
- Seeded Glass Shades (3x)
- Downrods (3.5" and 6" options)
- Canopy and Mounting Bracket
- Pull Chains (for fan speed and light)
- Hardware Pack (screws, washers, wire nuts, etc.)



Image: A detailed view of the fan's central body, highlighting the satin nickel finish and the dual-tone reversible blades, illustrating the silver and walnut options.

## SETUP AND INSTALLATION

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before proceeding.

1. **Mounting Bracket Installation:** Secure the mounting bracket to a UL Listed outlet box capable of supporting a ceiling fan. Use hardware provided with the outlet box.
2. **Downrod Assembly:** Select the desired downrod (3.5" or 6"). Feed the fan wires through the downrod and secure the downrod to the fan motor housing.
3. **Hanging the Fan:** Carefully lift the fan assembly and hang it from the mounting bracket using the ball joint.
4. **Electrical Wiring:** Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the separate wiring guide (not included in this general manual). Ensure all connections are secure with wire nuts.
5. **Canopy Installation:** Slide the canopy up to the ceiling and secure it to the mounting bracket, covering the wiring connections.
6. **Blade Attachment:** Attach each fan blade to its respective blade bracket using the provided screws. Then, attach the blade assemblies to the fan motor housing. Ensure all screws are tightened securely.
7. **Light Kit Installation:** Connect the light kit wires to the fan motor housing wires. Secure the light kit assembly to the bottom of the fan motor housing. Install the three seeded glass shades.
8. **Bulb Installation:** Install three 9W non-dimmable medium-base LED bulbs (not included) into the light kit sockets.

## OPERATING INSTRUCTIONS

Your Quorum International Breeze ceiling fan is controlled by two pull chains and features a manual reverse switch.

- **Fan Speed Control:** The fan speed is controlled by one of the pull chains. Pull the chain repeatedly to cycle through speeds: High, Medium, Low, Off.
- **Light Control:** The light kit is controlled by the other pull chain. Pull the chain to turn the lights On or Off.
- **Reverse Airflow (Seasonal Operation):**
  - Locate the manual reverse switch on the fan motor housing (usually near the light kit).
  - To change the direction of airflow, ensure the fan is completely OFF.
  - Slide the reverse switch to the opposite position.
  - **Summer Operation:** Blades rotate counter-clockwise, creating a downward breeze for a cooling effect.
  - **Winter Operation:** Blades rotate clockwise, creating an upward draft to circulate warm air from the ceiling.

## MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Periodically clean the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Blade Cleaning:** Wipe fan blades with a soft cloth to remove dust.
- **Tightening Screws:** Check all screws, especially those on the blade attachments and mounting bracket, at least twice a year. Tighten any loose screws to prevent wobbling and noise.
- **Light Bulb Replacement:** Ensure power is off before replacing light bulbs. Use only recommended bulb types (3 x 9W non-dimmable medium-base LED bulbs).
- **No Lubrication Required:** The fan motor is permanently lubricated and does not require oiling.

## TROUBLESHOOTING GUIDE

Before attempting any repairs, ensure power is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Fan does not start.	No power to the fan; Loose wire connections; Blown fuse/tripped circuit breaker.	Check circuit breaker and wall switch; Verify all wire connections are secure; Replace fuse or reset breaker.
Fan wobbles.	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Ensure blades are balanced (use balancing kit if necessary); Secure mounting bracket.

Problem	Possible Cause	Solution
Noisy operation.	Loose screws; Motor hum (normal); Fan not properly seated.	Check and tighten all screws; Ensure canopy is not vibrating against the ceiling; Verify fan is securely hung.
Light kit not working.	Loose wire connections; Faulty bulbs; Light pull chain in "off" position.	Check light kit wiring; Replace bulbs; Pull light chain to "on" position.

## PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Quorum International
Model Number	70525-365
Color	Pewter, Nickel, Silver (Satin Nickel Finish)
Electric Fan Design	Ceiling Fan
Style	Breeze (Transitional)
Product Dimensions	52"D x 52"W x 16.75"H
Special Feature	Fan & Light Pull Chain
Wattage	66.00 W (Fan), 33 W (Max Light)
Voltage	120 Volts
Blade Material	Plastic (Reversible Silver/Walnut)
Item Weight	13 Pounds
Light Type	Integrated 3-Light LED (bulbs not included)
Safety Rating	UL Listed for Dry Locations

## WARRANTY AND SUPPORT

The Quorum International Breeze ceiling fan features a long-lasting motor backed by a limited lifetime warranty. For specific warranty details, please refer to the warranty card included with your product or contact Quorum International directly.

For technical support, missing parts, or warranty claims, please contact Quorum International customer service. Have your model number (70525-365) and proof of purchase ready.

**Quorum International Contact Information:**

*Website:* [www.quorumintl.com](http://www.quorumintl.com)

*Phone:* Refer to product packaging or official website for current contact numbers.