

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lindby](#) /
- › [Lindby Tommi Modern Plaster Wall Lamp User Manual](#)

## Lindby 9613070

# Lindby Tommi Modern Plaster Wall Lamp User Manual

MODEL: 9613070

Brand: Lindby

## Introduction

Thank you for choosing the Lindby Tommi Modern Plaster Wall Lamp. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.

## Important Safety Instructions

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with all local and national electrical codes. Always disconnect power at the main circuit breaker before installation or maintenance.
- **Voltage:** Ensure the supply voltage matches the lamp's requirements (230 Volts).
- **Bulb Type:** Use only E14 base bulbs with a maximum wattage of 25 watts. LED bulbs are recommended.
- **Material:** The lamp is made of plaster. Handle with care to prevent damage.
- **Indoor Use Only:** This product is designed for indoor use in dry locations. It is not water-resistant.
- **Heat:** Allow bulbs to cool before touching or replacing.

## Package Contents

Verify that all components are present before beginning installation:

- Lindby Tommi Wall Lamp fixture (1 unit)
- Mounting hardware (screws, wall anchors)
- *Note: Light bulbs are not included.*

## Specifications




Image: Product dimensions diagram.

Feature	Detail
Brand	Lindby
Model Name	Tommi
Model Number	9613070
Product Dimensions (L x W x H)	15L x 100W x 10.5H centimeters
Weight	3.1 Kilograms
Material	Plaster
Color	White
Style	Modern
Room Type	Living Room
Indoor/Outdoor Use	Indoor
Power Source	Corded Electric
Special Features	Dimmable
Control Method	Touch (referring to switch type, likely external)
Light Source	LED (recommended, bulbs not included)
Number of Light Sources	4
Voltage	230 Volts
Light Color	Warm White (with appropriate bulbs)
Wattage	25 watts (max per bulb)
Lamp Fitting	E14
Switch Type	Rotary Switch (external, not integrated)
Water Resistance Level	Not Water Resistant

Brightness	1000 lumens (with appropriate bulbs)
Mounting Type	Wall Mount
Installation Type	Recessed Mount
Assembly Required	No (referring to the fixture itself, but installation is required)

## Setup and Installation

---

**Before you begin:** Ensure the power supply to the installation area is turned off at the circuit breaker. It is recommended to have a qualified electrician perform the installation.

- 1. Prepare the Mounting Location:** Choose a suitable wall location for the lamp. Ensure there is adequate space and access to electrical wiring.
- 2. Mark Drilling Points:** Hold the mounting bracket (or the lamp itself if the bracket is integrated) against the wall at the desired installation height. Use a pencil to mark the drilling points for the screws.
- 3. Drill Holes:** Drill holes at the marked points. Insert appropriate wall anchors if necessary, depending on your wall material.
- 4. Attach Mounting Bracket:** Secure the mounting bracket to the wall using the provided screws. Ensure it is firmly attached.



*Image: Internal view of the lamp showing the mounting bracket and wiring terminals.*

5. **Electrical Connection:** Connect the electrical wires from the wall to the lamp's terminal block.

- Connect the live wire (usually brown or black) to the 'L' terminal.
- Connect the neutral wire (usually blue) to the 'N' terminal.
- Connect the earth wire (usually green/yellow) to the earth terminal (marked with  $\sphericalangle$ ).

Ensure all connections are secure.



*Image: Close-up of the electrical terminal block for wiring connections.*

- 6. Install Light Bulbs:** Insert four E14 base light bulbs (not included) into the lamp holders. Do not exceed 25 watts per bulb.



*Image: Interior of the lamp with bulb sockets visible.*

- 7. Mount the Lamp Fixture:** Carefully align the lamp fixture with the mounting bracket and secure it in place. Ensure it is stable and flush against the wall.
- 8. Restore Power:** Once the installation is complete and all connections are secure, restore power at the main circuit breaker.
- 9. Test the Lamp:** Turn on the light switch to ensure the lamp is functioning correctly.

## Installation Video Guide

Your browser does not support the video tag.

*Video: Product demonstration and installation guide for a similar wall lamp. This video illustrates the general installation process.*

Your browser does not support the video tag.

*Video: Short demonstration of an LED wall light, showing its warm light output and elegant profile.*

## Operating Instructions

The Lindby Tommi wall lamp is designed for simple operation via a standard wall switch. If connected to a compatible dimmer switch, the light output can be adjusted.

- **Turning On/Off:** Use the wall switch connected to the lamp to turn it on or off.
- **Dimming (Optional):** If you have installed dimmable E14 bulbs and connected the lamp to a compatible dimmer switch, you can adjust the brightness by operating the dimmer switch.

## Maintenance

- **Cleaning:** To clean the lamp, ensure the power is off. Wipe the surface with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these can damage the plaster finish.
- **Bulb Replacement:**
  - a. Turn off the power to the lamp at the circuit breaker.
  - b. Allow the old bulb to cool completely before touching it.
  - c. Carefully unscrew the old E14 bulb.
  - d. Screw in a new E14 bulb, ensuring it does not exceed 25 watts.
  - e. Restore power and test the lamp.

## Troubleshooting

Problem	Possible Cause / Solution
Lamp does not light up.	<ul style="list-style-type: none"> <li>• Check if the power supply is on at the circuit breaker.</li> <li>• Ensure the wall switch is in the 'ON' position.</li> <li>• Verify that the bulbs are correctly installed and not faulty. Replace if necessary.</li> <li>• Check electrical connections for looseness or incorrect wiring (consult a qualified electrician).</li> </ul>
Light flickers.	<ul style="list-style-type: none"> <li>• Ensure bulbs are fully screwed in.</li> <li>• If using a dimmer, ensure both the bulbs and the dimmer switch are compatible with each other.</li> <li>• Loose wiring connection (consult a qualified electrician).</li> </ul>
Lamp is physically damaged.	<ul style="list-style-type: none"> <li>• Due to the plaster material, the lamp can be fragile. Handle with care. Minor imperfections are normal for plaster products. For significant damage, contact customer support.</li> </ul>

## Warranty and Support

For warranty information, please refer to the terms and conditions provided at the point of purchase or contact your retailer. Lindby products are designed for quality and durability.

If you encounter any issues or require assistance, please contact Lindby customer support or your authorized dealer. Please have your model number (9613070) and purchase details ready.

For more information about Lindby products, visit the official Lindby brand store: [Lindby Brand Store](#).