

VAXCEL F0057

VAXCEL Curtiss 52 In. Ceiling Fan User Manual

Model: F0057 | Brand: VAXCEL

1. INTRODUCTION

Thank you for choosing the VAXCEL Curtiss 52 In. Industrial Indoor-Outdoor Wood Ceiling Fan. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new ceiling fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The Curtiss ceiling fan features hand-carved solid wood blades and a clean motor housing design, offering an industrial aesthetic. It is equipped with an LED light kit and a remote control for convenient operation. This fan is suitable for both indoor and exterior damp locations, making it versatile for various spaces such as entryways, family rooms, or covered outdoor porches.



Figure 1.1: VAXCEL Curtiss 52 Inch Ceiling Fan, Matte Black and Brushed Silver finish with wood blades.



Figure 1.2: The VAXCEL Curtiss fan is rated for both indoor and outdoor use, suitable for various environments including covered patios.

Key Features:

- **3-Speed Settings:** Easily adjust airflow to maintain optimal comfort.
- **Remote Control:** Operate fan speeds and light functions from anywhere in the room.
- **Integrated LED Light Kit:** Dimmable LED light produces 1050 lumens at its highest setting, offering energy savings and adjustable illumination.
- **Versatile Installation:** Compatible with standard and sloped ceilings (up to 23 degrees). Includes a 6-inch down rod; longer down rods sold separately.
- **Manual Reverse Air Flow:** Change blade direction seasonally to optimize air circulation (downward for cooling, upward for heat distribution).
- **Damp Rated:** CETL rating ensures safe use in exterior damp locations, as well as all indoor spaces.
- **Quality Construction:** Features durable solid wood blades.

2. SAFETY INFORMATION

Before installing or operating your ceiling fan, please read and understand all safety precautions. Failure to do so may result in electric shock, fire, or personal injury.

- Always disconnect power at the main circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code (NEC).
- Consult a qualified electrician if you are unsure about wiring or installation procedures.
- Ensure the installation site can support the fan's weight (approximately 14.99 lbs).
- Do not operate the fan with damaged blades or housing.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is operating.
- This fan is designed for indoor and exterior damp locations. Do not expose to direct water spray.

3. PACKAGE CONTENTS

Carefully unpack your ceiling fan and ensure all components are present and undamaged. If any parts are missing or damaged, do not proceed with installation and contact VAXCEL customer service.

Typical package contents include:

- Fan Motor Housing
- Fan Blades (3)
- LED Light Kit
- Remote Control (with 9V battery included)
- 6-inch Down Rod
- Mounting Hardware
- Canopy and Mounting Bracket
- Instruction Manual (this document)

4. SETUP AND INSTALLATION

For detailed installation instructions, please refer to the official Installation Manual PDF provided by VAXCEL. A link to this document is typically available on the product's online listing or can be found on the VAXCEL website. The following provides a general overview and important considerations.

Important: Professional installation is recommended for electrical components. Ensure the power is OFF at the circuit breaker before starting any electrical work.

Mounting Options:

The Curtiss fan supports both standard and sloped ceiling installations. It can accommodate angled sloped ceilings up to 23 degrees. The included 6-inch down rod is suitable for low or standard ceiling heights. For higher ceilings, longer down rods (up to 72 inches) are available and sold separately.

CUSTOMIZABLE TO FIT YOUR DECOR



STANDARD



SLOPED

MULTIPLE
OPTIONS



FAN BLADES WALNUT



MULTIPLE
OPTIONS

LONGER DOWN RODS
UP TO 72"
SOLD SEPARATELY

Figure 4.1: The fan supports both standard flush mounting and sloped ceiling installations.

General Installation Steps (Consult PDF for details):

1. Secure the mounting bracket to the ceiling junction box.
2. Assemble the down rod and canopy to the fan motor.
3. Hang the fan assembly from the mounting bracket.
4. Complete electrical wiring connections (ensure proper grounding).
5. Attach the fan blades to the motor housing. Note: Some plastic pieces within the blade track may need to be removed before blade installation. Refer to the detailed manual.
6. Install the LED light kit.
7. Attach the light shade.
8. Restore power and test the fan and light functions.

For a comprehensive guide, please download the [Official VAXCEL Curtiss Installation Manual \(PDF\)](#).

5. OPERATING INSTRUCTIONS

Your VAXCEL Curtiss ceiling fan is operated using the included remote control. Ensure the 9V battery is correctly installed in the remote.



Figure 5.1: Remote control functions for fan speed, light, and seasonal modes.

Remote Control Functions:

- **Fan ON/OFF:** Press the fan button to turn the fan on or off.
- **Fan Speed Control:** Use the speed buttons (typically 1, 2, 3) to cycle through low, medium, and high fan speeds.
- **Light ON/OFF:** Press the light button to turn the LED light on or off.
- **Light Dimming:** Hold the light button to dim or brighten the LED light.
- **Seasonal Mode (Reverse Air Flow):** Locate the manual reverse switch on the fan motor housing.
 - **Summer Mode (Counter-clockwise):** Blades rotate counter-clockwise, pushing cool air downward.
 - **Winter Mode (Clockwise):** Blades rotate clockwise, drawing air upward to circulate warm air trapped near the ceiling.

LED Light Kit Information:

The integrated LED light kit provides efficient and long-lasting illumination. The dimming feature allows you to

adjust the brightness to your preference. The light produces 1050 lumens at its highest setting.




Figure 5.2: Lumens calculator illustrating LED light output equivalence to traditional bulbs.

6. MAINTENANCE

Regular maintenance will help prolong the life and performance of your VAXCEL Curtiss ceiling fan.

- **Cleaning:** To avoid damaging the finish, clean the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** Dust the fan blades regularly to prevent dust buildup, which can affect performance and balance.
- **Tighten Fasteners:** Periodically check all screws and fasteners on the fan and mounting hardware to

ensure they are secure.

- **Lubrication:** The fan motor is permanently lubricated and does not require additional oiling.
- **LED Light Kit:** The integrated LED light kit is designed for long-lasting performance and does not require bulb replacement.

Always ensure the power is OFF at the circuit breaker before performing any cleaning or maintenance.

7. TROUBLESHOOTING

If you experience issues with your VAXCEL Curtiss ceiling fan, refer to the following common troubleshooting steps. If the problem persists, contact VAXCEL customer support.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low/dead; Incorrect dip switch settings on remote/receiver.	Check circuit breaker and wall switch; Verify all wire connections are secure; Replace remote battery; Ensure dip switches match between remote and receiver.
Fan makes noise (humming/clicking)	Loose screws; Fan blades unbalanced; Motor issues.	Tighten all screws on fan housing and blades; Check blade balance and use balancing kit if necessary; If noise persists, contact customer support.
Light does not work	Loose wire connections; LED driver failure; Remote control issue.	Check light kit wiring connections; Ensure remote battery is good and signal is reaching the fan; If integrated LED, contact customer support for LED driver issues.
Fan wobbles excessively	Loose mounting bracket; Unbalanced blades; Bent blade holder.	Ensure mounting bracket is securely fastened to the ceiling; Use a blade balancing kit to correct imbalance; Check blade holders for bends and adjust or replace if necessary.

8. SPECIFICATIONS

Detailed technical specifications for the VAXCEL Curtiss 52 In. Ceiling Fan.



Figure 8.1: Technical diagram showing key product dimensions.

Specification	Value
Model Name	Curtiss
Model Number	F0057
Product Dimensions	52"D x 52"W x 16.25"H
Item Weight	14.99 Pounds
Color	Matte Black and Brushed Silver
Number of Blades	3
Blade Material	Wood
Power Source	Corded Electric
Voltage	120 Volts

Specification	Value
Wattage	22 watts
Air Flow Capacity	3961 Cubic Feet Per Minute
Light Type	Integrated LED
Control Method	Remote
Downrod Length	6 Inches (included)
Indoor/Outdoor Usage	Indoor / Exterior Damp Rated
Certification	CETL Listed
UPC	884656742558

SIZED TO FIT YOUR SPACE

16.25"

52"

IDEAL FOR UP TO
20'x20'
ROOM
OR SMALLER

OPTIMIZED
AIR FLOW
EFFICIENCY

MAIN BEDROOM
FAMILY ROOM
DINING ROOM

Figure 8.2: Fan dimensions and recommended room size (ideal for up to 20'x20' room or smaller).

9. WARRANTY AND SUPPORT

VAXCEL is committed to providing quality lighting and fan solutions. For information regarding your product's warranty, please refer to the documentation included with your purchase or visit the official VAXCEL website. VAXCEL offers protection plans for extended coverage.




Customer Support:




If you have any questions, require technical assistance, or need to report a missing/damaged part, please contact VAXCEL customer service. Contact information can typically be found on the VAXCEL website or on your product packaging.

For more information about VAXCEL products, visit the [VAXCEL Store on Amazon](#).

© 2024 VAXCEL. All rights reserved.

Related Documents - F0057

	<p>Vaxcel T0809 Outdoor Flush Mount Ceiling Light Assembly and Installation Instructions</p> <p>Comprehensive assembly and installation guide for the Vaxcel T0809 outdoor flush mount ceiling light. Includes step-by-step instructions, hardware details, spare parts, and warranty information.</p>
	<p>Vaxcel F0097 Ceiling Fan: Limited Lifetime Warranty, Installation Guide, and Troubleshooting</p> <p>This document provides the limited lifetime warranty, package contents, detailed installation instructions, safety precautions, remote control operation, and troubleshooting guide for the Vaxcel F0097 ceiling fan.</p>
	<p>Vaxcel C0264 Semi-Flush Mount Ceiling Light Assembly and Installation Instructions</p> <p>Detailed assembly and installation guide for the Vaxcel C0264 semi-flush mount ceiling light. Includes hardware list, step-by-step instructions, and spare parts information.</p>

<p>ASSEMBLY AND INSTALLATION INSTRUCTIONS</p> <p>WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, ALWAYS UNPLUG THE LIGHT FROM THE WALL SWITCH BEFORE ATTEMPTING TO ASSEMBLE OR DISASSEMBLE THE LIGHT. ALWAYS USE THE CORRECT WIRING AND GROUNDING REQUIREMENTS. ALWAYS FOLLOW THE LOCAL ELECTRICAL CODES.</p>  <p>Installation Steps:</p> <ol style="list-style-type: none"> 1. Mount the mounting bracket to the ceiling using the provided screws. 2. Attach the mounting arm to the bracket and the mounting bracket to the ceiling. 3. Connect the wiring to the mounting arm. 4. Attach the mounting arm to the mounting bracket. 5. Attach the mounting arm to the mounting bracket. <p>Page 1/2</p>	<p>Vaxcel W0547/W0548 Assembly and Installation Instructions</p> <p>Comprehensive assembly and installation guide for Vaxcel W0547 and W0548 lighting fixtures, detailing hardware, wiring, mounting steps, spare parts, and warranty information.</p>
<p>ASSEMBLY AND INSTALLATION INSTRUCTIONS</p> <p>WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, ALWAYS UNPLUG THE LIGHT FROM THE WALL SWITCH BEFORE ATTEMPTING TO ASSEMBLE OR DISASSEMBLE THE LIGHT. ALWAYS USE THE CORRECT WIRING AND GROUNDING REQUIREMENTS. ALWAYS FOLLOW THE LOCAL ELECTRICAL CODES.</p>  <p>Installation Steps:</p> <ol style="list-style-type: none"> 1. Mount the mounting bracket to the ceiling using the provided screws. 2. Attach the mounting arm to the bracket and the mounting bracket to the ceiling. 3. Connect the wiring to the mounting arm. 4. Attach the mounting arm to the mounting bracket. 5. Attach the mounting arm to the mounting bracket. <p>Page 1/2</p>	<p>Vaxcel C0341 Ceiling Light Fixture Assembly and Installation Instructions</p> <p>Detailed assembly and installation guide for the Vaxcel C0341 ceiling light fixture, including hardware lists, step-by-step instructions, and warranty information.</p>
<p>VAXCEL</p> <p>ORIGINAL VAXCEL CEILING FAN LIGHTS ARE THE ONLY CEILING FAN LIGHTS THAT CAN BE USED IN THE CEILING FAN LIGHTS.</p> <p>WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, ALWAYS UNPLUG THE LIGHT FROM THE WALL SWITCH BEFORE ATTEMPTING TO ASSEMBLE OR DISASSEMBLE THE LIGHT. ALWAYS USE THE CORRECT WIRING AND GROUNDING REQUIREMENTS. ALWAYS FOLLOW THE LOCAL ELECTRICAL CODES.</p>  <p>Installation Steps:</p> <ol style="list-style-type: none"> 1. Mount the mounting bracket to the ceiling using the provided screws. 2. Attach the mounting arm to the bracket and the mounting bracket to the ceiling. 3. Connect the wiring to the mounting arm. 4. Attach the mounting arm to the mounting bracket. 5. Attach the mounting arm to the mounting bracket. <p>Page 1/2</p>	<p>VAXCEL F0128 Ceiling Fan Installation Guide and Limited Lifetime Warranty</p> <p>Comprehensive installation guide, safety instructions, troubleshooting tips, and limited lifetime warranty details for the VAXCEL F0128 Ceiling Fan.</p>