

## OVENTE KP72B

# OVENTE Electric Kettle KP72B User Manual

Model: KP72B | Brand: OVENTE

## 1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your OVENTE Electric Kettle, Model KP72B. This 1.7L electric kettle is designed for fast water boiling, featuring automatic shut-off, boil-dry protection, and a removable filter for clean water. Please read all instructions carefully before first use and retain for future reference.

## 2. IMPORTANT SAFETY INFORMATION

**WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions.**

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Always ensure the lid is securely closed during operation.
- The kettle body may become extremely hot during operation. Always use the cool-touch handle to avoid burns.

## 3. PRODUCT OVERVIEW AND COMPONENTS

The OVENTE Electric Kettle KP72B is designed for user convenience and safety. Familiarize yourself with its components:

- **Kettle Body:** The main container for water, made from durable, BPA-free material with a stainless steel concealed heating element.
- **Power Base:** A 360° rotary base that supplies power to the kettle. Features built-in cord storage.
- **Lid:** Secure locking lid that opens with a push-button mechanism.
- **Cool-Touch Handle:** Ergonomically designed for safe handling, even when the kettle is hot.
- **Water Level Gauge:** Transparent window with markings to indicate water volume (Min 0.5L to Max 1.7L).
- **LED Indicator Light:** Illuminates when the kettle is actively boiling water.
- **Removable Filter:** Located in the spout, it ensures debris-free water and is easy to clean.
- **On/Off Switch:** Activates the boiling process.



Figure 1: OVENTE Electric Kettle KP72B (Black)



Figure 2: Detail of Water Level Gauge, LED Indicator, and BPA-Free Certification.

## 4. SETUP AND FIRST USE

---

1. **Unpack:** Carefully remove the kettle and all accessories from the packaging.
2. **Clean:** Before first use, fill the kettle with water to the MAX line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Position:** Place the power base on a dry, flat, stable surface away from the edge of the counter. Ensure the cord is not dangling where it can be pulled or tripped over.
4. **Cord Storage:** The power base includes built-in cord storage slots to keep your kitchen neat and organized. Adjust the cord length as needed.

## 5. OPERATING INSTRUCTIONS

---

1. **Fill the Kettle:** Press the button on the lid to open it. Fill the kettle with fresh water between the 0.5L MIN and 1.7L MAX marks on the water level gauge. Do not overfill or underfill.

2. **Close Lid:** Close the lid securely until it clicks into place.
3. **Place on Base:** Place the kettle firmly onto the power base.
4. **Power On:** Plug the power base into a standard electrical outlet. Press the On/Off switch located on the handle downwards. The LED indicator light will illuminate, signaling that the kettle is heating.
5. **Boiling Process:** The kettle will begin to heat the water. It operates at 1100W and can boil a full 1.7L of water in minutes.
6. **Automatic Shut-Off:** Once the water reaches its boiling temperature (100°C / 212°F), the kettle will automatically shut off, and the LED indicator light will extinguish.
7. **Pouring:** Carefully lift the kettle from its base using the cool-touch handle and pour the hot water.
8. **Boil-Dry Protection:** The kettle is equipped with boil-dry protection, which automatically shuts off the heating element if there is no water in the kettle, preventing damage.

## Operational Videos

Your browser does not support the video tag.

Video 1: A detailed review and demonstration of the Ovente Electric Hot Water Kettle, showcasing its features and operation. (Source: THE SANDE SHOP)

Your browser does not support the video tag.

Video 2: Demonstration of the Ovente Electric Kettle's convenience for cooking and coffee preparation. (Source: Lovelee Joy Rios)

## 6. MAINTENANCE AND CLEANING

---

Regular cleaning and maintenance will ensure the longevity and optimal performance of your kettle.

- **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Interior Cleaning (Hand Wash):** The interior of the kettle should be hand washed. Do not immerse the power base or the exterior of the kettle body in water.
- **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale:
  - a. Mix 3 tablespoons of white vinegar or lemon juice with water.
  - b. Fill the kettle with this solution to the MAX line.
  - c. Allow it to boil.
  - d. Let the solution sit in the kettle for a minimum of five hours.
  - e. Discard the solution and rinse the kettle thoroughly with fresh water.
- **Removable Filter:** The spout filter can be easily slid out for cleaning. Rinse it under running water to remove any debris. Slide it back into place after cleaning.



Figure 3: Removing the removable filter for cleaning.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	No power supply. Kettle not properly seated on base.	Check if the power base is plugged in. Ensure the kettle is correctly placed on the power base.
Water is not boiling.	Insufficient water. Kettle has boil-dry protection activated.	Ensure water level is above MIN mark. If boil-dry activated, let kettle cool down before refilling.
Kettle switches off before boiling.	Excessive limescale buildup.	Descale the kettle as per the cleaning instructions.
Water has an unusual taste.	New appliance residue or limescale.	Perform initial cleaning steps again. Descale if necessary.

## 8. SPECIFICATIONS





- **Brand:** OVENTE
- **Model:** KP72B
- **Capacity:** 1.7 Liters
- **Power:** 1100W (120V)
- **Material:** BPA-Free, Stainless Steel (concealed heating element)
- **Color:** Black
- **Product Dimensions:** 8.5"L x 6.5"W x 8.7"H
- **Item Weight:** 2.06 pounds
- **Special Features:** Automatic Shut-Off, Boil-Dry Protection, Indicator Light, Removable Filter, 360° Rotary Base, Cord Storage.



## 9. WARRANTY AND SUPPORT

OVENTE warrants that this product shall be free from defects in material and workmanship under normal use and conditions for **2 years** from the original purchase date. For warranty claims or customer support, please contact OVENTE customer service. Keep your proof of purchase for warranty validation.

© 2025 OVENTE. All rights reserved.

### Related Documents - KP72B

	<a href="#">Ovente KG733 Series Temperature Control Electric Kettle with Integrating Teapot User Manual</a> User manual for the Ovente KG733 Series Temperature Control Electric Kettle with Integrating Teapot. Includes important safety information, parts and features, operating instructions, cleaning and descaling guides, electrical specifications, and warranty details.
	<a href="#">Ovente FSW Hailey French Press User Manual</a> A comprehensive guide to using, caring for, and maintaining your Ovente FSW Hailey French Press coffee maker. Learn about its parts, features, and get answers to frequently asked questions.
	<a href="#">Ovente HS560 Series Multi-Purpose Immersion Hand Blender - User Manual, Features, and Warranty</a> Comprehensive guide for the Ovente HS560 Series Multi-Purpose Immersion Hand Blender. Details features, usage instructions, safety precautions, care, maintenance, and warranty information for this powerful 300-watt kitchen appliance.
	<a href="#">Ovente OFD4025 Series Digital Air Fryer Rotisserie Oven User Manual</a> User manual and guide for the Ovente OFD4025 Series Digital Air Fryer Rotisserie Oven, covering important safeguards, parts and features, operating instructions, care and maintenance, and warranty information.

<div data-bbox="116 114 309 360"><p><b>OVENTE</b> Air Fryer Oven Quick Start Guide</p><p>OFM2025BR</p></div>	<p><a href="#">OVENTE Air Fryer Oven OFM2025BR Quick Start Guide</a></p> <p>A concise guide to operating the OVENTE OFM2025BR Air Fryer Oven, covering function selection, temperature setting, and timer operation.</p>
<div data-bbox="116 405 309 651"><p><b>OVENTE</b> Electric Single Burner BGC101 Series</p><p><small>Before using, please read the instruction manual and keep it for future use.</small></p></div>	<p><a href="#">Ovente Electric Single Burner BGC101 Series User Manual and Recipes</a></p> <p>Comprehensive user manual and recipe guide for the Ovente Electric Single Burner BGC101 Series. Includes important safety precautions, parts identification, operating instructions, care and maintenance tips, and delicious recipes.</p>